



K A C O 
new energy.

KACO blueplanet 100 NX3
KACO blueplanet 125 NX3

B / M / MF / L

Manual

■ English translation of German original

 **Authorised electrician**

Important safety instructions

These instructions form part of the product and must be carefully read, observed and stored in a place which is freely accessible at all times.

Legal provisions

The information contained in this document is the property of KACO new energy GmbH. Publication of this document, in whole or in part, is subject to the written consent of KACO new energy GmbH.

Definitions on product designations

In this Manual, the product "Photovoltaic feed-in inverter" is referred to as "device" for ease of reading.

Trademarks

All trademarks are recognised, even if not explicitly identified as such. A lack of identification does not mean that a product or designation/logo is free of trademarks.

Software

This device contains open source software that has been developed by third parties. The software is licensed, amongst others, under GPL and LGPL.

More details on this topic and a list of the open source software used, as well as the corresponding licence texts, can be found in the web interface information display under "Licence List".

Change history

The following table documents all changes to this document. If you have any questions about a specific version, please contact KACO customer service.

Photovoltaic feed-in inverter

Contents

1	General information	4	8.2	Preconditions relating to standards	37
1.1	About this document	4	8.3	Network topologies	38
1.2	More information	4	8.4	Start-up options	38
1.3	Layout of Instructions	5	9	Configuration and operation	44
1.4	Target group	6	9.1	Initial start-up	44
1.5	Identification	6	9.2	Signal elements	45
1.6	Warnings on the device	6	9.3	User interface	47
2	Safety	7	9.4	Menu structure	50
2.1	Intended use	7	9.5	Monitoring the device	75
2.2	Protection features	8	9.6	Performing a firmware update	75
3	Description of the device	9	9.7	Access via Modbus	76
3.1	Mode of operation	9	10	Specifications	77
3.2	Device diagram	9	10.1	Reactive power control	77
3.3	System layout	11	10.2	Active power regulation	85
4	Technical data	12	10.3	FRT	91
4.1	Electrical data	12	10.4	Other grid-supporting functions that are effective in the case of active power	95
4.2	General data	13	10.5	Advanced islanding detection	97
4.3	Environmental data	14	10.6	Q on Demand	98
4.4	Accessories	14	11	Maintenance and troubleshooting	100
5	Transportation and Delivery	16	11.1	Visual inspection	100
5.1	Check the equipment included	16	11.2	Cleaning	100
5.2	Transporting the device	16	11.3	Replacing the fan	101
5.3	Installation tool	16	11.4	Replacing overvoltage protection	102
6	Assembly and preparation	17	11.5	Shutting down for maintenance	102
6.1	Choosing the installation location	17	11.6	Troubleshooting	103
6.2	Unpacking the device	18	11.7	Messages	104
6.3	Preparing the installation location	19	11.8	Event messages	104
6.4	Installing and securing the device	20	12	Decommissioning and dismantling	117
7	Installation	22	12.1	Switching off the device	117
7.1	General information	22	12.2	Disconnecting connections	117
7.2	Opening the housing	22	12.3	Uninstalling the device	118
7.3	Surveying the connection area	22	12.4	Removing the device	118
7.4	Making the electrical connection	22	12.5	Packaging the device	118
7.5	Connecting the device to the power grid	24	12.6	Storing the device	118
7.6	Connecting the PV generator to the device	25	13	Disposal	120
7.7	Establishing equipotential bonding	32	14	Service and warranty	121
7.8	Connecting the interfaces	32	15	Appendix	122
7.9	Sealing the connection area	36	15.1	EU Declaration of Conformity (EN)	122
8	Commissioning	37	15.2	Standards & directives	122
8.1	Requirements	37			

1 General information

1.1 About this document



⚠ WARNING

Improper handling of the device can be hazardous!

1. You must read and understand the manual in order to install and use the device safely.

Other applicable documents

During installation, observe all assembly and installation instructions for components and other parts of the system. These instructions also apply to the equipment, related components and other parts of the system.

Some of the documents required for the registration and approval of your system are included with the manual.

Storing the documents

These instructions and other documents must be stored near the system and be available at all times.

- The current version of the manual can be downloaded from www.kaco-newenergy.com/de/downloads.

English translation of German original

This document has been produced in several languages. The German-language version is the original version. All other language versions are translations of the original version.

This document is valid for the following types of device from firmware version: V.5.1.10.3

Previous versions with older firmware can be found in the respective archive folder:

Type designation [KACO art. no.]		
	KACO blueplanet 100 NX3 M8 WM OD IIGX	[1002081] variant „B“
	KACO blueplanet 100 NX3 M8 WM OD IIGM	[1002132] variant „M“
	KACO blueplanet 100 NX3 M8 WM OD FRGM	[1002133] variant „MF“
	KACO blueplanet 100 NX3 M8 WM OD IIGL	[1002170] variant „L“
	KACO blueplanet 125 NX3 M10 WM OD IIGX	[1002080] variant „B“
	KACO blueplanet 125 NX3 M10 WM OD IIGM	[1002131] variant „M“
	KACO blueplanet 125 NX3 M10 WM OD FRGM	[1002130] variant „MF“
	KACO blueplanet 125 NX3 M10 WM OD IIGL	[1002171] variant „L“

General product information

The device is a photovoltaic inverter without galvanic isolation that converts direct voltage into alternating voltage. The input is connected via solar connectors and has 8 / 10 MPP trackers, two of which can be connected together in pairs. The PV disconnecter is an integral part of the device. The mains connection is made via busbars and offers integrated disconnection in accordance with IEC 62109-2 Ed 1.0.

- The IIGX models (variant "B") have directly soldered SPDs on the AC and DC inputs.
- The IIGM models (variant "M") have plug-in SPDs on the AC and DC inputs.
- The FRGM models (variant "MF") have plug-in SPDs and additional insulation foils in the DC area. Moreover, this variant measures the phase voltage against N instead of PE. Consequently, the connection to N is mandatory.
- The IIGL models (variant "L") have arc fault detection in accordance with IEC 63027:2023

1.2 More information


Links to more detailed information can be found at www.kaco-newenergy.com

Document title	Document type
Technical data sheet	Product flyer
Modbus protocol RS485 protocol reactive power control	Application note
SunSpec information model reference SunSpec information model reference KACO	Excel files for software version with application note "Modbus protocol" under https://kaco-newenergy.com/downloads/


Document title	Document type
Software package	Files for current software
EU Declaration of Conformity Country-specific certificates Module-specific certification	Certificates


1.3 Layout of Instructions


1.3.1 Symbols used


	General hazard		Fire and risk of explosion
	Electrical voltage		Risk of burns
	Earthing – protective earth conductor		Capacitor discharge

1.3.2 Safety warnings symbols guide


 **DANGER**
High risk
 Failure to observe this warning will lead directly to serious bodily injury or death.

 **WARNING**
Potential risk
 Failure to observe this warning may lead to serious bodily injury or death.

 **CAUTION**
Low-risk hazard
 Failure to observe this warning will lead to minor or moderate bodily injury.

 **CAUTION**
Risk of damage to property
 Failure to observe this warning will lead to property damage.

1.3.3 Additional information symbols

 **NOTE**
Useful information and notes
 Information that is important for a specific topic or objective, but that is not safety-relevant.

1.3.4 Symbols for instructions

↪ Prerequisite for use

1. Carry out the step
2. Additional action sequence

⇒ Interim result of the action

⇒ End result

1.3.5 Visualisation in images & graphics

1. Item numbers with localisation lines
2. Localisation table and reference in the text to the item numbers acc. to item 1
3. Sequence of action steps with item numbers in the circle.
4. Reference in the text to the sequence of action steps.

1.4 Target group

All activities described in the document may only be carried out by specially trained personnel with the following qualifications:

- Knowledge about how an inverter functions and operates
- Knowledge of the Modbus specifications
- Knowledge of the SunSpec Modbus specifications
- Training in the handling of hazards and risks during the installation and operation of electrical units and plants.
- Education concerning the installation and start-up of electrical devices and systems.
- Knowledge of applicable standards and directives.
- Knowledge and adherence to this document with all safety notices.
- Failure to follow the prescribed instructions may invalidate the manufacturer's warranty. If you are uncertain about anything, please contact your local KACO service team.

1.5 Identification

You will find the name plate with the following data for service and other requirements specific to installation on the right side panel of the product:

- Product name
- Part no.
- Serial number
- Date of manufacture
- Technical data
- Disposal information
- Certification marking, CE marking.

KACO 		blueplanet 125 NX3 M10 WM OD IGL	
KACO new energy GmbH		Part number	1002171
10000, Heidepark 44129 Münster, Germany Made in Germany		Serial number	125NX30XXXXXX00EC
		Year	02 / 21
			
Input	Vmax PV / Lc PV (max) / I from PV	1100 Vdc / 100 A / 100 A	
	V-MPP at Prim / V-range	550 V - 850 V / 200 V - 1000 V	
Nominal voltage		400 V (3/N/PE)	
Output	Voltage range continuous operation	300 V - 460 V (R+P)	
	Current (maximum continuous)	3 x 18.2 A	
	Frequency range	45 Hz - 65 Hz	
	Rated power at 380 V	120 000 VA	
	Rated power at 400 V	125 000 VA	
Output Power	Maximal power	125 000 VA	
	Reactive power	0-60 % _{nom} cos phi 0.8 ind - 0.8 cap	
Environment	Temperature range	-25°C - +50°C	
	Protection class / Ingress protection	IP66	
No galvanic separation / Ungrounded Arrays Only		Max. Backfed Current	0 A
Grid Support Interactive Inverter		AC Multi circuit protection	Yes
Interface protection according to country specific requirements, details see manual			
			

Fig. 1: Name plate

1.6 Warnings on the device

A warning sticker is affixed to the device. Read the warnings carefully.

Do not remove the sticker. If the sticker is missing or is illegible, please contact a KACO representative or distributor.

- Article number: 3016164



Fig. 2: Warning sticker

2 Safety



⚠ DANGER

Lethal voltages are still present in the connections and cables of the device even after the device has been switched off and disconnected!

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched.

1. Comply with all safety regulations and current technical connection specifications of the responsible power supply company.
2. The device is only permitted to be opened or serviced by a qualified electrician.
3. Switch off the grid voltage by turning off the external circuit breakers.
4. Capacitor discharge time: Wait at least 5 minutes before opening.
5. Do not touch the cables and/or terminals/busbars when switching the device on and off.
6. Keep the device closed when in operation.

The electrician is responsible for observing all existing standards and regulations. The following applies:

- Keep unauthorised persons away from the device and/or system.
- In particular, making sure that the locally applicable version of the standard ¹ "Requirements for special installations or locations – solar photovoltaic (PV) power supply systems" is observed.
- Ensure operational safety by providing proper grounding, conductor dimensioning and appropriate protection against short circuiting.
- Observe the safety instructions on the product and in this manual.
- Switch off all voltage sources and secure them against being inadvertently switched back on before performing visual inspections and maintenance.
- When taking measurements on the live device:
 - Do not touch the electrical connections
 - Remove all jewellery from wrists and fingers
 - Ensure that the testing equipment is in safe operating condition.
- Modifications to the surroundings of the device must comply with the applicable national and local standards.
- When working on the PV generator, in addition to disconnecting this from the grid it is also necessary to switch off the DC voltage using the DC isolator switch on the device.

⚠ CAUTION

Damage to the device from electrostatic discharge

Components inside the device can be damaged beyond repair by static discharge.

1. Observe the ESD protective measures.
2. Earth yourself before touching a component by touching a grounded object.

2.1 Intended use

The device is a transformerless PV inverter which converts the direct current of the PV generator into grid-compatible three-phase alternating current and then feeds the three-phase alternating current into the public power grid.

The device is built using state-of-the-art technology and in accordance with the recognized safety rules. Nevertheless, improper use may cause lethal hazards for the operator or third parties, or may result in damage to the product and other property.

¹ Country	Standard
EU	Harmonised document - HD 60364-7-712 (European implementation of the IEC standard)
USA	PV section of NEC 690 and sections in article 100, 690.4, 690.6 and 705.10

Tab. 1: Examples of standards specific to business premises

The device is intended for indoor and outdoor applications and may only be used in countries for which it has been approved or for which it has been released by KACO new energy and the grid operator.²

Operate the device only with a permanent connection to the public power grid. The country and grid type selection must be commensurate with the respective location and grid type.

The requirements of the grid operator must be met for grid connection to take place. The permission of the relevant authorities may also be required in order to secure authorisation to connect to the grid.

The name plate must be permanently attached to the product and must be in legible condition.

Any other or additional use is not considered proper or intended use and can lead to an annulment of the product guarantee. This includes:

- Mobile use
- Use in rooms where there is a risk of explosion
- Use in direct sunlight, rain or a storm or other harsh environmental conditions
- Outdoor use in environmental conditions that exceed the limits stated in the technical specifications >Environmental data.
- Operation outside the specification intended by the manufacturer
- Overvoltage of more than 1,100 V on the DC connection
- Device modification
- Standalone mode

2.2 Protection features

The following monitoring and protection functions are integrated in the device:

- RCMU (Residual Current Monitoring Unit)
- Overvoltage conductor / varistor to protect the power semiconductors from high-energy transients on the grid and generator sides.
- Device temperature monitoring system
- EMC filter to protect the product from high-frequency grid interference
- Grid-side varistors grounded to earth to protect the product against burst and surge pulses
- Anti-islanding detection according to the current standards
- ISO detection of a generator insulation fault.
- Arc detection (ARC fault detection) of 2 MPP trackers each for model variant 'L'.



NOTE

Overvoltage conductors / varistors influence the insulation resistance test when the device is connected

If the device is connected, the overvoltage conductors / varistors contained in the device have an impact on the electrical system insulation resistance test as per HD 60364-6 / IEC 60364-6 Low-voltage installations- Part 6: Verification.

IEC 60364-6 6.4.3.3 describes two options for this case. The first option is to disconnect devices with an overvoltage conductor or, if this is not practicable, then the test voltage can be reduced to 250 V.

² **WARNING! The device is not intended for use in residential areas and cannot ensure adequate protection of radio reception in such environments.**

3 Description of the device

3.1 Mode of operation

The device converts the DC voltage generated by the PV modules into AC voltage and feeds it into the grid. The starting procedure begins when there is sufficient sunlight and a specific minimum voltage is present in the device. The feed-in process begins once the PV generator has passed the insulation test and the grid parameters are within the requirements imposed by the grid operator for a specific monitoring time. If, as it gets dark, the voltage drops below the minimum voltage value, feed-in mode ends and the device switches off.

3.2 Device diagram




Fig. 3: Device diagram (M10 variant)




Fig. 4: Device diagram (M8 variant)

Key

1 Housing	6 Heat sink housing
2 Cover	7 Interface / cable feed-through
3 Status indicator	8 USB socket
4 Pedestal with carrying handle	9 DC connection / DC isolator switch
5 AC connection	10 Fan drawer (left/right)

3.2.1 Mechanical components

DC isolator switch

5(M10) / 4(M8) DC isolator switches are located on the underside of the device. These are used to individually disconnect four connected PV generator strings from the DC supply in the device in the event of servicing.

Disconnecting the device from the PV generator

☞ Switch the DC isolator switches from 1 (ON) to 0 (OFF).

Connecting the device to the PV generator

☞ Switch the DC isolator switches from 0 (OFF) to 1 (ON).




Fig. 5: DC isolator switch

3.2.2 Electrical functions

A potential-free relay contact is integrated into the device. Use this contact for one of the following functions:

Potential-free relay

The potential-free relay contact closes as soon as there is a fault during operation. You use this function, for example, to signal a fault visually or acoustically.

3.2.3 Special software functions

Reactive power if required (Q on Demand)

The device can provide reactive power in the long term over the full power range using the "Q on Demand" function.

3.2.4 Interfaces

You can configure the interfaces and the web server in the Settings menu. The device has the following interfaces for communication and remote monitoring:

Ethernet interface

Monitoring can occur directly on the device using the integrated Ethernet interface. A local web server is installed in the device for this purpose. This can also be used to request measured values remotely.

For monitoring a system comprising several inverters, we recommend you use an external data logging and monitoring system.

Ethernet interface

The device features two switched Ethernet ports to enable the user to, for example, connect several devices in series if the user prefers a linear topology.

USB port

The device's USB connection is a type A socket. It is located on the communication circuit board. The USB connection is specified to draw 5 V/500 mA of current.

Use the USB interface to read out stored operating data, load firmware updates or device configurations using a FAT32-formatted USB stick (max. 4GB).

It is possible to establish a connection to the webserver integrated into the device by connecting a USB-Wi-Fi stick. In addition to commissioning, service information and firmware updates, more extensive configurations are also possible via the web interface.

"Inverter Off" input / DRMO for Australia

In addition to the safety functions, the internal interface switches can also be actuated via the "Inverter Off" input.

If a Powador-protect is used as the central interface protection, the fail-safe disconnection of suitable KACO inverters from the public grid can be carried out by the internal interface switches instead of separate interface switches. This requires the inverters in the photovoltaic system to be connected to the Powador-protect.

Information on installation and use can be found in this manual, in the Powador protect operating instructions and in the instructions for use of the Powador protect on the KACO web site.

3.3 System layout




Fig. 6: Circuit diagram with a short or long supply cable to the inverter




Fig. 7: Circuit diagram from the grid connection point to the inverter

Key	Definition / information on the connection
PV generator	The PV generator converts the radiant energy of sunlight into electrical energy.
Transf.	All three phases need to be set up on the medium-voltage transformer or medium-voltage/high-voltage transformer. In this case, the total impedance of the transformer stations must be below 25%. NOTE: The grounding takes place in the star point that is fed out. (Dy5) – For additional information, see: application note "Grid type and impedance requirements ..."
Grid connection point	The clean PV-current is made available at the grid connection point.
DC isolator switch	Use the DC isolator switch to disconnect the device from the PV generator.

4 Technical data

4.1 Electrical data

DC input data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L	
Maximum recommended PV generator power	200 kW				250 kW				
MPPrange@Pnom	550 - 850 V								
Working range	200 - 1,000 V								
Rated voltage	620 V								
Starting voltage	250 V								
Open circuit voltage	1,100 V								
Nominal DC current (Inom) ^{3 4}	8 x 30 A				10 x 30 A				
Max. power/MPP tracker	15.5 kW								
Number of strings	2								
Number of MPP trackers	8				10				
Max. DC current (ISC max.)	8 x 37.5 A				10 x 37.5 A				
Input source feedback current	0 A								
Polarity safeguard	no								
Integrated electric arc	no			yes		no			yes
Overvoltage protection	2 soldered	1/2 pluggable			2 soldered	1/2 pluggable			
String fuse	no								
AC output data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L	
Rated power @ nominal voltage (x KVA@30°C/40°C/50°C)	100 kVA				125 kVA				
Rated voltage	400 V (3P+N+PE)								
Voltage range: continuous operation	300 V–460 V								
Max. voltage range (up to 100 s)	500 V								
Rated current	3 x 144.3 A				3 x 180.4 A				

³ The operating current per MPP tracker is limited to 30 A by the inverter. PV modules are allowed to have a higher operating current. The configuration is limited by the ISC_{max} . Also observe the max. current-carrying capacity of 20 A/DC plug. When high-current module strings are used with a rated current of over 20 A/string, Y-adapters must be employed [See figure 31 ▶ Page 28].

⁴ The "Nominal PV current (Inom)" is the maximal theoretical value for operation with full power when the feed-in power is low. The device is limited to the maximum AC power.

The "Max. PV current (ISC_{max})" together with the open circuit voltage (U_{DCmax}) defines the characteristic of the connected PV generator. This is the relevant value for string design and represents the absolute maximum limit for inverter protection. The connected PV generator must be designed in such a way that the maximum PV current is less than or equal to the ISC_{max} of the device under all foreseeable conditions and therefore complies with IEC 61730 Class A. Under no circumstances may the design lead to a short-circuit current greater than the ISC_{max} of the device [See section 7.6.2 ▶ Page 26].

AC output data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Max. continuous current	3 x 182 A							
Contribution to peak short-circuit current i_p	343.2 A							
Initial short-circuit alternating current (I_k'' first single period effective value)	190.2 A							
Short-circuit alternating current duration (max output fault current)	3 x 182.66 A							
Inrush current	<20 A [RMS (20ms)]							
Rated frequency	50 Hz							
Frequency range	45-65 Hz							
Reactive power	0-60 % S_{nom}							
cos phi	0.80–0.80 cap							
Number of feed-in phases	3							
Distortion factor (THD)	< 3 %							
Overvoltage protection	2 soldered	2 pluggable			2 soldered	2 pluggable		

4.2 General data

General data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Max. efficiency	99.0 %			99.1 %				
European efficiency	98.8 %			98.7 %				
Self consumption: Standby	4.8 W 400 V AC no LAN							
Feed-in from	60 W							
Circuit design	transformerless							
Protection class / overvoltage category	I / III (AC) II (DC)							
Classification of the ARC	-			F-I- AFPE-2-4-5	-			F-I- AFPE-2-4-5
Auto-reclosure method	-			Automatic	-			Automatic
Grid monitoring	yes							
Distribution system	TN-C/TN-C-S/TN-S/TT, solid grounded wye							
Mechanical data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Display	LEDs							
Controls	Web server							
Menu languages	EN; DE; FR; IT; ES; PL; NL; PT; CZ; HU; SL; TR; RO							
Interfaces	2 x Ethernet, USB, RS485, error_rel, inverter_OFF, WiFi (temporary)							
Communication	TCP/IP, Modbus TCP, based on Sunspec							
Q on Demand	yes							
Potential-free relay	yes							
DC isolator switch	yes							
AC isolator switch	no							

Mechanical data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Cooling	Temp. controlled fan							
Number of fans	6x outside, 2x inside							
Noise emission	<60 db(A)							
Housing material	AL							
HxWxD	740 mm x 1023 mm x 330 mm							
Weight	85 kg							

4.3 Environmental data

Environmental data	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Installation height	3,000 m							
Installation distance from coast	C4							
Ambient temperature ⁵	-25-+60 °C							
Ambient temperature (storage)	-40-80 °C							
Power derating from	Temperature-dependent on applied DC voltage °C							
Protection rating (in-installation location)	IP66							
Humidity range (non-condensing)	100 %							
Pollution level inside the enclosure	2							
Pollution level outside the enclosure	3							

Certification	100 NX3 B	100 NX3 M	100 NX3 MF	100 NX3 L	125 NX3 B	125 NX3 M	125 NX3 MF	125 NX3 L
Safety	EN 62109-1:2010, EN 62109-2:2011							
Interference immunity/interference emission/grid feedback	Interference immunity: EN IEC 61000-6-1:2019 EN 61000-6-1:2007 EN IEC 61000-6-2:2019 EN 61000-6-2:2005/AC:2005 EN 62920:2017/A11:2020 Class A Störaussendung: EN 62920:2017/A11:2020 Class A* EN 55011:2016/A11:2020+ A2:2021 group 1, Class A* *DC→ > 20 kVA ≤ 75 kVA EN IEC 61000-6-4:2019 EN 61000-6-4:2007 +A1:2011 Netrückwirkungen: EN 61000-3-11:2000 EN IEC 61000-3-11:2019 EN 61000-3-12:2011							
Certifications	Overview: see homepage, download area							
Item number	1002081	1002132	1002133	1002170	1002080	1002131	1002130	1002171
Name on nameplate	blueplanet 100 NX3 M8 WM OD IIGX	blueplanet 100 NX3 M8 WM OD IIGM	blueplanet 100 NX3 M8 WM OD FRGM	blueplanet 100 NX3 M8 WM OD IIGL	blueplanet 125 NX3 M10 WM OD IIGX	blueplanet 125 NX3 M10 WM OD IIGM	blueplanet 125 NX3 M10 WM OD FRGM	blueplanet 125 NX3 M10 WM OD IIGL

4.4 Accessories

KACO order number	Designation
1002121	Mounting frame kit bp100NX3/125NX3
1002321	Multicore AC input plate kit bp100NX3/125NX3 (PK69T / M32)
1002173	Multicore AC input plate kit bp100/125NX3 (M63 / M32)
1002120	Daisy chain AC input plate kit bp100NX3/125NX3 (double row)
1002160	AC SPD type 1+2 kitbp100NX3/125NX3 (3+1)
3016362	USB wifi adapter bp100NX3/125NX3

⁵ Power derating at high ambient temperatures.

KACO order number	Designation
1002192	Spare part kit AC SPD type 2 bp100/125NX3
1002193	Spare part kit DC SPD type 1+2 bp100NX3 M8
1002194	Spare part kit DC SPD type 1+2 bp125NX3 M10
1002195	Spare part kit external fan (2x) bp100NX3/125NX3
1002196	Spare part kit interior fan (3x) bp100NX3/125NX3

5 Transportation and Delivery

Every product leaves our factory in perfect electrical and mechanical condition. Special packaging ensures that the devices are transported safely. The shipping company is responsible for any transport damage that occurs.

5.1 Check the equipment included

- Inverter
- DC solar connector (8/10 pairs) Requirement for supply lines and fuse
- Mounting kit consisting of:
5x AC mounting screws with spring washers and 5x hexagon nuts, 1x RS485 and 1x INV-OFF communication connector, 1x 2-pole connector, 1x cable sealing insert, 4x wall mounting screws with dowels, 4x profile mounting screws, 2x locking screws with nuts, 6x cable ties. [See figure 8 [▶ Page 16]
- Leaflet as a drilling template
- Quick guide [multi-language] / Manual [online]




Fig. 8: Installation kit

1. Inspect the device thoroughly.
2. Immediately notify the shipping company in case of the following:
 - Damage to the packaging that indicates that the device may have been damaged.
 - Obvious damage to the device.
3. Send a damage report to the shipping company immediately.
4. The damage report must be received by the shipping company in writing within 6 days following receipt of the device. We will be glad to help you if necessary.

5.2 Transporting the device

⚠ CAUTION

Hazard due to impact; risk of breakage to the device.

1. Pack the device securely for transport.
2. Carefully transport the device using the transportation pallet.
3. Do not expose the device to any shocks.

For safe transportation of the product, use the hand recesses in the carton.

Packaging	Folding cardboard box
Height x width x depth	830 x 1170 x 560 mm
Total weight	90 kg








Fig. 9: Transporting the device

5.3 Installation tool

The codes given in the table below are used in all usage instructions for assembly/installation/maintenance and disassembly for the tools and tightening torques being used.

Sym- bol	Screw head con- tour	Sym- bol	Screw head contour
	External hexagon		Internal hexagon
	Torx		Slot

Tab. 2: Key and description of tool codes




Fig. 10: Presentation format

6 Assembly and preparation

6.1 Choosing the installation location



DANGER

Risk of fatal injury due to fire or explosions

Fire caused by flammable or explosive materials in the vicinity of the device can lead to serious injuries.

1. Do not mount the device in potentially explosive atmospheres or in the vicinity of highly flammable materials.



CAUTION

Risk of property damage due to gases that have an abrasive effect on surfaces when they come into contact with ambient humidity caused by weather conditions!

The device housing can be seriously damaged due to gases in combination with air humidity resulting from weather conditions (e.g. ammonia, sulphur).

1. If the device is exposed to gases, it must be installed in a location that is visible.
2. Perform regular visual inspections.
3. Immediately remove any moisture from the housing.
4. Ensure adequate ventilation at the installation location.
5. Immediately remove dirt, especially on vents.
6. Failure to observe these warnings may result in damage to the device that is not covered by the warranty.



NOTE

Access by maintenance personnel for service

Any additional costs arising from unfavourable structural or installation conditions will be billed to the customer.

Installation space

- As dry as possible, climate-controlled, the waste heat must be dissipated away from the device.
- Unobstructed air circulation.
- Close to the ground, accessible from the front and sides without requiring additional resources.
- In outdoor areas, KACO new energy recommends protecting the device from direct weather exposure and sunlight. This should be carried out by means of constructional measures (e.g. wind breaks) in order to reduce thermal heating of the components, premature derating and more extensive wear of the fans.

Installation surface

- Must have adequate load-bearing capacity
- Must be accessible for installation and maintenance
- Must be made out of heat-resistant material (up to 90 °C)
- Must be flame resistant
- Minimum clearances to be observed during installation: [See figure 20 [▶ Page 20]]




Fig. 11: Load-bearing capacity & cooling direction




Fig. 12: Device for outdoor installation




Fig. 13: Permissible installation location




Fig. 14: Free-standing installation beneath PV system




Fig. 15: Mounting advice for installation beneath PV system

6.2 Unpacking the device



⚠ CAUTION

Risk of injury caused by excessive physical strain.

Lifting the device for transportation, to change location and during installation can lead to injuries (e.g. spinal injuries).

1. Only lift the device using the openings provided.
2. The device must be transported and installed by at least 3-4 persons.
3. Be mindful of the weight of the device and use aids to secure it.




Fig. 16: Opening the package




Fig. 17: Setting the device upright

Key	
1	Cover
2	Upper side section
3	Clamp (4x)
4	Base
5	Lower side section
6	Cardboard packaging with accessories and quick guide

☞ The device is transported to the installation location.

1. Remove the plastic band from the pallet and packaging.
2. Pull the clamp off the packaging.
3. Pull the hood upwards to remove it and place the cardboard packaging to one side together with the mounting kit.
4. Set the device with base and side sections upright.
5. Remove the top side section and base from the device.

⇒ If the device is in the correct installation position: Prepare the installation location.

6.3 Preparing the installation location

 **WARNING**

Hazard when using unsuitable fixing materials!

If unsuitable fixing materials are used, the device could fall and persons in front of the device may be seriously injured.

1. Use only fixing materials that are suitable for the mounting base. The fastening materials supplied are only to be used for masonry and concrete.
2. Only install the device in an upright hanging position.

Use the leaflet as a drilling template

☞ Have adhesive strips to hand (not in scope of supply).

1. Open the leaflet at the lower right-hand corner and smooth out the marked inner side.
2. Raise the leaflet to the installation location and fix it with adhesive strips at all four corners.
3. If necessary, adjust the position and height according to [See figure 20 ▶ Page 20] and smooth out the leaflet so that the hole pattern is precisely adhered to. (tolerance: 1mm!)
4. Choose a drill bit and drill all the fixing holes to match the holes in the leaflet.
5. Once the wall plugs are in place, the leaflet can be removed and placed back in the packaging.




Fig. 18: Using the drilling template

1	Leaflet with drill holes	2	Marking pen (optional)
3	Adhesive strips	4	

⇒ The device is ready for wall mounting.





Fig. 20: Minimum clearances for wall mounting

Fig. 19: Wall mounting

key			
1	Screws for mounting (4x) [SW 13 / [See figure 8 [▶ Page 16]]]	3	Bolt with lock nut (2x)
2	Fastening anchors [S12-Ø12 mm / 25 mm]	4	U-lock (not in scope of supply)
A	Minimum clearance: 486 mm Recommended clearance: 735 mm	1)	Minimum clearance excluding device: 500 mm Recommended clearance excluding device: 766,5 mm
B	Recommended clearanced: 1000 mm	-	-
C	Minimum clearance: 500 mm	-	-
D	Minimum clearance: 300 mm Recommended clearanced: 1000 mm	-	-

☞ Remove the mounting kit from the packaging.

1. Check that the conditions and minimum room height comply with the specified dimensions.
 2. Without a drilling template: Mark the mounting position accurately (+/- 1mm) on the wall surface using the specified distances. [See figure 20 [▶ Page 20]]
 3. Check that the upper and lower distances are parallel using a spirit level.
- NOTE: The minimum clearances between two devices, or the device and the ceiling or floor have already been taken into account in the diagram.**
4. Drill the holes at the marked position and insert the dowels all the way into the wall surface.
 5. Screw in the upper wall mounting screws to a distance of 8 mm from the wall surface.
 6. Screw in the lower wall mounting screws to a distance of 12 mm from the wall surface.
- NOTE: Make sure that the wall mounting screws are sufficiently fastened.**

⇒ Proceed with the installation of the device.

6.4 Installing and securing the device



CAUTION

Risk of injury from improper lifting and transport.

If the device is lifted improperly, it can tilt and result in a fall.

1. The device must be transported and installed by at least 3-4 persons.
2. Always lift the device vertically using the openings provided.
3. Use a climbing aid for the chosen installation height.
4. Wear protective gloves and safety shoes when lifting and lowering the device.



NOTE

Power reduction due to heat accumulation!

If the recommended minimum clearances are not observed, the device may go into power regulation mode due to insufficient ventilation and the resulting heat build-up.

1. Observe minimum clearances and provide for sufficient heat dissipation.
2. All objects on the device housing must be removed during operation.
3. Ensure that no foreign bodies prevent heat dissipation following device installation.




Fig. 21: Lifting the housing




Fig. 22: Attaching the device to the PV shelter profile

Key

1	Opening	3	Screw with profile lock (not included in scope of supply)
2	Centre of gravity	4	Mount

Lifting and installing the device

↪ Mounting screws screwed in at the correct distance from the mounting surface.

1. Raise the device using the lower side recesses and support it on the head side. Observe the device's centre of gravity!

NOTE: Do not lift the device by the lid or cover!

2. Hook the device into the 4 fastening screws for the wall / mounting frame by way of the rear keyholes. Make sure that all screws are seated properly so that the back of the device is flush with the wall / mounting frame ([See figure 19 [▶ Page 20]]).

3. Insert the enclosed locking screw into the hole of the pedestal / carrying handle and secure it with the nut. ([See figure 19 [▶ Page 20]]).

4. Optional: Insert your own safety lock into the designated hole in the pedestal / carrying handle and lock it to prevent it from being lifted out. ([See figure 19 [▶ Page 20]]).

⇒ Device is installed. Proceed with the electrical installation.

CAUTION

Risk of damage to property as a result of condensation

If the device is pre-assembled, moisture can get into the internal area via the DC connectors and the dust-proof screw connections. The resulting condensate can cause damage to the device during installation and start-up.

✓ Keep the device closed during pre-assembly and do not open the connection area until you perform installation.

1. Seal off any plug-in connections and screw fittings using sealing covers.
2. Prior to installation, check the inner area for condensation and if necessary, allow it to dry sufficiently before installation.
3. Immediately remove any moisture from the housing.

7 Installation

7.1 General information

↪ Connection cables are available at the device.

1. Switch the DC isolator switches on the base plate from 1 (ON) to 0 (OFF).

DANGER! A measurement in a live state may be required for tests. Only appropriately qualified electricians authorised by the mains supply network operator are permitted to open and maintain the device.

DANGER! Observe all safety regulations for preventing contact with live parts.




Fig. 23: Setting the DC isolator switch to "OFF"

7.2 Opening the housing

↪ The device has been installed on the mount.

↪ Wipe any moisture off the frame of the housing cover using a cloth.

↪ Undo the 14 screws (2) and carefully remove the housing cover (1) [XT_30]

↪ Take care not to damage or soil the seals and fibre optics when setting down the housing cover.

⇒ Proceed with the installation of the device.




Fig. 24: Removing the housing cover

- 1 Housing cover
- 2 Fastening screws

7.3 Surveying the connection area

The connection point for the AC supply is situated inside the housing. The DC strings are plugged into the solar connectors on the base plate.




Fig. 25: Connection area M8 version




Fig. 26: Connection area M10 version

Key

1	AC connection point	4	AC overvoltage protection (plugged in)
2	DC connection point	5	AC earthing bolt
3	DC overvoltage protection (plugged in)		

7.4 Making the electrical connection



NOTE

Select the cable cross-section, fuse type and fuse value in accordance with the following master conditions

Country-specific installation standards; power rating of the device; cable length; type of cable installation; local temperatures.

7.4.1 Requirement for supply lines and fuse

AC-side	
Max. conductor cross-section	240 mm ² (AL or CU) ⁶
Min. cable cross-section	50 mm ² (AL or CU)
Cable diameter for cable fitting	16–28 mm
Length of insulation to be stripped off	Depending on the cable lug
Cable lug Ø connection bolt	Bore for M10 screw
Tightening torque	30 Nm
Connection type	Cable lug (use the appropriate cable lug depending on the cable material!)
Cable lug dimension w - maximum width	42 mm
Ground conductor connection	M10
Ground conductor connection tightening torque	10 Nm
Fuse protection for installation provided by customer (max output overcurrent protection)	500 A
Fitting for AC connection	M40
Torque for cable fitting	10 Nm
DC-side	
Max. conductor cross-section ⁷	6 mm ²
Min. cable cross-section ⁷	2.5 mm ²
Length of insulation to be stripped off	15 mm (see insert in scope of delivery)
Recommended cable type	in accordance with local installation standards
Connection type (brand and model for connector) ⁷	Adapter Phoenix/ PV-C3F-S 2,5-6 (+) 1100V/35A Adapter Phoenix/ PV-C3M-S 2,5-6 (-) 1100V/35A
Combiner box	yes
Interfaces	
Cable diameter for cable fitting	(2x) 8 - 17 mm
Torque for cable fitting	4 (M25) Nm
RS485 connection type	Screw connection or spring-type terminal
RS485 terminal cable cross-section	0.14 mm ² ... 1.5 mm ²
Cable diameter for cable fitting	(1) 8 - 17 mm
Torque for cable fitting	4 (M25) Nm
Ethernet cable cross-section	Standard Cat5 0,5-0,7 mm ²
Ethernet connection type	RJ45
PID connection type	defined by external solution (e.g. Padcon)

⁶ Option: 50 mm² with 2x5 AC cable. The optionally available input plate is required for this! [See section 4.4 ▶ Page 14]

⁷ The following Phoenix Contact connectors are also allowed to be used as an alternative to the DC solar connectors included in the scope of supply:

PV-C4F-S 6-16 (+) article no.: 1284634 (from 6 - 16 mm² cable)

PV-C4M-S 6-16 (-) article no.: 1284632 (from 6 - 16 mm² cable)

If these connectors are used in combination with a 16 mm² cable, a suitable current limitation must be ensured. The aforementioned connectors do not form part of the scope of supply and must be obtained by the customer.

7.5 Connecting the device to the power grid



⚠ WARNING

IP66 (IEC 60529) not guaranteed!

Ingress of condensation, dust or vermin can lead to short-circuiting/overheating or even failure of the device.

1. Tighten **all** cable/sealing plug/housing screw connections to the **specified torques**.
2. If cable glands are not used, the sealing plugs must be retained with the specified torques.

7.5.1 Preparing the grid connection

- ⌚ Connection cable with 5 wires (5 single cores or multi-core) up to a maximum cable cross-section 16 mm² - 42 mm² is available on the device.
- ⌚ Time required for AC connection: 30 min
- ⌚ The nominal grid voltage matches the "VAC nom" specification on the name plate.

1. For improved accessibility: Unfasten the AC input plate using the 6 screws [✂ T_30]

2. Unfasten the cable fitting for AC connection and PE earth (ground) [✂ W_46].

3. Remove sealing plug.

4. Insert the AC cables into the cable fittings.

5. Strip the insulation from the AC cables.

6. Strip the individual wires for L1 / L2 / L3 (ABC) and PE (Ground) (FRGM: neutral conductor (N)), so that the strands and insulation can be pressed into the cable lug sleeve.

CAUTION! Risk of fire due to chemical corrosion. Cable lugs must be suitable for the conductor material and copper busbars being used.⁸

7. Press on cable lug.

8. Slip a shrink-fit sheath (not part of the scope of supply) over the shaft of the ring cable lug of the AC cable.




Fig. 27: Removing the AC input plate

- 1 Housing base – AC-side
- 2 Screws for mounting
- 3 Input plate
- 4 Cable fitting












Fig. 28: Preparing the AC connection

- 1 Screw
- 2 Washer (2x)
- 3 Ring cable lug
- 4 Spring washer
- 5 Nut

⁸ When using aluminium cable lugs we recommend using cable lugs with galvanic tin plating or, alternatively, AL/CU cable lugs with suitable AL/CU washers. Otherwise, the aluminium may be destroyed by the copper busbars in the presence of electrolytes (e.g. condensate).

7.5.2 Making the grid connection

↻ **4/5-wire connection; TN and TT system** is prepared.

1. The grounding cable must be placed on the grounding point and secured with the provided screw, spring washer, and washer [ W_17 /  10 Nm].⁹
2. Place the cable lug of cores L1 / L2 / L3 / N on the busbar in accordance with the labeling and secure it with a bolt, nut, spring washer and washer (fastening elements in scope of supply) [ W_17 /  30 Nm].
- . **NOTE: In TN-C systems, only four conductors (L1, L2, L3, PE) are permitted. The N conductor remains unused, and bridging it with PE is prohibited.**
- . **NOTE: In a TN-C-S system, the neutral conductor may remain unused if L1, L2, L3, and PE are connected.**
- . **NOTE: In the FRGM variant, that measures the N conductor (e.g., in France), the N conductor must be connected. Therefore, this device is not suitable for use in TN-C systems.**
3. Optional: When using the double-row input plate (see accessories), the oppositely configured cable lug must be placed under the upper cable lug on the cores L1 / L2 / L3 / N according to the labeling on the busbar and fastened with a bolt, nut, spring washer and washer (fastening elements included in the scope of supply) [ W_17 /  30 Nm].
4. Check that all connected cables are securely seated.
5. Tighten AC cable fittings [ W_46 /  10 Nm].

⇒ The device is connected to the power supply network.




Fig. 29: AC mains connection 4/5-pole

- 1 L1 busbar
- 2 L2 busbar
- 3 L3 busbar
- 4 N busbar
- 5 PE earthing point

Residual current monitoring unit (RCMU):

The device is equipped with an AC/DC-sensitive residual current monitoring unit in accordance with IEC/EN 62109-2 and VDE 0126-1. The AC/DC-sensitive residual current monitoring unit monitors AC and DC residual currents and redundantly disconnects the device from the grid in the event of residual current jumps of > 30 mA. In the event of a malfunction in the residual current monitoring unit, all poles of the device are immediately disconnected from the public grid. The functionality of the integrated RCMU is described in the document 'RCMU functionality +device type' on our website. If local regulations require an external residual current circuit breaker (RCD), the recommendations in the document "Confirmation of compatibility with residual current circuit breakers (RCD)" on our website must be observed.



NOTE

Earthing recommendation

Observe the general earthing recommendation of the existing mains system.



NOTE

Selection of the residual current circuit breaker

If an external residual current circuit breaker is necessary due to the installation specification, a type A residual current circuit breaker must be used.

If a residual current circuit breaker B is used, the menu item "Compatibility with type B – RCD" must be enabled [See section 9.4.2 ▶ Page 51] This can affect the efficiency somewhat.

If one of these types is used, it must have a protective rating of at least 1250 mA.

For questions regarding the appropriate type, please contact the installer or our KACO new energy customer service.

7.6 Connecting the PV generator to the device

The DC connection is intended exclusively for PV generators. Other sources fall within the scope of improper operation (e.g. batteries).

⁹ If the connection is made in a TN-C grid, connect the PEN grounding cable to the ground earthing point.

7.6.1 Checking the PV generator for a ground fault



! DANGER

Risk of fatal injury due to electric shock!

Severe injury or death will result if the live connections are touched. When there is solar radiation on the PV generator, DC voltage will be present at the open ends of the DC cables.

1. Only touch the PV generator cables on the insulation. Do not touch the exposed ends of the cables.
2. Avoid short circuits.
3. Do not connect any strings with a ground fault to the device.
4. The device must not be operated with negatively or positively earthed PV modules.

Ensuring that there is no ground fault

1. Measure the DC voltage between the earth potential (PE) and the positive cable of the DC source.

2. Measure the DC voltage between the protective earth (PE) and the negative cable of the DC source.

⇒ If stable voltages can be measured, there is a ground fault in the DC generator or its wiring. The ratio between the measured voltages gives an indication as to the location of this fault.

3. Rectify any faults before taking further measurements.

4. Measure the electrical resistance between the protective earth (PE) and the positive cable of the DC source.

5. Measure the electrical resistance between the protective earth (PE) and the negative cable of the DC source.

⇒ In addition, ensure that the DC source has a total insulation resistance of more than 2.0 MOhm, since the device will not feed in if the insulation resistance is too low.

6. Rectify any faults before connecting the DC generator.

7.6.2 Configuring the PV generator

! CAUTION

Damage to components due to faulty configuration

In the expected temperature range of the PV generator the values for the no-load-voltage and the short circuit current must never exceed the values for U_{DCMAX} and I_{SCMAX} in accordance with the technical data.

1. Observe limit values in accordance with the technical data.



NOTE

Dimensioning the PV generator

The device is designed with a reserve of DC short-circuit current resistance. This allows for oversizing of the connected PV generator. The absolute limit for the PV generator is the value of the max. short-circuit current (I_{SCmax}) and the max. no-load voltage (U_{DCmax}). See footnote under [See section 4.1 ▶ Page 12]

7.6.3 Recommended standard connection



! DANGER

Risk of fatal injury due to electric shock (electric arc)!

Incorrect assignment of MPP trackers will seriously damage the device. Touching the live connections will result in severe injury or death!

1. Make sure that each MPP tracker can be disconnected from all poles.
2. Before connecting to the device, it is essential to measure the current of all DC plug connections used.
3. A PV string is only allowed to be connected to a single device. Connecting a PV string to several devices can lead to irreparable damage.
4. Observe recommended standard connection.



WARNING

An incongruent configuration of the DC inputs and the associated menu setting can lead to irreparable damage to the device

This device can be operated with either 10 / 8 or 5 / 4 MPP trackers.

Two neighbouring DC inputs must be electrically connected via a Y cable for operation with the reduced number of MPP trackers. [See figure 33 [▶ Page 29] & [See figure 34 [▶ Page 29]

At the same time, the setting „in parallel in pairs“ must be selected in the inverter menu.

However, if each input is wired individually, the „All DC inputs separate“ option must be activated. See table : Configuration via web user interface [▶ Page 69]

If the wiring and menu settings do not match, there is a risk of irreparable damage to the device due to overloading or incorrect current routing.



WARNING

Device damage due to bridged PV string connection to an MPP tracker.

Unused MPP trackers can build up a voltage of 200 V, which is displayed on the web interface.

1. Distribute all PV strings as evenly as possible across the device.
2. PV strings must be connected individually and selected and activated in the "DC Configuration" menu item. An improperly configured DC input leads to device damage.
3. Two strings on one MPP tracker must have the same voltage. ($U_{n1-nx} = U_{n2-nx} / U_{n3-nx} = U_{n4-nx}$)
4. The voltage at the MPP trackers can be different. They are supplied by separate, independently operating MPP trackers (MPP Tracker 1 / 2).
5. In the following illustrations, two MPP trackers (1 / 2) have been occupied by PV strings by way of example. Naturally, this configuration can be transferred to the other MPP trackers (3 / 4; 5 / 6; 7 / 8; 9 / 10) identically.

– Menu item: All DC inputs separated




Fig. 30: Connection variant: 2 strings each on one MPP tracker

Limitation

Up to 20 A at the DC connector

Tab. 3: Electrical data of the installation




Fig. 31: Connection variant: high-current module string >20 A with Y-cable on one MPP tracker

Limitation / Required accessories
From 20 A per string on the Y-cable
Min. 2 Y-cables (one PV+ and one PV- each) for one high-current module string
CAUTION! Depending on the selected PV modules, string fuses may be required. Observe the module manufacturer's information.

Tab. 4: Electrical data of the installation




Fig. 32: Connection variant: 1 string each on one MPP tracker

Limitation / Required accessories
Up to 20 A at the DC connector and MPP tracker

Tab. 5: Electrical data of the installation




Fig. 33: Connection variant: 2 strings each via Y-cable and 1 string directly to an MPP tracker

Limitation / Required accessories
Max. 10 A per string on the Y-cable
Min. 2 Y-cables (one PV+ and one PV- each) for one string
CAUTION! Depending on the selected PV modules, string fuses may be required. Observe the module manufacturer's information.

Tab. 6: Electrical data of the installation




Fig. 34: Connection variant: 2 strings each via Y-cable on one MPP tracker

Limitation / Required accessories
Max. 7.5 A per string on the Y-cable
Min. 4 Y-cables (two PV+/PV- each) for two strings
CAUTION! Depending on the chosen PV modules, string fuses may be required.

Tab. 7: Electrical data of the installation

- Menu item: All DC inputs pairwise parallel



WARNING

Damage to the device due to overloaded DC plug connectors

In DC parallel operation, the internal cabling is not designed to carry a current of over 20 A per DC plug connector.

1. Each DC plug connector must not exceed a current of 20 A. Exceeding this limit can lead to serious damage to the device.
2. In the following illustration, Y-cables have been used to interconnect 2 trackers. This configuration must be transferred to all other trackers (3 / 4; 5 / 6; 7 / 8; 9 / 10) when used.




Fig. 35: Connection diagram: 1 string parallel across 2 MPP trackers and each string separately on one MPP tracker.

Limitation / Required accessories
Max. 20 A at the Y-connector (n_3) 20 A at the DC connector (MPP tracker 1/ n_1 & MPP-Tracker 2/ n_2) (max. 30 A per MPP tracker)
10x (8x) Y-cables (1x PV-/PV+)

Tab. 8: Electrical data of the installation

7.6.4 Configuring the DC plug connector




Fig. 36: Insert wires




Fig. 37: Slide insert into sleeve




Fig. 38: Check fastening

Key			
1	Wire for DC connection	5	Cable fitting
2	Spring	6	Contact plug
3	Insert	7	Coupling
4	Sleeve		

↻ Connection area opened.



↻ **NOTE: Before proceeding with the isolation ensure that you do not cut any individual wires.**

1. Insert isolated wires with twisted ends carefully up to the end stop.

NOTE: Wire ends must be visible in the spring.

2. Close the spring so that the spring latches.

3. Slide insert into sleeve.

4. Secure and tighten the cover on the cable fitting [W_15/ 2 Nm]

5. Join insert with contact plug.

6. Check latch by lightly pulling on the coupling.

⇒ Make the electrical connections.



NOTE

The permissible bending radius of at least 4x the cable diameter should be observed during installation

Excessive bending force may negatively impact the protection rating.

1. All mechanical loads must be absorbed in front of the plug connection.
2. Rigid adaptations are not permitted on DC plug connectors.

7.6.5 Connecting the PV generator



DANGER

Risk of fatal injury due to electric shock!

Severe injury or death will result if the live connections are touched. When there is solar radiation on the PV generator, DC voltage will be present at the open ends of the DC cables.

1. Only touch the PV generator cables on the insulation. Do not touch the exposed ends of the cables.
2. Avoid short circuits.
3. Do not connect any strings with a ground fault to the device.
4. The device must not be operated with negatively or positively earthed PV modules.

CAUTION

Damage to the PV generator in case of faulty configuration of the DC connector.

A faulty configuration of the DC connector (polarity +/-) causes equipment damage in the DC connection if it is connected permanently.

1. Please check polarity (+/-) of the DC connector before connecting the DC generator.
2. Before using the solar modules, check the vendor's calculated voltage values against those actually measured. The DC voltage of the PV system must not exceed the maximum no-load voltage at any time.



NOTE

Type and configuration of the PV modules

Connected PV modules must be dimensioned for the DC system voltage in accordance with IEC 61730 Class A, but at least for the value of the AC grid voltage

Connecting the DC cable

↪ PV generator is dimensioned according to the performance characteristics of the device.

1. Remove protective cap from the DC connection plugs required.

NOTE: For each plug connector pair, the power output can be connected in relation to the string fuse size used.

2. Connect the PV generator to the DC plug connectors on the underside of the device according to the polarity of the PV generator.

NOTE: Meet the requirements of protection class IP66 by closing the unused plug connectors with protective caps.

⇒ The device is connected to the PV generator.




Fig. 39: Connection to plug connector

1 DC- plug connector

2 DC+ closure

3 DC- closure

4 DC+ plug connector

7.7 Establishing equipotential bonding



NOTE


Use of the housing earthing

Depending on the local installation specifications, it may be necessary to earth the device with a second earthing connection. To this end, the threaded bolt on the underside of the device can be used.

↪ The device has been installed on the mount.

1. Strip the insulation from the equipotential bonding cable.

2. Furnish the stripped cable with an M8 ring cable lug.

3. Lay the cable for equipotential bonding onto the grounding point and attach with an additional M10 screw and lock washer [XW_15/  15 Nm].

4. Check that the connected cable is fitted securely.

⇒ The housing is included in the equipotential bonding.




Fig. 40: Additional earthing point

1 Earthing bolt

7.8 Connecting the interfaces

7.8.1 Overview



⚠ DANGER

Risk of fatal injury due to electric shock!

Severe injuries or death may result from improper use of the interface connections and failure to observe protection class III.

1. The SELV circuits (SELV: safety extra low voltage) can only be connected to other SELV circuits with protection class III.

⚠ CAUTION

Damage to the device from electrostatic discharge

Components inside the device can be damaged beyond repair by static discharge.

1. Observe the ESD protective measures.
2. Earth yourself before touching a component by touching a grounded object.

All interfaces are located on the communication circuit board (HMI board) inside the housing.




Fig. 41: Communication circuit board (HMI board)

- | | |
|--|---|
| 1 Communication circuit board | 5 Ethernet for network connection DHCP |
| 2 RS485 – standard (Daisy Chain) | 6 Ethernet – only for starting up by means of static IP ([See section 8.4.2▶ Page 40]) |
| 3 DIP switch - activate terminator | 7 USB socket |
| 4 INV OFF - connection for external grid protection component - 24 V(+/- 20%) / 1 A (at least 15 mA) | 8 ERR – fault signal relay |



WARNING

IP66 (IEC 60529) not guaranteed!

Ingress of condensation, dust or vermin can lead to short-circuiting/overheating or even failure of the device.

1. Tighten **all** cable/sealing plug/housing screw connections to the **specified torques**.
2. If cable glands are not used, the sealing plugs must be retained with the specified torques.

7.8.2 Inserting and laying the cables



DANGER

Risk of fatal injury due to electric shock!

Touching damaged insulation on the grid and battery connection leads results in severe injury or death.

1. Check the connection leads for damage.
2. All signal cables for interfaces must be correctly encased up to the connection using the insulation tube provided before fitting the cable.

1. Observe the instructions on the recommended cable for the interface used.
2. Unfasten the cover on the cable fitting [XW_20].
3. Feed the signal cable into the connection area.

⇒ Signal cable inserted.

Inserting the Ethernet cable

1. Unfasten and remove the cover on the cable fitting [XW_29].
2. Remove the sealing insert.
3. Pass the connection cable through the cover of the cable fitting and the sealing insert.
4. Insert the sealing insert into the cable fitting.
5. Feed the connection cables into the connection area.

⇒ Ethernet cable inserted.




Fig. 42: Inserting the interface cable

- 1 Cable fitting (3x)
- 2 USB socket

7.8.3 Making the Ethernet connection



NOTE

Feed-in of the communication line

The connection plug of an RJ45 cable is larger than the opening of an M25 cable fitting when it is installed. For this reason, remove the sealing insert before installation and thread the Ethernet cable outside of the cable fitting through the sealing insert.



NOTE

Note the type of network cable

Use a suitable network cable of at least category 5. The maximum distance between two devices is 100 m (328 ft). The Ethernet switch allows for the repeater function and supports auto-sensing. Ensure that the cable is correctly assigned. You can use both crossed and 1:1 protectively-wired Ethernet connection cables.

↪ Connecting cable inside the device.

1. Plug in an Ethernet cable at one of the two Ethernet ports on the communication circuit board.

2. Check that the connecting cable is fitted securely.

⇒ Connect additional signal cables.

Connecting the device to the network

↪ Ethernet cable connected to the device.

1. Connect the Ethernet cable to the network or a computer.

2. Configure the Ethernet settings and the web server in the Settings menu.

7.8.4 Connecting the RS485 bus



NOTE

Observe line polarity

Ensure that the DATA+ and DATA- wires are properly connected. Communication is not possible if the wires are reversed. Different manufacturers do not always interpret the standard on which the RS485 protocol is based in the same way. Note that the wire designations (DATA+ and DATA-) for wires A and B may vary from one manufacturer to another.




Fig. 43: RS485 interface wiring diagram

1 Inverter, terminal unit

4 Communication

2 Inverter

5 Power supply

3 Data monitoring unit

Properties of the RS485 data line




Maximum length of the RS485 bus line

Max. 1200 m

Properties of the RS485 data line	
	This length can be reached only under optimum conditions. Cable lengths exceeding 500m generally require a repeater or a hub.
Maximum number of connected bus devices	99 devices + 1 data monitoring unit
Data line	Twisted, shielded.
Recommendation	Li2YCYv (twisted pair) black for laying cable outside and in the ground, 2 x 2 x 0.5 mm ² Li2YCY (twisted pair) grey for dry and damp indoor spaces, 2 x 2 x 0.5 mm ²

RS485 Smart Meter compatibility list

- ⌚ To avoid interference during data transmission:
 - Observe the connection of DATA+ and DATA- wire pairing.
 - Do not lay the RS485 bus cable close to the live DC/AC cables.

1. Loosen the cable fitting [W_20]
 2. Thread the connection cables through the cable fitting.
 3. Connect the connection cables to the corresponding connection terminals.
 4. Connect to all inverters and the data monitor device in this way:
 - Wire A (-) to wire A (-) and wire B (+) to wire B (+)
 - GND to GND.
 5. Tighten cable fittings [W_20 / 1,5 Nm].
- WARNING! Ensure IP66 protection! See warning message in** [See section 7.5 ▶ Page 24]




Fig. 44: Assignment of twisted-pair wires




NOTE

Configuration of the RS485 bus devices

When using the RS485 bus system, assign a unique address to every bus device (inverter, sensor) and terminate the terminal units (see the "Settings" menu) .

- ⌚ Check whether one of the devices represents the terminal unit.

 Only activate the terminating resistor on the communication circuit board of the terminal unit using the DIP switch.

- ⇒ RS485 connection made. Lay signal cable correctly.




7.8.5 Connecting the fault signal relay

In addition to the option of connecting a warning lamp, external grid protection devices can also be controlled here.

Maximum contact load	
DC	30 V / 1A
AC	250 V / 1A

The contact is designed as an N/O contact and is labelled "ERR" on the circuit board. [See section 7.8.1 ▶ Page 32]

- ⌚ Connection area cover open.

1. Loosen the cable fitting to pass the signal cable through [W_20]
 2. Thread the connection cables through the cable fitting.
 3. Attach the connection cables to the terminals. [See section 7.8.1 ▶ Page 32]
 4. Tighten cable fitting [W_20 / 1,5 Nm].
- WARNING! Ensure IP66 protection! See warning message in** [See section 7.5 ▶ Page 24]

7.8.6 Connecting external grid protection components



NOTE

The digital input of the device is intended for connection of external grid protection components.

1. Please note the corresponding application note under Downloads and Videos in the category PV accessories – powador-protect.
2. When using devices from other manufacturers or in combination with KACO inverters, interface switches as a minimum must be used for shutting down devices from other manufacturers.

Connect Powador-protect



NOTE

This product has been removed from the regular sales range and is no longer available through the usual sales channels.

1. This product can only be purchased through our customer service. Alternatively, a third-party device can be used.
2. Product is only suitable for 380/400 V and blueplanet 87.0TL3 / 92.0TL3 / 105TL3 / 100 NX3 / 125 NX3.

Connecting the external device




NOTE

For the connection of 3rd party devices, a continuous voltage of max. 24 V (+/-20%) with at least 15 mA must be present for the "INV-OFF" connection.

NOTE: When an external device is used, a separate power supply is also required for this purpose. Some external devices only have a normally closed contact and do not supply any voltage.

- ⌚ The cable to the external grid protection device is available on the device.
- ⌚ An external power supply is available at the grid protection device.
- ⌚ Cover of the device has been opened.

1. Undo the cable fittings [**XW_20**]
2. Pass the connection cable through the cable fittings.
3. Connect the corresponding output of the external N/A protection to "INV_OFF+", follow the operating instructions for the external device.
4. Connect the corresponding output of the external N/A protection to "INV_OFF"-, follow the operating instructions for the external device.
5. Connect the other devices to one another as follows:
 - wire A (+) to wire A (+) and wire B (-) to wire B (-).
6. Tighten cable fitting [**XW_20** /  1,5 Nm].
7. After commissioning: Configure the external device Overvoltage protection in the menu entry Properties / functions.





Fig. 45: Connecting the device to the external grid protection device

7.9 Sealing the connection area

- ⌚ Grid connection is prepared.

1. Lift the housing cover onto the housing and loosely tighten the fastening screws.
2. Secure the housing cover (1) by tightening all 14 screws (2) in a diagonally opposite sequence [**XT_25** /  4 Nm

- ⇒ The device has been mounted and installed.
- ⇒ Put the device into operation.




Fig. 46: Closing the housing cover

- 1 Housing cover
- 2 Fastening screws

8 Commissioning

8.1 Requirements



⚠ DANGER

Lethal voltages are still present in the connections and cables of the device even after the device has been switched off and disconnected!

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched.

1. The device is only permitted to be commissioned by a qualified professional.
2. Unauthorised persons must be kept away from the device.

- ⌚ The device has been mounted and electrically installed.
- ⌚ The PV generator supplies a voltage above the configured start voltage.

1. Connect the grid voltage using the external circuit breakers.
2. Connect the PV generator using the DC isolator switch (0 > 1)

- ⇒ The device begins operation.
- ⇒ During initial start-up: Follow the instructions of the New Connection Wizard.



NOTE

Wi-Fi-enabled device required

A mobile terminal device with Wi-Fi interface is required in order to put the device into operation

The following functions are only available via the WEB interface:

1. Initial start-up
2. Setting parameters
3. Reset to factory defaults.



NOTE

Use of a suitable web browser

We recommend using an up-to-date Firefox or Chrome browser or the default browser that is available on the mobile terminal devices to configure the device via the web interface.



⚠ DANGER

Risk of fatal injury due to electric shock!

Severe injury or death will result if the live connections are touched. When there is solar radiation on the PV generator, DC voltage will be present at the open ends of the DC cables.

1. Only touch the PV generator cables on the insulation. Do not touch the exposed ends of the cables.
2. Avoid short circuits.
3. Do not connect any strings with a ground fault to the device.
4. The device must not be operated with negatively or positively earthed PV modules.

8.2 Preconditions relating to standards

Attachment of safety label in accordance with UTE C15-712-1

The code of practice UTE C15-712-1 requires that, upon connection to the French low-voltage distribution network, a safety sticker showing a warning to isolate both power sources when working on the device must be attached to each device.

- 📎 Attach the provided safety sticker to the outside of the device housing where it is clearly visible.




Fig. 47: Adhesive label UTE_C15-712-1

8.3 Network topologies

Plant segmentation




Fig. 48: Plant segmentation

- | | |
|--|---|
| 1 Gateway VPN 3G/4G Router | 6 Network Segment Switch |
| 2 Main network switch | 7 Wechselrichter |
| 3 FO – Switch (Fiber Optic) | 8 Connection cable and protocol
-DC / Modbus RTU / RS485 |
| 4 Slicebox (for Fiber Optic Data transfer) | 9 Plant Controller |
| 5 Segment Controller | |

While a gateway to the Internet, a data logger and an instance for higher-level power control are usually sufficient for smaller systems, larger systems must be divided into separate network segments, as there are certain upper limits regarding the number of nodes that can be managed for monitoring/control.

This illustration shows a possible variant for multiple segments. Depending on the local conditions, a different positioning of the components may also be preferable (e.g. position segment controller at a central location and connect in the segment via glass fibre cable).

Located directly after the Gateway VPN-Router, is the main network switch via which the segment controller is connected in. With the corresponding system size (distance from main network switch to the segment controller >100 m), it may also be necessary to connect in segments that are further away via a glass fibre connection.

Within a segment, it is possible to link KACO devices to one another as part of an Ethernet daisy-chain by way of an integrated switch, whereby the Segment Controller is connected at the first element in the chain. For this purposes of an example, this topology is shown in segment 2. A Segment Controller can manage up to 100 nodes. A node in this sense is any data source that is monitored by the Segment Controller.

If additional failure safety is desirable, the KACO devices can also be arranged in a ring via a correspondingly configured Network Segment Switch (that supports the Rapid Spanning Tree Protocol "RSTP"). This switch is then also coupled to the Segment Controller. This configuration is shown as an example in segments 1 and M.

8.4 Start-up options

- | | |
|---|--|
| Option 1:
Locally managed start-up via Wi-Fi | – Installation technician connects to a KACO inverter via Wi-Fi. |
|---|--|

	<ul style="list-style-type: none"> – Installation wizard carries out start-up steps interactively.
Option 2: Locally managed LAN connection	<ul style="list-style-type: none"> – Installation technician connects to a KACO inverter via LAN. – Installation wizard carries out start-up steps interactively.
Option 3: Local start-up with pre-arranged configuration	<ul style="list-style-type: none"> – Installation technician uses a USB memory stick that contains a pre-prepared device configuration. – The device imports these settings and is then ready for operation.
Option 4: Start-up in a network without Segment Controller	<ul style="list-style-type: none"> – Start-up in an existing network. – The installation technician can start up the device with the aid of the installation wizard as described at option 1. The device can be addressed using its host name.
Option 5: Centralised start-up via Segment Controller	<ul style="list-style-type: none"> – A device configuration that is available on the Segment Controller can be uploaded to several KACO inverters. – The devices are ready for operation once the configuration is activated.

Tab. 9: Start-up variants for individual devices or system segments

8.4.1 Start-up via Wi-Fi

To start up the device directly, the first option is to carry out the installation interactively with a Wi-Fi-compatible adapter approved by KACO. If such an adapter is not available, the other option is to perform an automatic configuration using a USB memory stick.




Fig. 49: Start-up via WIFI

Application

The planned network infrastructure or AC-coupling is not yet in place or has not been completed. A DC supply to the KACO device is sufficient for start-up.

Required components

- Wi-Fi-compatible notebook, tablet or smartphone (Android or iOS devices can be used).
- USB Wi-Fi stick (KACO accessory, type: WLAN adapter Digitus 150 N micro article no.: 3016362)

Establishing a connection to the KACO device via Wi-Fi

☞ Connect the USB Wi-Fi stick to the device and connect to the access point generated by the device using a notebook or mobile device. The Wi-Fi SSID corresponds to the serial number of the device, which is printed on the nameplate.

☞ Name of access point: <serial number> (e. g. „125NX3<123456789>“ or „100NX3<123456789>“)

1. Password: kacowifi

2. Launch the browser on the terminal device and enter server name a) or server address b):

☞ [http:// 192.168.1.1](http://192.168.1.1)

☞ Confirm input.

⇒ The device configuration page is displayed.

1. At the Login/register icon, log in as:

2. User name: user/Installer

3. Password: (assigned in step 1 [See section 9.1 ▶ Page 44])

4. Confirm authorisation via Anmelden.



Fig. 50: Login screen

8.4.2 Start-up via LAN connection

The following figure provides an example of the structure of a KACO device and directly connected mobile devices via Ethernet.




Fig. 51: Start-up via LAN connection

Application

The planned network infrastructure or AC-coupling is not yet in place or has not been completed.

A DC supply to the KACO device is sufficient for start-up.

Required components

- Notebook with Ethernet interface
- Ethernet cable (uncrossed patch cable)

Establishing a connection to the KACO device

1. The device must be opened in order to connect the Ethernet cable! For safety reasons, KACO therefore recommends connection via Wi-Fi.

2. The device has 3 Ethernet ports on the communication board that can be used:

- The 2 neighbouring shielded Ethernet ports are labelled LAN1 and LAN2. These ports have an internal switch and, in their factory default state, they expect to receive an IP address from a DHCP server. Consequently, these can only be used if the connected PC provides a DHCP service.
- The port labelled CON700, via which the device can be addressed with the static IP address 169.254.1.1. If you have chosen a wired solution, this option should be preferred.

1. On the terminal device, launch the browser and enter the IP address of the device:

2. <http://<Device IP address>> (if LAN1 or LAN2 ports were used)

3. <http://169.254.1.1> (if the port labelled CON700 was used)

⇒ Device configuration page is displayed.

8.4.3 Start-up via a USB memory stick

Application

The installation technician has saved a pre-prepared device configuration on a USB memory stick (e.g. a configuration that he has uploaded during the guided installation of a device or one that has been given to him by a third party).

Required components

- USB memory stick with pre-prepared start-up configuration file.

Procedure

1. Connect the USB memory stick to the USB slot on the underside of the device.

- ⇒ The device checks the saved configuration and emits a flash code via the LEDs on the front of the device which allows conclusions to be drawn about the validity of the configuration ([See section 9.2 ▶ Page 45]).

2. If the configuration is valid, the parameters are transferred.

- ⇒ Once the parameters have been adopted and the device has been restarted, the device is put into operation.

8.4.4 Starting up a network

The following illustration provides an example of the structure of a KACO device and an external network connection.




Fig. 52: Start-up via a network without Segment Controller

Application

If the device is to be integrated into an existing network, then the configuration shown in the figure should be used. It is immaterial whether port LAN1 or LAN2 is used.

Required components

- A notebook that is logged into the external network.
- Ethernet cable (uncrossed patch cable)

The device can also be operated without an external Segment Controller or data logger. In this case however, the internal logging options are limited and log data are only available for a certain period of time.

Establishing a connection to the KACO device

1. The device must be opened in order to connect the Ethernet cable! The device has 3 Ethernet ports that can be used. These are located on the printed-circuit board marked LBL1100. In this application only one of the 2 neighbouring shielded Ethernet ports (marked LAN1 and LAN2) should be used. These ports have an internal switch and, in their factory default state, they expect to receive an IP address from a DHCP server.
2. Use a functioning Ethernet slot on the external network end.
3. It may be necessary to take additional IT configuration measures in the external network so that the device is assigned an IP address.
4. Next, launch the browser on the terminal device and enter the IP address of the device:
 - ⇒ `http://<IP address of the device>`
 - ⇒ The IP address can either be requested from the network administrator or determined using an IP scanner tool.
5. Alternatively, it is possible to address the device using its host name. The host name corresponds to the serial number, e.g.:
 1. `http://125NX01234567` or `http://100NX1234567`
 2. If this is unsuccessful, please use the full domain name:
`http://125NX01234567<ExternalNetworkDomainName>` or `http://100NX01234567<ExternalNetworkDomainName>`

8.4.5 Starting up a plant segment



NOTE

Disturbances when used with network address 169.254.1.1

The above address must not be used in the system configuration, otherwise the gateway may have the same IP address as the WIFI stick. This will inevitably cause the device to malfunction.

1. Make sure that the address has a higher address range as shown above.

The following figure provides an example of the structure of a system segment consisting of a segment controller and a certain number of KACO units.




Fig. 53: Commissioning via segment controller

Application

The network infrastructure already exists. All of the KACO devices in the segment can be reached via Ethernet using a Segment Controller.

NOTE: When multiple Segment Controllers are present, keep in mind that the Segment Controllers must not be connected to one another via the network during start-up.¹⁰

Once start-up is complete (assignment of devices to the individual Segment Controllers), these can be connected to the network by pressing a *Main network switch*.

Required components

- Notebook with Ethernet interface and pre-prepared start-up configuration file
- Segment Controller

¹⁰ Note: Otherwise all inverters would be visible for the respective Segment Controller.

Procedure

1. Connect the notebook to the Segment Controller via Ethernet (or to a switch that provides access to the Segment Controller).
2. Upload a pre-prepared device configuration (e.g. a device configuration that has been set up successfully on a single device).
3. Using the Segment Controller's WEB server, it is then possible to display and select all of the connected devices on the Segment Controller that should have this configuration.
4. Once the configuration has been uploaded to the respective devices, they will go into operation automatically following a restart.

9 Configuration and operation

9.1 Initial start-up



NOTE

Ensure DC power supply during initial start-up

The DC power supply must be guaranteed during initial start-up.¹¹

The sequence of the settings required for initial start-up is pre-set in the configuration assistant.

During initial start-up, the installation wizard is called up directly (if the device is still in the delivery state and start-up has not yet been carried out).

The installation wizard can still be relaunched at a later stage to make further changes to the original configuration.

The installation process currently consists of multiple steps which are outlined below.

step: Authorisation

↻ The installation wizard has been started or re-started.

1. Enter `password*` as user of the system and confirm correctness.
2. Enter `password*` for installer of the system and confirm correctness.
3. Confirm the action field.

⇒ The `Forward` button jumps to the next installation step.

*) The password must be at least 8 characters long and must contain characters from at least three of the following four categories: Upper case letters, lower case letters, numbers, special characters.

It is recommended for passwords to be changed regularly.

step: Language selection

↻ Access to the wizard has been granted.

1. Select `Menu language` via the dropdown menu.
2. Confirm the action field.

⇒ The `Forward` button jumps to the next installation step.

step: Country configuration

↻ A language has been selected.

1. Select `Country` and `Grid type` from the dropdown menu.
2. Confirm the action field.

⇒ The `Forward` button jumps to the next installation step.

step: Power limitation

↻ The country and grid type have been selected.

NOTE: The permanent power limitation of the maximum active and apparent power for generation plants is agreed between the grid operator and the plant operator.

1. Activate `power limitation` if required
2. Set `maximum apparent power` and `maximum active power`.
3. Activate `password protection` if required.
4. Confirm the action field.

⇒ The `Forward` button jumps to the next installation step.



Fig. 54: Menu item: Configuration via web user interface




Fig. 55: Menu item: Configuration via web user interface




Fig. 56: Menu item: Configuration via web user interface




Fig. 57: Menu item: Configuration via web user interface

¹¹ It is only possible to configure the grid parameters with DC voltage. The further parameters can also be configured with a present AC voltage.

step: Grid parameters

↪ The country and grid type have been selected.

- . **NOTE: By default, IP addresses are assigned via the plant DHCP server.**
- . **NOTE: If static IP addresses are required, you will have to assign these.**
- . **CAUTION! In this case, it is no longer possible to distribute the configuration via the Segment Controller as this would then be part of the configuration and ultimately all inverters in the same segment would be assigned the same IP address.**

1. Activate DHCP or enter the IP address at the deactivated DHCP.
2. Confirm the action field.

⇒ The Forward button jumps to the next installation step.

step: Localisation

↪ Grid parameters have been set.

1. Set Date, time and time zone or initiate synchronisation with the client.
2. **NOTE: An NTP server needs to be activated for synchronization purposes** ¹²
3. Select temperature unit from the dropdown menu.
4. Confirm the action field.

⇒ The Forward button jumps to the next installation step.

step: ModBus

↪ Portal configuration completed.

- . **NOTE: The device supports MODBUS/TCP and conventional SUNSPEC models. If there are concerns over security, write access can be deactivated.**

1. Specify the Modbus port and determine Read/write access.
2. Confirm the action field.

⇒ The Forward button jumps to the next installation step.

step: Optional parameters

↪ Modbus has been specified.

- . **NOTE: Using the plant ID, the device followed by its firmware version can be detected automatically in the Cloud/portal and assigned to the relevant plant.**

1. Enter the device name used to reach the device in the network.
- . **NOTE: The coordinates identify the device installation location.**
2. Confirm the action field.

⇒ The Forward button jumps to the next installation step.

step: Finalisation

↪ Optional parameters have been set.

1. Generate installation report (includes a list of all relevant parameters for acceptance purposes)
2. Specify a name for the device installation report.
3. Confirm the action field.

NOTE: All of the settings can also be transferred to another device in the same series (provided that no individual parameters are required, e.g. static IP address).

1. Optional: Export current device settings to the client.
2. Device configuration completed successfully. Please click "Finish" to put the device into operation.

⇒ The initial installation is now complete. Set access to device(s) and "connect network" via the user area AC.

9.2 Signal elements

The 3 LEDs on the device control panel show the different operating states. The LEDs can display the following states:

¹² It is preferable to install this on a plant component. It is also possible to select an NTP server localized on the internet provided the device has direct access to the internet.



Fig. 58: Menu item: Configuration via web user interface



Fig. 59: Menu item: Configuration via web user interface




Fig. 60: Menu item: Configuration via web user interface



Fig. 61: Menu item: Only on the installation wizard!

















































Fig. 62: Menu item: Only on the installation wizard!

Operating status	LED status	Description
	 LED illuminated  LED flashing  LED not illuminated	
	  	
Start	  	The green „Operating“ lights up when AC and DC voltage is present and the web server is accessible at the same time. If the LED flashes, the web server is not yet accessible. This process may take several minutes. After flashing, the device is ready for power supply. If the LED continues to flash for more than 10 minutes, internal communication is disrupted.
Feed-in start	  	The green „Operating“ LED is lit. The green „Feed-in“ LED is illuminated after the country-specific waiting period*. The device feeds into the grid. You can hear the circuit-breaker / interface switch switch on. NOTE: Both LEDs are also illuminated in Q on Demand operation mode.
Feed-in mode with reduced power	  	The green „Operating“ LED is illuminated. The green LED „Feed“ is flashing because one of the modes: internal power reduction, external power reduction, external reactive power request or standalone mode is active. The device feeds into the grid. You can hear the circuit-breaker / interface switch switch on.
Non-grid feed mode	  	The green LED „Operating“ LED is lit.
Fault	  	None of the LEDs is illuminated or the red „Fault“ LED is illuminated. Fault in the AC/DC source Conditional special cases: <ul style="list-style-type: none"> – There is no DC voltage present (e.g. DC isolator switch open) (e.g. DC isolator switch open) – DC voltage too low (<starting voltage) DC voltage is present (>starting voltage), but communications connection between the front end (operating unit) and back end (control unit) is faulty, or interrupted.

The 3 LEDs also signal the **firmware update process** when a USB stick is inserted. The LEDs can assume other states for this purpose:

Operating status	LED status	Description
	 LED flashes rapidly  LED flashes slowly  LED flashes alternating	
	  	
Procedure in progress	  	The green "Operating" LED is illuminated when the device is ready for use. Note: When updating via the web server and a USB stick is inserted in parallel, the device remains inactive until the USB stick is removed or then performs a reset and restarts.

Operating status	LED status	Description
Procedure has commenced (initialisation).	  	The green "Operating" LED and the green "Feed-in" LED are flashing quickly yet alternately . Note: The procedure will last up to 5 min for firmware updates or up to 30 secs for parameter updates.
Process is initiated (update)	  	The green "Operating" LED and the green "Feed-in" LED are flashing quickly .
Procedure completed successfully.	  	The green "Operation" and "Feed-in" LEDs and the red "Fault" LED light up briefly several times. Note: Check the new SW version via the web interface .
Fault	  	The red "Fault" LED is flashing slowly . Note: The procedure has not been completed successfully or a time limit has elapsed. Important: If the USB stick is removed during the initialisation phase, a device fault is triggered. Inserting the USB stick initiates a device re-start.
No fault	  	No fault present.

9.3 User interface



NOTE

Tolerances of displayed measured values

Depending on the tolerances of the measuring elements, the measured and displayed values are not always the actual values. However, the measuring elements ensure maximum solar yield. Due to these tolerances, the daily yields shown on the display/monitor may deviate from the values on the grid operator's feed-in meter by up to 15%.




Fig. 63: Monitoring interface

Area	Description
Basic layout – 1st tab	Displays the current reactive power factor Displays the current output
Basic layout – 2nd tab	Displays AC and DC voltages
Basic layout – 3rd tab	Current measurement values with export function

Tab. 10: Description of the areas




Fig. 64: Interface for evaluating the yields

Area	Description
Selection area	Filtering options for daily and annual values
Visual representation	Graphical bar chart
Key	Meaning of colour coding

Tab. 11: Description of the areas




Fig. 65: Parametrisation interface

Area	Description
Menu bar	Menus and commands for operating the interface.
Tool bar	
Area of use	Displays parameter values, graphs or input options relative to the view, function and parameter selected.
Navigation area	Displays the user level and error messages. Enables selection of connected interfaces. Enables selection of devices connected at the interface. Enables selection of functions in relation to the parameter selected.

Tab. 12: Description of the areas




Fig. 66: Device and hardware information interface

Area	Description
Device	Displays the serial number, device name, grid type, local installation location and time
Software	Displays the firmware package installed
Network	Displays the current grid parameters

Tab. 13: Description of the areas

9.4 Menu structure

NOTE



















Use of a suitable web browser

We recommend using an up-to-date Firefox or Chrome browser or the default browser that is available on the mobile terminal devices to configure the device via the web interface.














Symbols used


	Menu level (0,1,2,3)		Password-protected menu (password can be requested from KACO customer service)
	Submenu		Setting only in Installer interface
	Setting only in Service interface		Option box
	Display		Setting range
	Option menu		Default value
			Interval
















































9.4.1 Yield via web user interface



Country-spec. Settings	Level Display/ Setting	Display/ Setting	Action in this menu/meaning
		Daily view	 Displays the recorded operating data graphically.  Select a day.  The web interface shows the selected data.
		Weekly view	 NOTE: Displays the recorded operating data graphically.  Select a week.  The web interface shows the selected data.
		Month display	 Displays the recorded operating data graphically.  Select a month.  The web interface shows the selected data.
		Complete overview	 Displays the total yield up to now.
		Export / print	 NOTE: Opportunity to print out or save the chart.
	<input type="checkbox"/> Print		1. Select an output format.
	<input checked="" type="checkbox"/> PNG PDF JPEG SVG GIF		2. Specify the storage location.











































9.4.2 Configuration via web user interface



Country-spec. Settings	Level Display/ Setting	Display/ Setting	Action in this menu/meaning
		Overview	 Input screens for basic settings
		Localisation	 <ol style="list-style-type: none"> 1. Select the required language for the user interface. 2. Select the current date and enter the time or press the button "Synchronize with the Client device now". 3. Select a time zone. 4. Specify the temperature unit. 5. Enter the device name. 6. Enter the degree of longitude and latitude of the installation location. 7. Enter the plant ID. 8. Confirm the action field.
	<input type="checkbox"/> Status		
		AC Settings	 Input screens for grid parameters.
		Country & Grid type	 NOTE: This option influences the country-specific operating settings of the device. Please consult KACO Service for further information.
			<ol style="list-style-type: none"> 1. Select country and grid type. 2. Observe the note for [See section 9.4.2 ▶ Page 74]
		Nominal grid voltage & Nominal grid frequency	 Specify optional nominal grid voltage.
	<input type="checkbox"/> Status		NOTE: The device switches off if the grid frequency deviates from the nominal grid voltage by more than 9.5Hz.
	<input checked="" type="checkbox"/>		<ol style="list-style-type: none"> 1. Select optional nominal grid frequency. 2. Confirm the action field.
		Shutdown settings	 NOTE: Activate shutdown according to generic parameters, frequency or voltage.
























Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	[+] [3] [-] Generic parameters [+] [1] [-] Protection shutdown with intentional delay <input type="checkbox"/> [] <input checked="" type="checkbox"/> [] Check to enable	 NOTE: Opportunity to activate standard protective shutdown 1. If necessary, activate delayed trip-off. 2. Confirm the action field.


Country-spec. Level Display/ Settings Setting	Action in this menu/meaning
 Frequency	 NOTE: Opportunity to monitor frequency shutdown.
 Trip underfrequency monitoring  Status	 Activate if necessary. NOTE: If the grid voltage drops below 20% of Un, the underfrequency monitoring is deactivated.
 Number of trip underfrequency levels  1- 5 /  1 /  1	 Specify the number of support levels.
 Trip underfrequency level 1  45 – 65 [Hz] /  47.5 [Hz] /  0.01 Trip underfrequency time level 1  0– 120000 [ms] /  100 [ms] /  1	NOTE: If the grid frequency is within the deactivation range for the duration of the deactivation time, then the function is deactivated.  Define range and trip-off time.
 Trip underfrequency level 2 - 5  42.5 – 65 [Hz] /  47.5 [Hz] /  0.01 Trip underfrequency time level 2 – 5  0– 100000 [ms] /  100 [ms] /  1	
 Trip overfrequency monitoring  Status	 Activate if necessary.
 Number of trip overfrequency levels  1- 5/  2 /  1	 Specify the number of support levels.
 Trip overfrequency level 1  45.0– 66 [Hz] /  51.5 [Hz] /  0.01 Trip overfrequency time level 1  0 – 120000 [ms] /  100 [ms] /  1	NOTE: If the grid frequency is within the deactivation range for the duration of the deactivation time, then the function is deactivated. 1. Define range and trip-off time. 2. Confirm the action field.
 Trip overfrequency level 2 – 5  45,0– 66 [Hz] /  51.5 [Hz] /  0.01 Trip overfrequency time level 2 – 5  0 – 120000 [ms] /  100 [ms] /  1	





























Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	Voltage	NOTE: Opportunity to monitor the voltage shutdown
	Trip undervoltage monitoring <input type="checkbox"/> Status	 Activate if necessary.
	Number of trip undervoltage levels 1 – 5 / 2 / 1	Specify the number of support levels.
	Trip undervoltage level 1 10 – 100 [% U _{nom}] / 80 [% U _{nom}] / 0.1 Trip undervoltage time level 1 0–120000 [ms] / 1000 [ms] / 1	Define range and trip-off time.
	Trip undervoltage level 2 – 5 10 – 100 [% U _{nom}] / 45 [% U _{nom}] / 0.1 Trip undervoltage time level 2 – 5 0–120000 [ms] / 300 [ms] / 1	
	Trip overvoltage monitoring <input type="checkbox"/> Status	 Activate if necessary.
	Number of trip overvoltage levels 1 – 5 / 2 / 1	Specify the number of support levels.
	Trip overvoltage level 1 100 – 125 [% U _{nom}] / 110.0 [% U _{nom}] / 0.1 Trip overvoltage time level 1 0–120000 [ms] / 100 [ms] / 1	1. Define range and trip-off time. 2. Confirm the action field.
	Trip overvoltage level 2 – 5 100 – 125 [% U _{nom}] / 114.8 [% U _{nom}] / 0.1 Trip overvoltage time level 2 to 5 0–120000 [ms] / 100 [ms] / 1	









Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	<p> 10 min. average</p> <p></p> <p><input type="checkbox"/> Status</p> <p>10-minute average</p> <p> 100 – 125 [% Unom] /</p> <p> 125.0  0.1%</p>	<p> NOTE: Monitoring of a variation in the average voltage value of 10 minutes.</p> <p> Activate if necessary.</p> <p> Set the voltage in % via averaging.</p>
	<p> Islanding detection</p>	<p>NOTE: Grid operators require shutdown of the device with standalone grid detection. More detailed information at: [See section 10.5 ▶ Page 97]</p>
	<p> Mode</p> <p><input type="checkbox"/> Off // ROCOF enhanced / Frequency shift</p> <p><input type="checkbox"/> Password Protection</p>	<p>NOTE: This function is active in the factory setting and may only be deactivated in standalone islanding operation (without grid).</p> <ol style="list-style-type: none"> 1. Select mode and note menu items. 2. Activate password protection if necessary. 3. Confirm the action field.
	<p> ROCOF threshold level 1 value  0.1 – 6.0 [Hz / s] /  0.1</p> <p>ROCOF threshold level 2 value  0.1 – 6.0 [Hz / s] /  0.1</p> <p>ROCOF threshold level 1 time  100 – 5000 [ms] /  0.1</p> <p>ROCOF threshold level 2 time  100 – 5000 [ms] /  0.1</p>	<p>  Define threshold for ROCOF.</p> <p> Define time value for ROCOF.</p>
	<p> ROCOF enhanced</p>	<p> NOTE: Active detection after exceeding the first frequency threshold.</p>
	<p> ROCOF threshold level 1 value  0.1 – 6.0 [Hz / s] /  0.1</p> <p>ROCOF threshold level 2 value  0.1 – 6.0 [Hz / s] /  0.1</p> <p>ROCOF threshold level 1 time  100 – 5000 [ms] /  0.1</p> <p>ROCOF threshold level 2 time  100 – 5000 [ms] /  0.1</p>	<p>  Define threshold for ROCOF.</p> <p> Define time value for ROCOF.</p>
	<p> ROCOF proportionality factor</p> <p> -5000 – 5000 [°/00 / Hz / s] /  -20 /  1</p> <p><input type="checkbox"/> Status</p>	<p> 1. Define the proportionality factor.</p> <p> 2. Confirm the action field.</p>











Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	[1] [2] [3] [4] Frequency shift [5] [6] [7] [8] Off On	 Activate frequency shift.
	[1] [2] [3] [4] Ramp rate limitation Operation mode [5] [6] [7] [8] On Off Increasing gradient & Falling gradient ⚙ 1 – 65534 [%/min] / ◦ 65534 / 🏠 1	 NOTE: Opportunity to limit power in the case of an increasing and decreasing nominal power/maximum power. ☞ Select operation mode. ☞ Set gradient. This percentage relates to the nominal power/maximum power. ☞ Confirm the action field.












Country-spec. Settings	Level Display/Setting	Action in this menu/meaning
	   Connection conditions	 NOTE: Precise connection conditions should be specified relative to the grid conditions.
	   Min. switch-on voltage after grid monitoring ⚙ 10 – 110 [% Unom] / ◉ 94.8 / 📶 0.1 & Max. switch-on voltage after grid monitoring ⚙ 90 – 125 [% Unom] / ◉ 110.0 / 📶 0.1	⚙ Specify switch-on voltage range after grid error.
	   Min. switch-on frequency after grid monitoring. ⚙ 45 – 65 [Hz] / ◉ 47.5 / 📶 0.01 & Max. switch-on frequency after grid monitoring. ⚙ 45 – 65 [Hz] / ◉ 50.05 / 📶 0.01	⚙ Specify switch-on frequency range after grid error.
	   Min. switch-on voltage after grid error ⚙ 10 – 110 [% Unom] / ◉ 94.8 / 📶 0.1 & Max. switch-on voltage after grid error ⚙ 90 – 125 [% Unom] / ◉ 110.0 / 📶 0.1	⚙ Specify switch-on voltage range after grid error.
	   Min. switch-on frequency after grid error ⚙ 45 – 65 [Hz] / ◉ 47.50 / 📶 0.01 & Max. switch-on frequency after grid error ⚙ 45 – 65 [Hz] / ◉ 50.05 / 📶 0.01	⚙ Specify switch-on frequency range after grid error.
	   PV voltage monitoring time ⚙ 1000 – 1800000 [ms] / ◉ 60000 / 📶 1000 & Grid voltage monitoring time ⚙ 1000 – 1800000 [ms] / ◉ 60000 / 📶 1000 &	⚙ Specify the time for monitoring the grid voltage and PV voltage.
	   Waiting time after grid error ⚙ 1000 – 1800000 [ms] / ◉ 60000 / 📶 1000	1. Set waiting time after grid failure. 2. Activate optional password protection. 3. Confirm the action field.
	 Status	




























Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	<p>1 2 3 4 Active power regulation</p>	<p>NOTE: The output power of the device can be set permanently to a lower value than the maximum output power via the active power regulation.</p>
	<p>1 2 3 4 Internal</p> <p>1 2 3 4 Power Limitation</p> <p><input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable</p>	<p>NOTE: Option for internal power limitation as required by the grid operator to limit the maximum power rating of the system at the grid connection point. More detailed information at: [See section 10.4.1 ▶ Page 95]</p> <p>Specify the activation status.</p>
	<p>1 2 3 4 Maximum apparent power Slim</p> <p>10000 –125000 / <input type="text"/></p> <p>[See section 4 ▶ Page 12]</p> <p>[VA] / <input type="text"/> 100 [VA]</p>	<p>NOTE: The max. apparent power limits the internal power of the device.</p> <p>Enter the value or set the value using the slider.</p>
	<p>1 2 3 4 Maximum active power Plim</p> <p>1.0 – 100.0 [% Slim] / <input type="text"/></p> <p>100[% Slim] / <input type="text"/> 0.1</p>	<p>NOTE: The max. active power limits the internal power of the device.</p> <p>Enter the value or set the value using the slider.</p>















































Country-spec. Level Display/ Settings Setting	Action in this menu/meaning
<p> External</p> <p> Power Limitation</p> <p><input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable</p> <p> AC fallback active power</p> <p> 0 – 100 [%Plim] /  100 [%Plim] /  1</p> <p> Fallback time</p> <p> 0 – 43200 [s] /  300 [s] /  1</p>	<p> NOTE: The parameters set here are used if no valid external power or reactive power setpoints are received via the communication interface or if communication fails for the set fallback time.</p> <p>NOTE: A communication failure has occurred if no valid "Enable" signal or no updated external setpoint is received within the set fallback time.</p> <p> Specify the activation status.</p> <p>NOTE: If the function is activated, external specifications for active power are taken into account and set to defined fallback values in the event of a fault.</p> <p>NOTE: If the function is deactivated, there is no automatic power fallback in the event of a communication failure</p> <p> Set fallback power.</p> <p>NOTE: Defines the active power to which the device reverts in the event of a communication failure.</p> <p>NOTE: If no valid external setpoint is received within the configured fallback time, the power is limited to the configured fallback power.</p> <p>NOTE: The fallback power is used taking into account other active limitations (e.g. mains-side limit values or device protection functions).</p> <p> Set the fallback time for the external power specification.</p> <p>WARNING! After the set fallback time has elapsed without a valid external specification, external setpoints for cos-phi, Q and P are set to the configured fallback values (cos-phi constant, Q-constant or AC active fallback power), respectively. During the fallback time, the device operates with the last valid setpoint that was received.</p> <p>WARNING! If the fallback time is set to 0 s, external specifications are not reset (continued operation with last received setpoint).</p> <p>WARNING! The fallback time is set for each valid external telegram.</p>
<p> Output gradient limitation increase & Output gradient limitation decrease</p> <p> 1 – 65534 [% Slim / min] /  65534 [% Slim / min] /  1</p>	<p>  Set maximum power increase.</p> <p>NOTE: Limits the maximum rate of change for power increases in normal operation and when returning from the fallback power to external specifications.</p> <p> Set gradient limitation for the fallback case.</p> <p>NOTE: If the value is set to 65534, there is no separate ramp limitation for the fallback case.</p>
<p> Settling time (3 Tau)</p> <p> 120 – 36000 [ms] /  120 [ms] /  10</p> <p><input type="checkbox"/> <input checked="" type="checkbox"/> Status</p>	<p> NOTE: The displayed value refers to 3 Tau according to the current standards.</p> <p>This setting only affects the display of the transient behaviour. The actual control behaviour of the device remains unchanged.</p> <p>1. Specify the settling time. 2. Confirm the action field.</p>
<p> P(f)</p>	<p> NOTE: Activate frequency-dependent power reduction in the P(f) menu.</p>




















Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
Not for IL, IT	Operation mode <input type="checkbox"/> Off Mode 1 Mode 2 Mode 3	 Specify the operation mode. NOTE: Mode 1 = Hysteresis active – Limit; Mode 2 = Hysteresis inactive – Limit; Mode 3 = Hysteresis inactive – Set
	Power reference at underfrequency <input type="checkbox"/> Actual power Nominal power Power reference at overfrequency <input type="checkbox"/> Actual power Nominal power	 <ol style="list-style-type: none"> 1. Specify control method with underfrequency. 2. Specify control method with overfrequency.
	Dynamic gradient mode <input type="checkbox"/> On Off	 Activate dynamic gradient. NOTE: Gradient "Feed-in/charging with over/under frequency" is not displayed.
	Minimum frequency for dynamic gradient ⚙️ 40 – 50 [Hz] / 📏 0.01 [Hz] Maximum frequency for dynamic gradient ⚙️ 50 – 60 [Hz] / 📏 0.01 [Hz]	 Specify dynamic gradient frequency in Hz.
	Gradient at overfrequency (feed-in) ⚙️ 0 – 200 (%/Hz) • 40 (%/Hz) Gradient at underfrequency (feed-in) ⚙️ 0 – 200 (%/Hz) • 40 (%/Hz)	 <ol style="list-style-type: none"> 1. Specify gradient for feed-in with overfrequency. 2. Specify gradient for feed-in with underfrequency.
	Activation threshold at underfrequency ⚙️ 40 – 50 [Hz] / 📏 0.01 [Hz] Activation threshold at overfrequency ⚙️ 50 – 60 [Hz] 📏 0.01 [Hz]	 <ol style="list-style-type: none"> 1. Set the frequency thresholds for activating the power limitation with undervoltage. 2. Set frequency thresholds for activating the power limitation with overvoltage.
	Frequency of the maximum deactivation threshold ⚙️ 45 -50.2 [Hz] Frequency of the minimum deactivation threshold ⚙️ 45 -50.2 [Hz]	 <ol style="list-style-type: none"> 1. Set frequency of the maximum deactivation threshold. 2. Set frequency of the minimum deactivation threshold.
Not for IL, IT	P(f) deactivation time ⚙️ 0 – 6000000 [ms] / • 0 [ms] / 📏 1000 [ms]	 Specify time for power reduction (if mode 1 is active).














Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	P(f) deactivation gradient 0 – 65534 [% S _{max} / min] / 10 / 1	 Determine the deactivation gradient.
	P(f) intentional delay 0 – 5000 [ms] / 0 [ms] / 1	 Set the power limitation delay.
	Deactivation range lower limit 45 – 61.5 [Hz] / 0.01 & Deactivation range upper limit 45 – 70 [Hz] / 0.01	 Set the lower and upper deactivation range in Hz. NOTE: Only evaluated in mode 1. The function is deactivated if the frequency returns to the range between the minimum and maximum deactivation threshold and remains in this range for the duration of the deactivation time.
	Activation delay 0 – 5000 [ms] / 0 [ms] / 1	 Set the control delay. NOTE: Time delay for activating the function after the activation frequency threshold has been exceeded in the case of overfrequency events with a rising edge or underfrequency events with a falling edge.
	Output gradient limitation increase & Output gradient limitation decrease 1 – 65534 [% P _{lim} / min] / 65534 [% P _{lim} / min] / 1	 Specify the increasing and decreasing output gradient.
	P(f) settling time (3 Tau) 120 – 36000 [ms] / 120 [ms] / 10 status status	 <ol style="list-style-type: none"> 1. Set the P(f) settling time mode. 2. Confirm the action field.
	Deact. Limitation time after fault 0 – 1000 [s] / 0 [ms] / 1000 [s]	 After the end of the fault, the change in active power is limited to the set gradient for the specified time. NOTE: Only evaluated in mode 2&3.
	Deactivation gradient increase after fault & Deactivation gradient decrease after fault 0 – 65534 [% / min] / 10 [% / min] / 1	 Limits the change in active power after the end of the fault. NOTE: Only evaluated in mode 2 & 3.
	P(U)	 NOTE: Activate voltage-dependent power reduction in the P(U) menu.
	Operation mode Off On	 Activate the control process. Off: Deactivates dynamic grid support using dynamic reactive current. Dynamic grid support remains active on account of immunity to interference.













































Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	Reference power <input type="checkbox"/> Instantaneous power <input checked="" type="checkbox"/> Nominal power	 Select the power-dependent control method.
	Rated voltage <input type="checkbox"/> Maximum phase voltage <input checked="" type="checkbox"/> Positive sequence voltage	 Select the voltage to be rated. Specifies which voltage is evaluated in a three-phase system.
	Hysteresis mode <input type="checkbox"/> Off On	 NOTE: Hysteresis mode affects the shutdown response of P(U).  Activate the mode.
	Deactivation gradient 0 – 65534 [%P _{mom} / min] / 65534 [% / min] / 1	 Set the gradients for the power limitation.
	Deactivation time 0 – 60000000 [ms] / 0 [ms] / 1000 [ms]	 Specify the time for voltage reduction.
	Output gradient limitation increase & Output gradient limitation decrease 1 – 65534 [% P _{lim} / min] / 65534 [% P _{lim} / min] / 1	 Specify the increasing and decreasing output gradient.
	Settling time (3 Tau) 600 – 72000 [ms] / 1200 [ms] / 10	 Specify the settling time.
	Active curve 1 - 5	 Select active curve. NOTE: Up to 5 characteristic curves can be configured independently and one of them can be activated for regulation each time.
	Number of nodes 2 – 5	 Specify the number of nodes.
	Power 0.0 – 100.0 [% Pref] / 100 [% Pref] / 1	 Specify power for 1st, 5th ... node as a percentage of the maximum power.
	Voltage 80.0 – 125.0 [%Unom] / 112 / 0.1	1. Specify voltage for 1st, 5th ... node as a percentage of the maximum voltage. 2. Confirm the action field.
	<input type="checkbox"/> Status	





























Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	 Ramping-up limitation	 NOTE: Power ramp-up is used to ramp up the power gradually. More detailed information at: [See section 10.4.2 Page 97]
	 Power rampup gradient ⚙️ 1 – 3000 [% / min] / ⚙️ 10 [% / min] / 🏠 1	 Set increase.
	 Power rampup on every connect Rampup on first connect Rampup after grid failure <input type="checkbox"/> Check to enable	<ol style="list-style-type: none"> 1. Activate option. 2. Confirm the action field.
	 Reactive power control	 NOTE: Activate the reactive power process in the mode menu. More detailed information at: [See section 10.1 Page 77]
	 Mode <input type="checkbox"/> Specification cos-phi <input type="checkbox"/> Specification Q Cos-phi(P/Plim) Q(U) Q(P)	 <ol style="list-style-type: none"> 1. Select a control process. 2. Confirm the action field.
	 Cos-phi constant	 NOTE: Define the cos φ constant.
	 Cos-phi constant ⚙️ 0,3 – 1 / ⚙️ 1 / 🏠 0,001	 Determine the specified power factor.
	 Increasing power gradient & Decreasing power gradient ⚙️ 1 – 65534 [% P _{lim} / min] / ⚙️ 65534 [% P _{lim} / min] / 🏠 1	 <ol style="list-style-type: none"> 1. Maximum change in the reactive power %P_{lim}/min in the event of a change to overexcited mode. 2. Maximum change in the reactive power %P_{lim}/min in the event of a change to underexcited mode.
	 Settling time (3 Tau) ⚙️ 600 – 72000 [ms] / ⚙️ 10000 [ms] / 🏠 10	 <ol style="list-style-type: none"> 1. Set the settling time in the event of an abrupt change in the reactive power target value (e.g. caused by a voltage jump). 2. Confirm the action field.
	 Q constant	 NOTE: Define the Q constant.
	 Priority mode <input type="checkbox"/> Q-priority P-priority	 Set priority.
	 Q constant ⚙️ 0 – 100 [% Slim] / ⚙️ 0 [% Slim] / 🏠 0.1 ⚙️ Under-excited over-excited	 Set the idle power Q to a fixed value.  Select the type of phase shift. NOTE: Underexcited relates to inductive load, overexcited relates to capacitive load.
	 Output gradient limitation increase & Output gradient limitation decrease ⚙️ 1 – 65534 [% P _{lim} / min] / ⚙️ 65534 [% P _{lim} / min] / 🏠 1	 <ol style="list-style-type: none"> 1. Maximum change in the reactive power %P_{lim}/min in the event of a change to overexcited mode. 2. Maximum change in the reactive power %P_{lim}/min in the event of a change to underexcited mode.



























Country-spec. Level Settings	Display/ Setting	Action in this menu/meaning
	Settling time (3 Tau)  600 – 72000 [ms] /  10000 [ms]  10	 <ol style="list-style-type: none"> 1. Set the settling time in the event of an abrupt change in the re-active power target value (e.g. caused by a voltage jump). 2. Confirm the action field.
	Cos-phi(P) 	 NOTE: Define the cos ϕ (P).
	Lock-in voltage  10 – 126.6 [% Unom] /  80 [% Unom] /  0.1	 Set the voltage above which control is activated.
	Lock-out voltage  10 – 126.6 [% Unom] /  80 [% Unom] /  0.1	 Set the voltage below which control is deactivated.
	Increasing power gradient & Decreasing power gradient  1 – 65534 [% P _{lim} / min] /  65534 [% P _{lim} / min] /  1	 <ol style="list-style-type: none"> 1. Maximum change in the reactive power %P_{lim}/min in the event of a change to overexcited mode. 2. Maximum change in the reactive power %P_{lim}/min in the event of a change to underexcited mode.
	Settling time (3 Tau)  600 – 72000 [ms] /  10000 [ms]  10	 Set the settling time in the event of an abrupt change in the re-active power target value.
	Number of nodes  2 - 10	 NOTE: The maximum number of configurable nodes depends on the selected grid type.  Specify the number of nodes.
	Node 1- Node 10 Power Curve 1  0-100% [% Slim] /  0, 50, 100 [% Slim] /  1 Cos-phi Curve 1  0.3 – 1 [ind/cap] /  1 /  0.001 over-excited Under-ex-cited  Status	 Power factor for 1st , 10th ... node as a percentage of the maximum power. NOTE: For the 1st node, the power must be 0%, for the last node the power must be 100%. The power values of the nodes must increase continuously.  Specify the cos ϕ of the node.  If a reactive power not equal to 1 is selected: Select the type of phase shift. NOTE: Overexcited relates to a capacitive load, underexcited relates to an inductive load.  Confirm the action field.
	Q(P) 	 NOTE: Define Q(P).
	Increasing power gradient & Decreasing power gradient  0 – 65535 [% Slim] /  65535 [% Slim] /  1	 Specify the increasing and decreasing power gradient.
	Settling time (3 Tau)  120 – 180000 [ms] /  3600 [ms]  10	 Set the settling time in the event of an abrupt change in the rated power target value.








































Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	[] [] [] [] Number of nodes ⚙️ 2 - 10	 NOTE: The maximum number of configurable nodes depends on the selected grid type. ☞ Specify the number of nodes.
	[] [] [] [] Q(P) Active curve ⚙️ 1 - 10	 ☞ Select active curve. NOTE: Up to 10 characteristic curves can be configured independently and one of them can be activated for regulation each time.
	[] [] [] [] Node 1- Node 10 Power Curve 1 ⚙️ 0-100% [% Slim] / ◉ 0, 50, 100 [% Slim] /  1 Cos-phi Curve 1 ⚙️ 0.3 – 1 [ind/cap] / ◉ 1 /  0.001 over-excited Under-excited <input type="checkbox"/> = Status	 ☞ Power factor for 1st , 10th ... node as a percentage of the maximum power. NOTE: For the 1st node, the power must be 0%, for the last node the power must be 100%. The power values of the nodes must increase continuously. ☞ Specify the cos φ of the node. ☞ If a reactive power not equal to 1 is selected: Select the type of phase shift. NOTE: Overexcited relates to a capacitive load, underexcited relates to an inductive load. ☞ Confirm the action field.
	[] [] [] [] Q(U)	 NOTE: Define Q(U).
	[] [] [] [] Lock-in power ⚙️ 0 – 100 [% Slim] / ◉ 20 [% Slim] /  1	 ☞ Set the active power as a % of rated power above which control is activated.
	[] [] [] [] Lock-out power ⚙️ 0-100 [% Slim] / ◉ 5 [% Slim] /  1	 ☞ Set the active power as % of rated power below which control is deactivated.
	[] [] [] [] Lock-in time ⚙️ 0 – 60000 [ms] / ◉ 30000 [ms] /  1000 [ms] Lock-out time ⚙️ 0 – 60000 [ms] / ◉ 30000 [ms] /  1 [ms]	 ☞ Set the length of time that the active power must remain above the lock-in / lock-out power level before control is activated.
	[] [] [] [] Downtime ⚙️ 0 -10,000 [ms] / ◉ 0 [ms] /  1	 ☞ Set the intentional delay for the start of the Q(U) function.
	[] [] [] [] Output gradient limitation increase & Output gradient limitation decrease ⚙️ 1 – 65534 [% P _{lim} / min] / ◉ 65534 [% P _{lim} / min] /  1	 <ol style="list-style-type: none"> 1. Maximum change in the reactive power %P_{lim}/min in the event of a change to overexcited mode. 2. Maximum change in the reactive power %P_{lim}/min in the event of a change to underexcited mode.
	[] [] [] [] Settling time ⚙️ 1000 – 120000 [ms] / ◉ 1000 [ms] /  10	 ☞ Set the response speed of the control.

















Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	Minimum cos-phi Q1 - Minimum cos-phi Q4 0 – 1 / 0 / 0,001	 Enter the minimum cos ϕ factor for quadrants 1 and 4.
	Voltage dead band 0 – 5 [% Uref] / 0.0 / 0.1	 Set voltage dead band in %.
	Q(U) Offset (temporary) U offset -100 -100 [% Slim] / 0.0 [%Slim] / 0.1 Q offset -100 -100 [% Slim] / 0.0 [%Slim] / 0.1	 Set the intended Q or U offset for the function. NOTE: The voltage offset is added to the measured voltage. Accordingly, the sign must be inverted if the curve is shifted.
	Q minimum 0 – 100 [% Slim] / 0 [% Slim] / 0.1 Under-excited over-excited	 Set the reactive power Q to a minimum value.  Select the type of phase shift. NOTE: Underexcited relates to inductive load, overexcited relates to capacitive load.
	Q maximum 0 – 100 [% Slim] / 0 [% Slim] / 0.1 Under-excited over-excited	 Set the reactive power Q to a maximum value.  Select the type of phase shift. NOTE: Underexcited relates to inductive load, overexcited relates to capacitive load.
US, UD	Autonomous adjustment Vref <input type="checkbox"/> Check to enable	 When autonomous adjustment is activated, the reference voltage of the reactive power function is adjusted to the measured voltage using a PT1 filter. This dynamically shifts the Q(U) characteristic curve.
US, UD	Time constant setting Vref 300 – 5000 [s] / 300 s	 Set the time constant for adjusting the dynamic reference voltage.
	Q(U) Active curve 1 - 4	 Select active curve. NOTE: Up to 4 characteristic curves can be configured independently and one of them can be activated for regulation each time.
	Priority mode Q-priority P-priority	 Set priority for reactive power – Q or active power – P. NOTE: When it comes to P-priority, the reactive power adjustment range is limited subject to the active power that is currently available and fed in.
	Number of nodes 2 - 10	 NOTE: The maximum number of configurable nodes depends on the selected grid type.  Specify the number of nodes.





















Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	<p> Node 1- Node 10</p> <p> Power / Excitation / Voltage</p> <p> 0 – 100 [% Slim] /  43.6 [% Slim] /  0.1</p> <p>over-excited Under-excited</p> <p> Status</p> <p> 0 – 125.0 [% Unom] /  90 ... 110.0 [% Unom] /  0.1 [% Unom]</p>	<p> Set the reactive power of the node as a percentage of the maximum power.</p> <p> Select the type of phase shift.</p> <p>NOTE: Overexcited relates to a capacitive load, underexcited relates to an inductive load.</p> <p> Enter the voltage of the node in volts.</p> <p>NOTE: The voltage values of the nodes must increase continuously. At voltages below the 1st node and voltages above the last node, the reactive power value of the 1st or last node is used each time.</p>
	<p> FRT (Fault Ride Through)</p>	<p>NOTE: The device supports dynamic grid stabilization. More detailed information at: [See section 10.3 Page 91]</p>
	<p> Operation mode</p> <p> On Off</p> <p>Settings Manual Pre-defined zero current</p> <p>Priority – Reactive current limitation Dynamic reactive current</p>	<p> Select a control process.</p> <p>On: Activates dynamic grid support using dynamic reactive current.</p> <p>Off: Deactivates dynamic grid support using dynamic reactive current. Dynamic grid support remains active on account of immunity to interference.</p> <p> Select a control process.</p> <p> Select a control process.</p>
	<p> Constant K positive sequence dip & Constant K positive sequence swell</p> <p> k 0 – 10  2  0.1</p>	<p> Set amplification factor k for the pos. sequence for drop and increase in the grid voltage.</p>
	<p> Constant K negative sequence dip</p> <p>Constant K negative sequence swell</p> <p> k 0 – 10  2  0.1</p>	<p> Set amplification factor k for the neg. sequence for drop and increase in the grid voltage.</p>
	<p> Dead band</p> <p> 2 – 120 [% Uref]  10.0  0.1</p>	<p> Set dead band in %.</p>
	<p> Dynamic reactive current only</p> <p> Off On</p>	<p>NOTE: With activated FRT mode, the pre-fault reactive current can be added.</p> <p> If necessary, activate pre-fault reactive current.</p>
	<p> Dead band mode</p> <p> Mode 1 Mode 2</p>	<p> Select dead band mode for the active control process.</p>
	<p> Reference voltage</p> <p> 80.0 – 110.0 [% Unom]  100  0.1</p>	<p> Set reference voltage for the active control process.</p>































Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	Minimum operating voltage deactivation  0.0 – 100 [% Unom]  0.1 & Maximum operating voltage deactivation  100.0 – 125.0 [% Unom]  0.1	 Set voltage range for the active control process.
	Zero current under-voltage threshold  0 – 90 [% Unom]  0.1 Zero current overvoltage threshold  110 – 141.8 [% Unom]  0.1	 Set voltage threshold for zero current mode. If one or more phase/phase or phase/neutral conductor voltages move below or above the configured threshold, the inverter changes to zero current mode. The total current is regulated to virtually zero.
	Reactive current limitation  0 – 100 [% Imax] /  100 [% Imax] /  1	 Set the reactive power limitation.
	Minimum support time  1,000 – 15,000 [ms] /  5,000 [ms]  10	 Set the minimum support time.
	Overvoltage protection	 NOTE: Shutdown carried out within a grid cycle.
	Transient overvoltage protection  114.8 – 127.5 [% Unom] /  127.5 /  0.1 %	 <ol style="list-style-type: none"> 1. Set the transient overvoltage protection. 2. Confirm the action field.
	External grid protection disconnection	 NOTE: Opportunity to detect the external grid protection devices
	External grid protection <input type="checkbox"/> No device Powador-protect third-party device	 Select device.
	Powador-protect Powador-protect operation mode <input type="checkbox"/> Auto On Off	 NOTE: Configures the grid shutdown via a Powador protect connected to the "INV OFF" input of the device.  Auto/On: A Powador-protect is operating in the photovoltaic system and is connected to the device at the "INV OFF" input.  Set the operating mode for Powador-protect. Auto: The device automatically detects a Powador-protect integrated into the photovoltaic system. On: The digital signal of the Powador-protect must be present at the digital input of the device for the device to begin feed-in. Off: The device does not check whether a Powador-protect is integrated into the PV plant.




















Country-spec. Settings	Level Display/Setting	Action in this menu/meaning
	 3rd party device Name of the 3rd party device 3rd party device operation mode <input type="checkbox"/> On <input type="checkbox"/> Off	 NOTE: Configures the grid shutdown via a 3rd party device connected to the digital input of the device Enter the name of the 3rd party device. Select operation mode. On: The digital signal of the 3rd party device must be on the device's digital input so that the device does not shut down. Off: The device does not check whether a 3rd party device is integrated into the PV system.
	 Password Protection <input type="checkbox"/> Check to enable	 <ol style="list-style-type: none"> 1. Opportunity to set password protection. 2. Confirm the action field.
	 DC Settings	 Input masks for DC source (PV generator/battery)
	 DC starting volt.  /  [See section 4 ▶ Page 12] [V] /  1 [V]	 NOTE: The device begins feed-in as soon as this DC voltage is present. <ol style="list-style-type: none"> 1. Set the starting voltage. 2. Confirm the action field.
	 Insulation resistance  100 – 2000 [kohm] /  300 [kohm] /  1[kohm]	 <ol style="list-style-type: none"> 1. Set threshold value at which the insulation monitor reports a fault. 2. Confirm the action field.
	 DC configuration All inputs separate All inputs parallel	 NOTE: Before connecting the individual DC strings, the correct DC configuration must be set. The inputs used may only be separated or connected in parallel. Mixed operation may damage the device. NOTE: Observe recommended standard connections! [See section 7.6.3 ▶ Page 26] <ol style="list-style-type: none"> 1. "Select all inputs used separately" if strings are connected individually. 2. Optional: Select "All inputs in parallel" if strings are connected in parallel. 3. Confirm the action field.
	 Global MPPT <input type="checkbox"/> On <input type="checkbox"/> Off Time interval  5–120 min • 30 min	 NOTE: To determine the global MPP, first the MPP trackers (1/3/5/7/9) and then the MPP trackers (2/4/6/8/10) are investigated. During this time of approx. 8 sec. each, the MPP is left and causes a reduced yield. The interval time of the testing is carried out every 30 minutes and can be set. A reduction in the interval time leads to a greater reduction in yield. If 2 DC inputs of the device are connected in parallel, only one cycle is performed to determine the global MPP. If a global MPP is found, the MPP search algorithm is active again and follows the changes to provide the maximum possible power of the PV modules. In general, activating the global MPP only makes sense for shaded modules. Activate active management mode for all MPPT trackers. Set time interval.
	 Communication	 Input screens for configuring the interfaces.
	 Ethernet	 NOTE: Opportunity to parametrise the Ethernet interface.

Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning
	 IP Settings	NOTE: Parametrization of network access.
	 DHCP <input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable	  Activate or deactivate DHCP. On: Once the DHCP server becomes available, the IP address, subnet mask, gateway and DNS server are automatically applied and the aforementioned menu options are filled out. Off: Apply settings manually.
	 IP address	 Allocate a unique IPv4 address in the network.
	 Subnet mask	 Assign a subnet mask.
	 Standard gateway	 Enter IPv4 address of the gateway.
	 Obtain DNS server settings from DHCP <input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable	  Activate or deactivate the DNS server from DHCP. On: Once the DHCP server becomes available, the IP address is automatically applied and the aforementioned menu options are filled out. Off: Apply settings manually.
	 Primary DNS & Secondary DNS (optional)	 1. Enter IPv4 address of DNS server. 2. Confirm the action field.
	 ModBus	 NOTE: Opportunity to set the Modbus port.
	 Modbus TCP / UDP Activation <input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable	 Allow Modbus TCP / UDP reading access.
	 Modbus TCP / UDP Write access <input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable	 Allow Modbus TCP write access. Activating write access allows system-critical parameters to be set via Modbus TCP. Do you really want to allow write access?  Confirm the action field.
	 Modbus TCP / UDP Port	  Set network port.
	 MQTT	 NOTE: The MQTT protocol is used to implement the advanced functions between the Segment Controller and the inverter (in particular, firmware updates, distribution of device configurations etc.).
	 Broker IP	1. Displays the IP address transmitted by the Segment Controller.
	 Broker Port	NOTE: The standard settings allow for successful communication with the Segment Controller. 2. Confirm the action field.
	 NTP	 NOTE: An NTP server receives its accurate time information from a precise time source and makes it available to other devices on the network via the NTP protocol.
	 NTP server <input type="checkbox"/> <input checked="" type="checkbox"/> Check to enable	1. Obtain server addresses via DHCP or enter them under NTP Server 1&2. Activate server if necessary. 2. Confirm the action field.
	 NTP server 1	 Enter the server address.
	 NTP server 2	 Enter an alternative server address.
	 RS485	 NOTE: Option to select the communication protocol.
	 Serial Settings	NOTE: Set RS85 address and access.

Country-spec. Level Display/ Settings Setting	Action in this menu/meaning
<p> RS485 address</p> <p></p> <p>Baud rate</p> <p> 9600 8n1</p>	<p>NOTE: Opportunity to parametrise the RS485 interface. The parameters of the RS485 (CON901) are (as with all KACO inverters): 9600 Baud, 8n1 and cannot currently be re-configured via the web interface.</p> <p>NOTE: The address must not be the same as that of any other device or data logger.</p> <p>☞ Assign a unique RS485 bus address to the device.</p> <p>Bus termination is carried out on the HMI board by means of a dip-switch</p> <p>☞ Specify transmission and detection intervals.</p>
<p>Activating the RS485 configuration commands</p> <p><input checked="" type="checkbox"/> Check to enable</p>	<p>☞ Activation enables communication via RS485 with a duration of 24 hours.</p> <p>NOTE: Access is automatically deactivated after 24 hours.</p> <p>NOTE: This only affects commands that have been activated by the "Activating the RS485 configuration commands" command. Other commands that are used by meteocontrol, for example, are not affected by this.</p> <p>☞ Confirm the action field.</p>
<p> Protocol</p>	<p> NOTE: Option to select the communication protocol.</p>
<p> Protocol</p> <p> KACO Legacy or Modbus RTU</p>	<p>☞ Define communication protocols.</p> <p>NOTE: The selection ensures that communication can only take place via the existing commands.</p> <p>☞ Confirm the action field.</p>
<p> Modbus RTU</p>	<p> ☞ Set network port.</p>
<p> Modbus RTU Write access</p> <p><input checked="" type="checkbox"/> Check to enable</p>	<p>1. Allow Modbus RTU write access.</p> <p>2. Confirm the action field.</p>
<p> Properties / functions</p>	<p> NOTE: Input screens for advanced device functions</p>
<p> AFPE (ARC-Fault Protection Equipment)</p>	<p> NOTE: The internal arc fault protective device is only integrated in the "L" device variant.</p>
<p> AFPE monitoring (ARC)</p> <p><input checked="" type="checkbox"/> Check to enable</p>	<p> NOTE: The arc detection function is deactivated by default and can be activated via the Service account.</p> <p>1. Specify the activation status.</p> <p>2. Confirm the change using the "Apply settings" action field.</p> <p>⇒ Recognition starts the following day or by "Restarting the device" in the Service/Maintenance menu.</p> <p>NOTE: ARC detection can also be activated immediately using the "Manual restart" button.</p>

Country-spec. Level Settings	Display/ Setting	Action in this menu/meaning
	Constant volt. control Constant voltage mode <input type="checkbox"/> Off <input checked="" type="checkbox"/> On Constant voltage  /  [See section 4 ▶ Page 12] [V] /  1 [V]	 NOTE: Opportunity to deactivate the MPP seek mode in order to operate the device with a constant DC voltage. NOTE: When the constant voltage control is activated and "Q on Demand" operation is active, there can be feeding back into the PV generator. Please observe the module manufacturer's instructions and approval.  Activate or disable the constant voltage controller. 1. Set value for constant voltage controller. 2. Confirm the action field.
	SPD monitoring SPD monitoring AC SPD monitoring DC <input type="checkbox"/> Check to enable	 NOTE: Opportunity to check the overvoltage protection with appropriate status messages 1. Activate overvoltage protection. 2. Confirm the action field.
	Q on Demand (reactive power on request)	 NOTE: Only activate the function with the express permission of the network operator. Additional conditions: - No PID solution connected to the device. - Constant voltage regulator in the device is deactivated. See table : Configuration via web user interface [▶ Page 72]
	Night shutdown <input type="checkbox"/> Check to enable	 1. "Q on Demand" function is activated by deactivating the night shutdown. 2. Transfer function to memory. 3. Pay attention to the information window and, if necessary, activate the function with the "OK" button. NOTE: The reactive power settings currently specified are used. Power-dependent functions are not used. NOTE: If the AC is disconnected during the night, the function will not be available until the next day.
	Compliant with type B RCD <input type="checkbox"/> Check to enable	 NOTE: When using a type B RCD, the function must be activated 1. Activate connected RCD – type B. 2. Confirm the action field.
	Digital inputs / outputs Relay <input type="checkbox"/> Positive logic <input checked="" type="checkbox"/> Negative logic <input type="checkbox"/> inactive <input checked="" type="checkbox"/> active	 NOTE: Opportunity to configure the fault signal relay [ERR]. 1. Select the type of logic. 2. Select the form of activity. 3. Confirm the action field.
	Service / Maintenance	 NOTE: Opportunity to perform updates, retrieve service/parameter data and grant remote access.
	Firmware update	 NOTE: Opportunity to update the device. Parameter data are not overwritten when the firmware is updated.

Country-spec. Settings	Level Display/ Setting		Action in this menu/meaning
	 Perform instant update		<ol style="list-style-type: none"> 1. Select and confirm the firmware update file with the "Browse..." button 2. Load the firmware with the "Upload" button. 3. Note: The AC and DC supply to the inverter must be ensured throughout the update process. A loss of supply may result in damage to the device. Proceed with update?
	 Settings		NOTE: Settings for updating the firmware via remote access.
	 Allow remote firmware update		<ul style="list-style-type: none"> ☞ Activate remote access for updates.
	 Status		<p>Enter firmware update URL .</p> <ol style="list-style-type: none"> 1. Enter user name and password. 2. Specify the start and end time for the update. 3. Confirm the action field.
	 Check for Available software packages		<ul style="list-style-type: none"> ☞ Network connection available. <ol style="list-style-type: none"> 1. Checks for available device updates online using the existing network connection. 2. Start the firmware update by clicking the button.
	 Export service package		<p>NOTE: Opportunity to send an error log to KACO new energy.</p> <ul style="list-style-type: none"> ☞ Press the Export button and send the file to our service staff.
	 Service log		<p>NOTE: Display of all logged installations. You should also add all maintenance activities manually via the "Service" and "Installer" interfaces.</p> <ol style="list-style-type: none"> 1. Enter additional service activities (exception: "User" interface). 2. Export service logs, if necessary.
	 Logging management		NOTE: Input screens for log and service data and default settings.
	 Settings		Specify the interval for data capture and base meters.
	 User logging interval ⚙ 1 5 10 15 [minutes] / ⦿ 5		<ul style="list-style-type: none"> ☞ Specify the time period between 2 log data recordings. <p>NOTE: Setting and time until memory is overwritten: 1 min – 5 days; 5 min – 4.5 years; 10 min – 9 years; 15 min – 14 years.</p>
	 Service logging interval ⚙ 1 – 120 [sec] / ⦿ 10 [sec] / 📄 1		<ul style="list-style-type: none"> ☞ Specify the time period between 2 log data recordings. <p>NOTE: Setting and time until memory is overwritten: 1 sec – 9 days; 10 sec – 92,5 days; 120 sec - 1110 days</p>
	 DC-DSP logging interval ⚙ 1 – 120 [sec] / ⦿ 10 [sec] / 📄 1		<ul style="list-style-type: none"> ☞ Specify the time period between 2 log data recordings. <p>NOTE: Setting and time until memory is overwritten: 1 sec – 9 days; 10 sec – 92,5 days; 120 sec - 1110 days</p>
	 ARC-DSP logging interval ⚙ 1 – 120 [sec] / ⦿ 10 [sec] / 📄 1		<ul style="list-style-type: none"> ☞ Specify the time period between 2 log data recordings. <p>NOTE: Setting and time until memory is overwritten: 1 sec – 9 days; 10 sec – 92.5 days; 120 sec – 1110 days</p>
	 Analyse log data		NOTE: All measurement data can be transferred to a USB stick by making individual and multiple selections.
	 User log data ☑ cosPhi fac (Hz) lac 1 (A) lac2 (A) lac3 (A) idc (A) Qac (var)		<ol style="list-style-type: none"> 1. Select a date in the calendar. 2. Select measurement data from the dropdown field. 3. Update the measurement data. 4. Move the selected measurement data to the storage device or move the data selectively.
	 Parameter management		NOTE: Opportunity to reset set values as well as to import and export specific parameters.


Country-spec. Settings	Level Display/ Setting	Action in this menu/meaning	
	 Factory setting		<ol style="list-style-type: none"> 1. Compare all parameters/ country-specific parameters /network-specific parameters with basic setting value. 2. If necessary, reset parameters using the "Restore" button.
	 Export config.		<ol style="list-style-type: none"> 1. Exporting parameters for device-independent settings / Export all settings. 2. Select the parameters for export into a file or the plant manager.
	 Import configuration		<ol style="list-style-type: none"> 1. Select the parameter file using the "Browse" button. 2. Import the parameters using the "Upload" button.
	 Password Protection <input type="checkbox"/> Country selection <input checked="" type="checkbox"/> Connection conditions Islanding detection FRT (Fault Ride Through) 		<ol style="list-style-type: none"> 1. Opportunity to set up password protection for individual parameters. 2. Confirm the action field.
	 Installation wizard		<p>NOTE: The installation wizard is described in the chapter [See section 8.4 ▶ Page 38].</p> <p>When the installation process is complete, the text: Installation wizard was completed appears</p>
	 Network statistics		<p>NOTE: Sent and received data packets indicator</p> <p>☞ Press Refresh.</p>
	 Remote access		<p>When remote access is enabled, KACO can access the device remotely and assist you.</p> <p>☞ Activate on request.</p>
	 History		<p>NOTE: Displays all of the actions performed in the system and on the web interface.</p>
	 User account management		<ol style="list-style-type: none"> 1. Enter your User name. 2. Enter your new user-defined Password. <p>NOTE: The following is specific to KACO: Following initial start-up, it is necessary to Change the password</p>
	 Reboot device		<p>NOTE: Transfer safety-related parameters to a storage medium.</p> <p>☞ If necessary, re-start the device.</p>

**NOTE****Validity for associated certificate according to country settings**

With regard to the selection of country settings, KACO new energy attests:

1. that the relevant certificates are only valid if the corresponding country settings have been selected.
2. that all configured grid parameters must be configured in accordance with the requirements of the grid operators.
3. that the configuration of parameters using IEEE 1547: 2003 table 1 is possible but is only permitted if it is requested by the grid operators.

**NOTE****Validity of the setting values shown**

Setting values that follow the pictogram  only refer to the blueplanet 125 TL3/NX3 device type with the "user defined" country setting. For your device, refer to the slider on the web interface.

9.5 Monitoring the device



NOTE

Contents of the export file

Regardless of the display data selected in the "Select display" area, an export file always contains all measurement data and yield data available for the selected period.

9.6 Performing a firmware update



NOTE

Ensure DC power supply during initial start-up

The DC power supply must be guaranteed during initial start-up.¹³

The sequence of the settings required for initial start-up is pre-set in the configuration assistant.


CAUTION

Damage to the device from incorrect power supply

The update can fail if the power supply is interrupted during the update process. Parts of the software or of the device itself may be damaged.

1. Never disconnect the DC and AC power supply for or during a firmware update.
2. Do not remove the USB stick during a firmware update.

Preparing a firmware update

 Load the firmware update file via the network. (Not the USB port!)

⇒ Perform the firmware update.



NOTE

Observe waiting time for firmware update

The firmware update can take several minutes. The "Operating" LED flashes during the update process. The device may restart several times as required.

Performing a firmware update

You can upload the current firmware to the devices directly via the web interface. Refer to the menu items under "Firmware Update" See table : Configuration via web user interface [▶ Page 72]

The firmware can be found on the website kaco-newenergy.com under Downloads / Software.

There is the **option** of updating the firmware at the USB socket of the device. Observe the following procedure:

- ⊖ Ensure that the power supply is connected.
- ⊖ Pay attention to signal elements (LEDs) and statuses during the process.
- ⊖ Note the description of the LED states during the process. [See section 9.2▶ Page 45]

1. Load the firmware from the KACO website onto a FAT32-formatted USB stick.
2. Insert the USB stick into the USB port of the device.

⇒ The update process starts once the firmware has been validated and the status LEDs flash to indicate this.

3. Once the update has been successfully completed, all 3 LEDs light up briefly several times and the device restarts.
4. Remove the USB stick from the USB socket.
5. Checking the firmware version on the Info web interface. [See section 9.3▶ Page 48]
6. When an error occurs, the update process must be repeated.

⇒ Update process completed successfully.

¹³ It is only possible to configure the grid parameters with DC voltage. The further parameters can also be configured with a present AC voltage.

9.7 Access via Modbus



NOTE

Update rate of the Modbus measured values in parallel operation

The measured values provided via Modbus are transmitted with an update rate of approx. **1 second**. The values can also be filtered for stabilisation. This can result in a time delay compared to rapid changes in performance.

In **PV or storage systems with several inverters operated in parallel**, especially if control is only carried out at the **grid connection point**, this delay must be taken into account when designing the higher-level control system.

A suitable external measuring solution may need to be provided for highly dynamic control requirements.



NOTE

Required usage information for remote access

In order to make use of the Modbus functionality, we recommend using the "SunSpec-Modbus-Interface" specification we have made available for the firmware version installed on your device.

Follow the description in the document "Modbus-Protokol.pdf" in order to use the two Excel files with a high level of process reliability.

↻ Firmware version of device is identical to the specifications of the Sunspec® Modbus®.

↻ **NOTE: The device supports MODBUS/TCP and conventional SUNSPEC models. If there are concerns over security, write access can be deactivated.**

1. Enable the entry `Network - Modbus TCP - Operation mode / Network services - Modbus TCP - Operation mode` in the menu on the device or on the web interface.

2. If necessary, allow `write access`.

3. Set up the `Port` for access. [Default: 502]

⇒ Access via Modbus enabled.

10 Specifications

10.1 Reactive power control

Reactive power can be used in electrical energy supply networks to bolster the level of voltage. As such, feed-in inverters can contribute to statistical voltage stability. Reactive power brings about a voltage drop at the inductive and capacitive components of the equipment which can either bolster or reduce the level of voltage. If the generating plant draws inductive reactive power while active power is being fed in, part of the voltage swing caused by the active power feed can be compensated for by the supply of reactive power.

This reactive power mode and the respective control process are specified by the grid operator. If no control process has been specified, then the system should be operated using a reactive power specification of 0%.

10.1.1 Operating power range depending on grid voltage

The device can be operated within the respective fixed voltage range provided. The maximum apparent power is stated in the following table. In the event of undervoltage determined by the maximum continuous current subject to the grid voltage.

The following figures show the reactive power operating range subject to active power and the apparent power operating range depending on the grid voltage for various devices.

Maximum apparent power [p.u.]	blueplanet 100 NX3 M8 Voltage with U_N 380 V	blueplanet 125 NX3 M10 Voltage with U_N 380 V
1.0	≥ 317	≥ 397
0.95	301	377
0.90	286	357
0.85	270	337

Tab. 14: Maximum continuous apparent power depending on grid voltage




Fig. 67: P-Q operating range for bp 100 NX3 ($Q_{max}=S_{max}$)




Fig. 68: Apparent power depending on the grid voltage for blueplanet 100 NX3




Fig. 69: P-Q operating range for bp 125 NX3 ($Q_{max}=S_{max}$)




Fig. 70: Apparent power subject to the grid voltage for blueplanet 125 NX3

10.1.2 Dynamics and accuracy

In all control methods the specified target value at the inverter's connection terminals is adjusted using a stationary deviation of the reactive power of maximum 2% S_N . This maximum deviation always relates to the specified value as reactive power.

If the power factor $\cos \phi$ is specified in the control method, then the deviation relates to the reactive power value brought about by the current power level.


The transient response of the control methods is determined by a PT-1 filter. In this case, the settling time corresponds to 3 Tau, or in other words, achieving approx. 99% of the final value for a PT-1 filter. Subject to the control method selected, there are also other parameters that determine dynamic behaviour.

10.1.3 Reactive power functions

The following functions for controlling the reactive power are implemented in the devices listed above:

- $\cos \phi$ constant
- Q constant
- $\cos \phi$ (P)
- Q(P) 10 nodes
- Q(U) 10 nodes

NOTE: Reactive power is prioritised in the basic setting in all methods, but this can also be deactivated accordingly. The priority can be selected when using the Q const. and the Q(U) mode. The maximum possible active power that can be fed in is reduced in line with the P-Q operating range when the maximum grid power is reached.




Model	Parameter	Scaling factor	R/RW	Area	Description
126.	ModEna	ModEna	RW	 0 / 1	The reactive power method selected in the device can only be activated/deactivated indirectly via Sunspec.




cos ϕ constant

In $\cos \phi$ constant mode, the specified power factor is permanently set by the inverter. In doing so, the reactive power level is set in line with $Q=P \cdot \tan \phi$ as a function of the power that continuously generates the specified power factor. If the setting value is changed, the new value is adopted by way of a filter in a muted manner. The settling time can be parametrised and is 1 s (this corresponds to 5Tau (according to SunSpec, 3Tau would be ideal) with the transient response of a first order filter (PT-1) with a time constant of $\tau = 200$ ms. The specified power factor can be configured on the display or by way of communication via the KACO RS485 protocol and MODBUS/SunSpec.

If the applicable grid code stipulates that the $\cos \phi$ should react to the target value slower than the configured $\tau = 200$ ms by way of a defined gradient or settling time, this gradient or settling time must be implemented in the system control.





Model	Parameter	Scaling factor	R/RW	Area	Description
123.	OutPFSet cos-phi const.	OutPFSet_SF	RW	 1-0.3 [%]	Set the power factor to a certain % value.
123.	OutPFSet_RmpTms Power gradient increasing & power gradient decreasing		R	 1 – 65524 [% Slim / min]	Determines the dynamic behaviour in the event of a change in the $\cos \phi$ power factor. The power factor is changed with the specified gradient. Note: The gradient is overlaid with the settling time.
123.	OutPFSet_WinTms Settling time	VArPct_SF	RW	 1000 – 120000 [ms]	Set the settling time in the event of an abrupt change in the reactive power target value (e.g. caused by a voltage jump).
	Not implemented!				

Model	Parameter	Scaling factor	R/RW Area	Description
123.	OutPFSet_RvrtTms Timeout		RW  0 – 1000 [s]	<p>Specifies the time after which the inverter, if it does not receive a new power factor specification, reverts to the previously applicable reactive power procedure.</p> <p>If the <code>Timeout</code> is set to 0 seconds, the transmitted power factor specification is permanently retained, even in the event of a communication timeout.</p> <p>Note: when the device is restarted, the <code>timeout</code> is reset to the set fallback time.</p>

Q constant

In Q-constant mode, the specified reactive power value is permanently set by the inverter. If the constant is changed, the new value is adopted by way of a filter in a muted manner. The settling time and the gradient limitation can be configured on the web user interface. The settling time is 1 s with the transient response of a first-order filter (PT-1) with a time constant of $\tau = 200$ ms. The specified reactive power can be configured on the display or by way of communication via the KACO RS485 protocol and MODBUS/SunSpec.

If the applicable grid code stipulates that the reactive power should react to the target value slower than the configured $\tau = 200$ ms by way of a defined gradient or settling time, this gradient or settling time must be implemented in the system control.

Model	Parameter	Scaling factor	R/RW Area	Description
123.	VArWMaxPct Q constant	VArPct_SF	RW  0-100 [% _{pmax}]	The setpoint of the reactive power can be adjusted depending on the set maximum active power.
123.	VArPct_RvrtTms Timeout		RW  0 – 1000 [s]	<p>Specifies the time after which the inverter, if it does not receive a new reactive power specification, reverts to the previously applicable reactive power procedure.</p> <p>If the <code>Timeout</code> is set to 0 seconds, the transmitted reactive power specification is permanently retained, even in the event of a communication timeout.</p> <p>Note: when the device is restarted, the <code>timeout</code> is reset to the default value.</p>
123.	VArPct_RmpTms Output gradient increase & Output gradient limitation decrease		R  1 – 65524 [% Slim / min]	<p>Determines the dynamic behaviour in the event of a change in the reactive power value. The reactive power is changed with the specified gradient.</p> <p>Note: The gradient is overlaid with the settling time.</p>
123.	VArPct_RmpTms Settling time		RW  1000 – 120000 [ms]	<p>Determines the dynamic behaviour in the event of a change in the active power set value. The active power is changed according to a PT-1 characteristic curve with a settling time of 3 τ.</p> <p>NOTE: The settling time is overlaid with the increasing and decreasing gradient.</p>

$\cos \varphi(P)$

In the $\cos \varphi(P)$ operating mode, the setpoint value of $\cos \varphi$ and the setpoint for the reactive power derived from it are continuously calculated depending on the actual power level. This function ensures that grid support is provided by the reactive power when a significant voltage boost is anticipated due to a high feed level. In this case, a characteristic curve is specified which can be used to configure up to 10 nodes, value pairs for active power and $\cos \varphi$. The active power is entered as a % in relation to the set maximum apparent power Slim. Other parameters allow you to limit functionality and to limit activation to certain voltage ranges.




Fig. 71: $\cos \varphi(P)$ standard characteristic curve with 3 nodes

Q(U) 10 nodes

When it comes to mode Q(U), the nominal value of the reactive power is continuously calculated depending on the grid voltage. This function ensures that grid support is provided by the reactive power as soon as the voltage actually deviates from the target voltage. In this case, a characteristic curve is specified which can be used to configure up to 10 nodes, consisting of value pairs for voltage and reactive power. Other parameters allow you to limit functionality and to limit activation to certain voltage ranges as well as parametrise the transient response.

The zero sequence voltage is used to calculate the reactive power target for three-phase units.




Fig. 72: Q(U) standard characteristic curve with 5 nodes

Q(P) 10 nodes

When it comes to mode Q(P), the nominal value of the reactive power is continuously calculated depending on the active power. In this mode, a characteristic curve is specified which can be used to configure up to 10 nodes, consisting of value pairs for power and reactive power. The function enables the transient response to be parametrised.

The zero sequence power is used to calculate the reactive power target for three-phase units.





























































Fig. 73: Q(P) standard characteristic curve with 5 nodes

10.1.4 Parameters for reactive power control

Country-spec. Settings	Menu u level	Display/ Setting	Action in this menu/meaning
		Mode	Select the active method for reactive power control and define the parameters in the respective method.
		☰ Specification cos-phi Specification Q Cos-phi(P/Plim) Q(U) Q(P)	
		Cos-phi constant	
		Cos-phi constant	Specified power factor.
		⚙️ 0,3 – 1 / ⚙️ 1 / 🏠 0,001	
		☰ Overexcited under-excited	Reactive power mode: Under-excited relates to inductive load, over-excited relates to capacitive load.
		Power gradient increasing & power gradient decreasing	Maximum change in the reactive power %P _{lim} /min in the event of a change to overexcited mode. NOTE: The gradient is overlaid with the settling time.
		⚙️ 1 – 65534 [% P _{lim} /min] / ⚙️ 65534 [% P _{lim} /min] / 🏠 1	
		Settling time	Determines the dynamic behaviour in the event of a change in the cos φ set value. With a reactive power change, the cos φ is changed according to a PT-1 characteristic curve with a settling time of 3 Tau.
		⚙️ 1000 – 120000 [ms] / ⚙️ 1000 [ms] / 🏠 10	
		Q constant	
		Q constant	Set as a percentage of the maximum reactive power.
		⚙️ 0 – 100 [% Slim] / ⚙️ 0 [% Slim] / 🏠 0.1	
		☰ Underexcited over-excited	Reactive power mode: Under-excited relates to inductive load, over-excited relates to capacitive load.

Country-spec. Men Settings	Display/ u Setting level	Action in this menu/meaning
	Output gradient limitation increase & Output gradient limitation decrease  increasing decreasing  1 – 65534 [% P _{lim} /min] /  65534 [% P _{lim} /min] /  1	In addition to configuring the dynamic behaviour using the setting time corresponding to a first-order filter, the reactive power setting can be determined by a maximum gradient – this means the maximum change in the reactive power per time period. Maximum change in the reactive power %P _{lim} /min in the event of a change to overexcited mode NOTE: The gradient is overlaid with the settling time.
	Settling time  1000 – 120000 [ms] /  1000 [ms] /  10	Determines the dynamic behaviour in the event of a change in the Q target value. With a change of the reactive power or the lock-in and lock out voltage, the Q is changed according to a PT-1 characteristic curve with a settling time of 3 Tau.
Cos-phi(P)		
	Lock-in voltage 10 – 126.6 [% Unom] /  80 [% Unom] /  1 [0.1]	The control is activated above this voltage.
	Lock-out voltage  10 – 126.6 [% Unom] /  80 [%Unom] /  0.1	The control is deactivated below this voltage.
	Power gradient increasing & power gradient decreasing  1 – 65534 [% P _{lim} /min] /  65534 [% P _{lim} /min] /  1	Maximum change in the reactive power %P _{lim} /min in the event of a change to overexcited mode. NOTE: The gradient is overlaid with the settling time.
	Settling time  1000 – 120000 [ms] /  5000 [ms]  10	Determines the dynamic behaviour in the event of a change in the cos φ set value. With a change of the active power or the lock-in and lock out voltage, the cos φ is changed according to a PT-1 characteristic curve with a settling time of 3 Tau.
	Number of nodes  2 – 10	Specify the number of nodes for the cos φ/(p/pn) characteristic curve.
	1st node ... 10th node  0V - Max. voltage in continuous operation	Power of the node as a percentage of the maximum power. For the 1st node, the power must be 0%; for the last node, the power must be 100%. The power values of the nodes must increase continuously. Note: Storage inverters only for feed-in operation
	 1 – 0,3 /  1 /  0.001	Reactive power of the node as a percentage of the maximum power.
	 Overexcited underexcited	Reactive power mode: Under-excited relates to inductive load, over-excited relates to capacitive load.
Q(P) 10 nodes		

Country-spec. Settings	Menu level	Display/Setting	Action in this menu/meaning
		Power gradient increasing & power gradient decreasing ⚙️ 1 – 65,534 [% S _{lim} /min] / ⚙️ 65,534 [% S _{lim} /min] / 📏 1	The rate of change of the output when the output power is increased is limited by the configured value. The rate of change of the output when the output power is decreased is limited to the configured value. NOTE: The gradient is overlaid with the settling time.
		Settling time ⚙️ 200 – 60000 [ms] / ⚙️ 6000 [ms] 📏 1	Sets the dynamic behaviour in the event of a change in the Q target value. With a change in the active power, the Q target value is changed according to a PT-1 characteristic curve with a settling time of 3 Tau.
		Number of nodes ⚙️ 2 – 10	Specify the number of nodes for the Q(P) characteristic curve.
		1st node ... 10th node ⚙️ 0V - Max. voltage in continuous operation	Power of the node as a percentage of the maximum power. For the 1st node, the power must be 0%; for the last node, the power must be 100%. The power values of the nodes must increase continuously. Note: Storage inverters only for feed-in operation
		⚙️ 1 – 0,3 / ⚙️ 1 / 📏 0.001	Reactive power of the node as a percentage of the maximum power.
		⚙️ Overexcited underexcited	Reactive power mode: Under-excited relates to inductive load, over-excited relates to capacitive load.
		Q(U) 10 nodes	
		Lock-in power ⚙️ 0 – 100 [% S _{lim}] / ⚙️ 20 [% S _{lim}] / 📏 1	Power threshold, function is activated if limit value is exceeded.
		Lock-out power ⚙️ 0 – 100 [% S _n] / ⚙️ 5 [% S _n] / 📏 1	Power threshold, function is activated if limit value is undershot.
		Lock-in time ⚙️ 0 – 60000 [ms] / ⚙️ 30000 [ms] / 📏 1000 [ms]	Length of time that the active power must remain below the lock-in power level before control is deactivated.
		Lock-out time ⚙️ 0 – 60000 [ms] / ⚙️ 30000 [ms] / 📏 1000 [ms]	Length of time that the active power must remain below the lock-out power level before control is deactivated.
		Downtime ⚙️ 0-10000 [ms] / ⚙️ 0 [ms] / 📏 1	If the voltage switches from a characteristic curve section with Q=0 to a characteristic curve section with Q≠0 under active control, then the reactive power setting process is delayed by the set dead time. Once the dead time has expired, the control circuit is no longer subject to a delay and the set setting time determines the transient behaviour.

Country-spec. Menu Settings	Display/Setting level	Action in this menu/meaning
	Output gradient limitation increase & Output gradient limitation decrease  increasing decreasing  1 – 65534 [% P _{lim} /min] /  65534 [% P _{lim} /min] /  1	In addition to configuring the dynamic behaviour using the setting time corresponding to a first-order filter, the reactive power setting can be determined by a maximum gradient – this means the maximum change in the reactive power per time period. Maximum change in the reactive power %P _{lim} /min in the event of a change to overexcited mode NOTE: The gradient is overlaid with the settling time.
	Settling time  1000 – 120000 [ms] /  2000 [ms]  10	Settling time in the event of an abrupt change in the reactive power target value (e.g. caused by a voltage jump). The transient behaviour corresponds to a first-order filter (PT-1) with setting time = 3 Tau. NOTE: The settling time is overlaid with the increasing and decreasing gradient.
	Min. cos-phi Q1 - Min. cos-phi Q4  0 – 1 /  0 /  0,001	In the event of a significant voltage deviation, the maximum reactive power adjustment range can be limited by a minimum cos φ in order to prevent an excessive reactive power supply and, as a result, a significant reduction in the maximum active power that can be fed in.
	Q1	Minimum cos φ in overexcited operating mode (in-feed).
	Q4	Minimum cos φ in underexcited operating mode (in-feed).
	Q2	Minimum cos φ in overexcited operating mode (charge).
	Q3	Minimum cos φ in underexcited operating mode (charge).
	Voltage dead band  0 – 5 [% Uref]  0.0  0.1	The control is activated above this voltage.
	Q(U) Offset (temporary) U offset  -100 -100 [% Slim] /  0.0 [%Slim] /  0.1 Q offset  -100 -100 [% Slim] /  0.0 [%Slim] /  0.1	Power threshold, function is activated if limit value is exceeded.
	 Q minimum  0 – 100 [% Slim] /  0 [% Slim] /  0.1  Underexcited overexcited	 Set the reactive power Q to a minimum value.  Select the type of phase shift. NOTE: Underexcited relates to inductive load, overexcited relates to capacitive load.
	 Q maximum  0 – 100 [% Slim] /  0 [% Slim] /  0.1  Underexcited overexcited	 Set the reactive power Q to a maximum value.  Select the type of phase shift. NOTE: Underexcited relates to inductive load, overexcited relates to capacitive load.

Country-spec. Settings	Menu Display/ Setting level	Action in this menu/meaning
US, UD	Autonomous adjustment Vref	The autonomous adjustment of the reference voltage enables a dynamic reactive power function. As a result, the reference voltage of the Q(U) characteristic curve is dynamically adjusted to the grid voltage via a PT1 filter.
US, UD	Time constant setting Vref ⚙️ 300 – 5000 [s] • 300 s	The time constant defines the control speed at which the reference voltage of the Q(U) characteristic curve is equalised to the grid voltage.
	Priority mode ☰ Q-priority P-priority	P-priority can be selected as an alternative to the standard setting Q-priority. When it comes to P-priority, the reactive power adjustment range is limited subject to the limited apparent power of the inverter and the active power that is currently available and fed in.
	Active curve ⚙️ 1 – 4 / curve 1 TMP / curve 2 / curve 3 / curve 4	Up to four characteristic curves can be configured independently and one of them can be activated for regulation each time.
	Number of nodes ⚙️ 2 – 10	Specify the number of nodes for the Q(U) characteristic curve.
	1st node ... 10th node ☰ Power Voltage Excitation ⚙️ 0 – 100 [% S _{lim}] / • 43.6 [% S _{lim}] / 📏 0.1	Power of the node as a percentage of the maximum power. For the 1st node, the power must be 0%; for the last node, the power must be 100%. The power values of the nodes must increase continuously.
	☰ Power Voltage Excitation ⚙️ 0 – 125 [% S _{lim}] / • 43.6 [% U _{nom}] / 📏 0.1	Voltage of the node in volts The voltage values of the nodes must increase continuously. At voltages below the 1st node and voltages above the last node, the reactive power value of the 1st or last node is used each time.
	☰ Power Voltage Excitation ⚙️ Overexcited underexcited	Reactive power mode: Under-excited relates to inductive load, over-excited relates to capacitive load.

10.2 Active power regulation

Dynamics / accuracy

In all of the control methods described below the specified target value at the inverter's connection terminals is adjusted using a stationary deviation of the reactive power of maximum 2% S_N.

The transient response of the control methods is determined by a PT-1 filter. In this case, the settling time corresponds to 3 Tau, or in other words, achieving approx. 99% of the final value for a PT-1 filter. Subject to the control method selected, there are also other parameters that determine dynamic behaviour.

Methods for active power regulation

Methods for regulating the active power of feed-in inverters may be necessary for local management of load flows, for voltage stability in the distribution network and for ensuring the stability of the interconnected grid.

The device makes use of the following functions in order to regulate the active power. These are described in the following section:

- P target value (MPPT(communication)) [See section 10.2.1 ▶ Page 86]
- P limit (communication) [See section 10.2.2 ▶ Page 86]
- P(U) (characteristic curve) [See section 10.2.3 ▶ Page 86]
- P(f) (characteristic curve) [See section 10.2.4 ▶ Page 88]

10.2.1 P target value

The function "P target value" is integrated into the MPP tracking of the inverter on all PV inverters. The P target value is continuously re-calculated on the basis of the MPP tracking algorithm.




The model 704 (DER AC Controls) also fulfils the current market requirements.

10.2.2 P limit

The function "P limit" is available for limiting the maximum feed-in power. If necessary, this can be used to reduce the maximum possible feed of an inverter, e.g. for managing bottlenecks for the operator of the distribution grid.

P limit is only available via the MODBUS/SunSpec inverter model 123 *Immediate Inverter Controls* and via RS485 communication. You can find detailed information on the communication protocol at www.kaco-newenergy.de in the "Software" subsection of the "Downloads" section.

When a target value is received for P limit, the output power of the inverter is limited to the specified power value. If the limit value is changed, the new value is adopted by way of a filter and a gradient limitation. The current power may be below the specified limit value because the available power (PV) or the target power value (storage) may be below the specified limit value. Depending on the inverter series, the settling time and gradient limitation may be adjustable.

Model	Parameter	Scaling factor	R/RW	Area	Description
123	WMaxLimPct Power Limitation	WMaxLimPct_SF	RW	 0 – 100 [%]	Set the power limitation to a certain % value.
123	WMaxLimPct_RvrtTms Timeout		RW	 0 – 1000 [s]	Specifies the time after which the inverter, if it does not receive a new power limitation, will cancel it. If the <i>Timeout</i> is set to 0 seconds, the transmitted power limitation is permanently retained, even in the event of a communication timeout. <i>Note:</i> when the device is restarted, the <i>timeout</i> is reset to the default value.
123	WMaxLimPct_RmpTms Output gradient limitation increase		RW	 1 – 65534 [% S _{lim} /min]	Determines the dynamic behaviour in the event of a change in the active power set value. The active power is changed with the specified gradient. NOTE: The gradient is overlaid with the settling time.

If the applicable grid connection guidelines call for the active power to be adjusted to the target value with a defined gradient or a defined settling time, then the device can be configured in such a way that this gradient is adhered to. In addition, the gradient can also be implemented on the plant controller. This second solution is to be used for all other inverters.

10.2.3 Voltage-dependent power reduction P(U)

If it is not possible to compensate adequately for increase in voltage in the upstream distribution network by intake on reactive power, it may be necessary to curtail the active power. In this case, P(U) control is available for making optimum use of the capacity of the upstream grid.

P(U) control reduces the active power that is fed in as a function of the grid voltage using a prescribed characteristic curve as a basis. P(U) control is implemented as an absolute power limit. The actual power of the inverter may vary freely below this limit due to a possible fluctuation in the available power or the target value, but at no time increases above the absolute power limit.

[See figure 74 [▶ Page 87] and [See figure 75 [▶ Page 87] are two examples of configuration. In figure 1 without hysteresis, the function is activated as soon as the voltage exceeds the configured voltage of data point 1 (dp1). The power limit follows the characteristic curve, a straight line between dp1 and dp2. The function is deactivated as soon as the voltage falls below dp1. In [See figure 75 [▶ Page 87], the function is activated as soon as the voltage exceeds the configured voltage of dp2. In this case, dp1 does not result in activation of the function because the power limit remains at 100%.

The power limit follows the characteristic curve, a straight line between dp2 and dp3. However, because hysteresis is activated, the power limit is not increased when the voltage drops. The function is deactivated as soon as the voltage falls below dp1.




Fig. 74: Example characteristic curve without hysteresis




















Fig. 75: Example characteristic curve with hysteresis and a deactivation threshold below the activation threshold

10.2.3.1 Parameters for P(U)

Country-spec. Settings	Men u Display/ Setting level	Action in this menu/meaning
	Operation mode <input type="checkbox"/> Off <input checked="" type="checkbox"/> On	<input checked="" type="checkbox"/> Activate the control process. <input type="checkbox"/> Off: Deactivates dynamic grid support using dynamic reactive current. Dynamic grid support remains active on account of immunity to interference.
	Reference power <input type="checkbox"/> Instantaneous power <input checked="" type="checkbox"/> Nominal power	Specifies the power reference for the characteristic curve. 100 % here corresponds to the nominal power or the actual power at the time the function was activated, the time when the voltage passes the configured node.
	Rated voltage <input type="checkbox"/> Maximum phase voltage <input checked="" type="checkbox"/> Positive sequence voltage	<input checked="" type="checkbox"/> Select the voltage to be rated. Specifies which voltage is evaluated in a three-phase system.
	Hysteresis mode <input type="checkbox"/> Off <input checked="" type="checkbox"/> On	Off: In non-hysteresis mode, the active power is increased immediately with dropping voltage. On: In hysteresis mode, the power is not increased with dropping voltage.
	Deactivation gradient <input checked="" type="radio"/> 0 – 65534 [% / min] / <input type="radio"/> 100 [% / min] / <input type="radio"/> 1	If the available power is above the actual output at the time of deactivation, the power increase back to the maximum power is limited. The limitation is implemented by an absolute power limitation that increases with a continuous gradient up to the maximum power. The actual power of the inverter may vary freely below this limit due to a possible fluctuation in the available power or the target value, but at no time increases above the absolute power limit.
	Deactivation time <input checked="" type="radio"/> 0 – 60000000 [ms] / <input type="radio"/> 100 [ms] / <input type="radio"/> 1	Only evaluated with activated hysteresis mode: Monitoring time during which the voltage must remain below the lowest configured node before the function is deactivated.

Country-spec. Men Settings	Display/ u Setting level	Action in this menu/meaning
	Output gradient limita- tion increase & Output gradient limitation de- crease  1 – 65534 [% / min] /  65534 [% / min] /  1	Specifies the dynamic response on changing the active power for power increase. With a voltage change, the active power is changed with the specified gradient. The gradient is overlaid with the settling time. Specifies the dynamic response on changing the active power for power decrease. With a voltage change, the active power is changed with the specified gradient. The gradient is overlaid with the settling time.
	Settling time  1000 – 120000 [ms] /  2000 [ms] /  10 [ms]	Determines the dynamic behaviour in the event of a change in the active power set value. With a voltage change, the active power is changed according to a PT-1 characteristic curve with a settling time of 3 Tau. Note: The settling time is overlaid with the increasing and decreas- ing gradient.
	Active curve  1 - 5	 Select active curve. NOTE: Up to 5 characteristic curves can be configured independ- ently and one of them can be activated for regulation each time.
	Number of nodes  2 - 5 Power  0.0 – 100.0 [% P _{ref}] /  100.0 [% P _{ref}] /  0.1 Voltage  80.0 – 126.0 [% U _{nom}] /  112.0 [% U _{nom}] /  0.1	up to 5 support points definable The power value of the first and last value pair is also used as the maximum or minimum active power value that is valid across the limits of the characteristic curve.

10.2.4 P(f)

Adjusting the active power P(f) in the event of overfrequency

Feed-in inverters must assist with frequency stability in the grid. If the grid frequency leaves the normal tolerance range (e.g. ±200 mHz), then the grid will be in a critical state. In the event of overfrequency, there is a generation surplus, in the event of underfrequency, there is a generation deficit.

PV systems must adapt their feed-in power relative to the frequency deviation. In the event of overfrequency, the power adjustment is determined by a maximum feed-in limit. The actual power of the inverter may vary freely below this limit due to a possible fluctuation in the available power or the target value, but at no time increases above the absolute power limit.

$$P_{max-limit} = P_M + \Delta P$$

Fig. 76: Equation 1

$$\Delta P = g \cdot P_{ref} \cdot (f_1 - f)$$

Fig. 77: Equation 2

Equation 1 [See figure 76 ▶ Page 88] defines the maximum limit with ΔP according to Equation 2 [See figure 77 ▶ Page 88], P_M the actual power at the moment of activation and P_{ref} the reference power. In the case of PV inverters from KACO, P_{ref} is defined as P_M , the current power at the time of activation. f is the current frequency and f_1 is the specified activation threshold.

$$\Delta P = \frac{1}{s} \times \frac{(f_1 - f)}{fn} \times Pref$$

Fig. 78: Equation 3

$$g = \frac{1}{s \cdot f_n}$$

Fig. 79: Equation 4

In some standards, the power adjustment is specified by a drop (s) instead of a gradient (g), as shown in equation 3 [See figure 78 ▶ Page 89]. The drop s can be transformed into a gradient g in accordance with equation 4 [See figure 79 ▶ Page 89].

The frequency f remains above the activation threshold f_1 during an overfrequency incident. Consequently, the expression $(f_1 - f)$ is negative and ΔP corresponds to a reduction in the feed-in power.

The measurement accuracy of the frequency is greater than 10 mHz.

The specific mode of operation of the function is specified by the grid operator or the pertinent standards or the grid connection guidelines. The configurability of the function makes it possible to satisfy a wide variety of standards and guidelines. Certain configuration options are not available in some country settings because the pertinent standards or grid connection guidelines prohibit adjustments.

Adjusting the active power P(f) in the event of underfrequency

Some grid connection guidelines also require adjustment of the active power P(f) in the event of underfrequency. Due to the fact that PV systems are typically run at the maximum power point, there are no power reserves for increasing the power in the event of underfrequency.

However, in the event that the system power is reduced due to market regulation, it is possible to increase the active power up to the power level available. Because the inverter is unable to distinguish between P constant target values for obligatory bottleneck management by the grid operator and for market regulation, this needs to be implemented in the site-specific infrastructure of system control.




Fig. 80: Example behaviour with hysteresis (mode 1)















































Fig. 81: Example behaviour without hysteresis (mode 2)

10.2.4.1 Parameters for P(f)

Country-spec. Settings	Menu	Display/Setting level	Action in this menu/meaning
		P(f) operation mode  Off Mode 1 Mode 2 Mode 3	Activate or deactivate function. Mode 1: With hysteresis activated – Limit Mode 2: Without hysteresis activated – Limit NOTE: In mode 1 & 2, the power below or above the characteristic curve (depending on over- or underfrequency) is adjusted via a Pset command. Plim can also limit the power with an active P(f) characteristic curve. Mode 3: Without hysteresis activated – Set NOTE: In mode 3, the pre-fault power is stored and the power moves along this characteristic curve.
		 Dynamic gradient mode  On Off	 Activate dynamic gradient. NOTE: Gradient "Feed-in/charging with over/under frequency" is not displayed.
		Maximum dynamic gradient frequency  50.22 – 70.5 [Hz]  0.01 [Hz]	Dynamic gradient maximum frequency: If dynamic gradient mode is activated, the gradient is calculated in order to guarantee a linear power adjustment and reach the maximum charging power if the frequency rises to the maximum configured frequency.
		Minimum dynamic gradient frequency  45 – 50 [Hz]  0.01 [Hz]	Dynamic gradient minimum frequency: If dynamic gradient mode is activated, the gradient is calculated in order to guarantee a linear power adjustment and reach the maximum feed-in power if the frequency drops to the minimum configured frequency.
		Activation threshold at underfrequency  40 – 50 [Hz] /  40 [Hz] /  0.01	Activation threshold (f1) underfrequency: Determines the frequency threshold for activating the function in case of underfrequency incidents. The active power adjustment is activated if the frequency falls below the configured value and mode 1 or 2 is activated.
		Activation threshold at overfrequency  50 – 60 [Hz] /  50.02 [Hz] /  0.01	In mode 2, the function is deactivated if the frequency rises above the configured value. Activation threshold (f1) overfrequency: Determines the frequency threshold for activating the function in case of overfrequency incidents. The active power adjustment is activated if the frequency rises above the configured value and mode 1 or 2 is activated.
		Threshold Area lower limit [Hz]  40 – 50 [Hz] /  47.5 [Hz] /  0.01	Only evaluated in mode 1. The function is deactivated if the frequency returns to the deactivation range and remains in this range for the duration of the deactivation time.
		Threshold Area upper limit [Hz]  50 – 60 [Hz] /  50.5 [%/Hz] /  0.01	

Country-spec. Settings	Menu	Display/Setting level	Action in this menu/meaning
		P(f) deactivation time  0 – 6000000 [ms] /  0 [ms] /  1	Only evaluated in mode 1. The function is deactivated if the frequency returns to the range between the minimum and maximum deactivation threshold and remains in this range for the duration of the deactivation time.
		Deact. Limitation time after fault  0 – 1000 [s] /  0 [ms] /  1000 [s]	Only evaluated in mode 2&3. After the end of the fault, the change in active power is limited to the set gradient for the specified time.
		Deactivation gradient increase after fault & Deactivation gradient decrease after fault  0 – 65534 [% / min] /  10 [% / min] /  1	 Specifies the dynamic response on changing the active power for power increase and power decrease. Any change in active power is limited to the set value for the set duration.
		P(f) intentional delay  0 – 5000 [ms] /  0 [ms] /  1	The activation of the function based on the activation threshold is delayed by the configured time. Note 1: This function is regarded as critical for the stability of the transmission grid and is therefore prohibited by several national grid connection regulations. Note 2: This function is stipulated as a requirement by some domestic grid connection directives in order to prevent any negative impact on island detection. However, P(f) has no negative impact on KACO's enhanced island detection.
		P(f) settling time  200 – 2,000 [ms] /  200 [ms] /  1	Determines the dynamic behaviour in the event of a change in the active power limit. In the event of a change in frequency, the active power is altered subject to a PT-1 characteristic curve using a settling time of 3 Tau. The settling time is overlaid with the increasing and decreasing gradient.
		Output gradient limitation increase & Output gradient limitation decrease  0 – 65534 [% / min] /  65534 [% / min] /  1	 Specifies the dynamic response on changing the active power for power increase and decrease. With a voltage change, the active power is changed with the specified gradient. Note: The gradient is overlaid with the settling time.
		P(f) deactivation gradient  0 – 65534 [%S _{max} / min] /  10 [% S _{max} / min] /  1	If the available power is above the actual output at the time of deactivation, the power increase back to the maximum power is limited. The limitation is implemented by an absolute power limitation that increases with a continuous gradient up to the maximum power. The actual power of the inverter may vary freely below this limit due to a possible fluctuation in the available power or the target value, but at no time increases above the absolute power limit.

10.3 FRT

Dynamic grid support (Fault Ride Through)

A generation plant's ability to remain immune to voltage drops and voltage spikes in the supply system is a key element in establishing a reliable energy supply. Immunity to interference ensures that brief disruptions do not result in a loss of generation capacity in a larger range of an interconnected grid. Grid support by a fast feeding of residual current also limits the spatial extent of the incident.

With its dynamic grid support by way of immunity, the device has this characteristic. The ability to remain on the grid is particularly relevant. The protective settings also determine the device's ability to remain on the grid or not. Protective settings take the upper hand over the capacity of immunity to interference.

10.3.1 Dynamic grid support by way of immunity to interference

Interference immunity against undervoltage

Voltage drop above the limit curve (see figure below) can be overcome without the need for shutdown from the grid. The feed-in power remains constantly within the limits of the maximum continuous current of the inverter.

If a reduction in power occurs, the power is brought back up to the pre-fault level within 100 ms of the voltage returning.

The inverters can ride through voltage fluctuations as long as the voltage level does not remain above the continuous operating voltage range for more than 100 s and does not exceed the short-term maximum operating voltage range (up to 100 s). The specific values for each inverter can be found here.

The interface protection (voltage, frequency, anti-islanding) integrated in the inverter can be set within a range that permits the above behaviour. However, if the interface protection setting limits the voltage-time characteristic curve, then the interface protection will trip and interrupt the ride-through as configured.




Fig. 82: Immunity to interference characteristic curve relative to the nominal voltage

10.3.2 Dynamic grid support using a fast feeding of residual current

When dynamic grid support using a fast feeding of residual current is activated, then residual current is fed in in addition to the immunity to interference properties against drops and spikes described above.

The inverter adapts its current feed as soon as a drop or spike incident occurs in order to bolster the grid voltage. The support takes place in the event of voltage drop in the form of overexcited reactive current (corresponds to a capacitive load), in the event of voltage spike in the form of overexcited reactive current (corresponds to an inductive load). In the reactive current priority mode, the effective current is reduced to the extent necessary to comply with the limits of the maximum continuous current of the inverter.

A dip or swell is detected if either the normal operating voltage range setting is exceeded by at least one phase-phase or phase-PE voltage, or if a voltage jump in the positive or negative sequence component greater than the dead band setting occurs. The magnitude of the voltage jump of the positive and negative sequence component corresponds to the difference between the pre-fault voltage and the actual voltage based on the reference voltage. The pre-fault voltage is calculated as a 50-periods mean value.

The reactive current is adapted using a response time of <20 ms and a setting time of <60 ms after the incident has occurred. Responses to changes in the voltage during the incident or to the voltage recovery at the end of the incident take place with the same dynamic.











The formula for calculating the dynamic reactive current that is fed for the positive or negative phase sequence voltage is:
























For the positive and negative phase sequence voltage, Δu equates to the difference between the pre-fault voltage and the current voltage based on the max. reference voltage. The pre-fault voltage is calculated as a 1-min mean value.















On account of the definition of a voltage jump in EN 50549-2 and in VDE-AR-N 4120 and VDE-AR-N 4110, it is typically the case that another voltage jump is detected when the incident is at an end, when the fault is rectified and when the voltage returns to a normal state. The result of this is that in an active operation mode a dynamic grid support using a fast feeding of residual current remains active even after the incident has passed and that reactive current is fed in according to the formulae (2) and (3). Dynamic grid support using fast feeding of residual current is then deactivated after a configured minimum support time, usually 5 s.

If the zero current threshold is exceeded, the inverter stops feeding current into the grid. If the inverter feeds in reactive power before the fault occurs, the reactive power is reset to the value prior to the fault Q after the fault has ended using the settling time set in the activated reactive power control mode.

10.3.3 Parameters for FRT

Country-spec. Settings	Menu level	Display/Setting	Action in this menu/meaning
		 FRT (Fault Ride Through)	NOTE: The device supports dynamic grid stabilization. More detailed information at: [See section 10.3 ▶ Page 91]
		 Operation mode – On Off Settings Manual Pre-defined zero current	Setting: Manual All parameters can be configured independently. Setting: Predefined zero current Dynamic grid support active on account of immunity to interference and zero current feed-in. During a voltage incident, the current in the inverter is reduced to zero. All parameters are pre-configured, only the activation threshold for zero current has to be configured.
		Priority – Reactive current limitation Dynamic reactive current	Priority: Reactive current priority Dynamic grid support active on account of immunity to interference and fast feeding of residual current. The inverter feeds additional reactive current according to the formulae (2) and (4). Priority: Effective current priority Dynamic grid support active on account of immunity to interference and fast feeding of active current with dynamic reactive current. The inverter feeds in as much active power as available. If, as a result of this, the maximum continuous current is not achieved, the inverter supplies additional reactive current according to the formulae (2) and (4) up to the limit of continuous current.
		Zero current under-voltage threshold Zero current threshold over voltage  0 – 184 V / 253 – 340 V /  1	If one or more phase/phase or phase/neutral conductor voltages move above the configured threshold, the inverter changes to zero current mode. The total current is regulated to virtually zero.
		Zero current under-voltage threshold Zero current threshold over voltage  0 – 80 [% Unom] /  10 [% Unom] /  0.1  108 – 129 [% Unom] /   125 [% Unom] /  0.1	If one or more phase/phase or phase/neutral conductor voltages move above the configured threshold, the inverter changes to zero current mode. The total current is regulated to virtually zero.

Country-spec. Settings	Menu Display/ Setting level	Action in this menu/meaning
	Reference voltage  80 – 110 [% Unom] /  100 [% Unom] /  0.1 [Unom]	Nominal value of the phase/neutral conductor voltage used as a reference voltage for formula (1) and (3). Adjustable in the range from level 1 undervoltage protection to level 1 overvoltage protection.
	Constant K negative sequence dip Constant K negative sequence swell  k 0 – 10 /  2 /  0.1	Amplification factor for the negative sequence used in the calculation of the reactive current using formulae (2) and (4). Can be configured independently for drops and spikes.
	Constant K positive sequence dip & Constant K positive sequence swell  k 0 – 10 /  2 /  0.1	Amplification factor for the negative sequence used in the calculation of the reactive current using formulae (2) and (4). Can be configured independently for drops and spikes.
	Dead band  2 – 120 [% Uref] /  10.0 [% Uref] /  0.1	Dynamic grid support through fast feeding of residual current activated in the case of voltage events with a voltage change greater than the dead band.
	Reference voltage 80 – 110.0 [% Unom] /  100 [% Unom] /  0.1 & Minimum operating voltage activation 45 – 125.0 [% Unom] /  80 [% Unom] /  0.1 & Maximum operating voltage activation 45 – 125.0 [% Unom]  80 [% Unom] /  0.1	Dynamic grid support via fast feeding of residual current is activated on voltage events with at least one phase/phase or phase/neutral conductor voltage outside the configured normal operating voltage range. Dynamic grid support via fast feeding of residual current is deactivated when the voltage returns to the reference operating voltage range.
	Minimum operating voltage deactivation  0 – max [V]  1 [V] & Maximum operating voltage deactivation  0 – max [V]  1 [V]	Dynamic grid support via fast feeding of residual current is deactivated when the voltage is within the configured deactivation range. This parameter is only available for the country settings VDE 4105, CH 4105 and UD.
	Dynamic reactive current only  Off On	<p>Standard: The reactive current according to the formulae (2) and (4) is fed as additional reactive current. This means that sum of the pre-fault and additional reactive current is fed in.</p> <p>Only dynamic: The reactive current according to the formulae (2) and (4) is fed in as absolute reactive current. This means that regardless of the reactive current before the voltage event, only the reactive current according to the formulae (2) and (4) is fed in during the voltage event.</p>

Country-spec. Men Settings	Display/ u Setting level	Action in this menu/meaning
	Dead band mode Mode 1 Mode 2	<p>Mode 1: When calculating the reactive current, the value of the dead band is not subtracted from the amount of voltage change. As such, formula (2) applies to overvoltage and undervoltage incidents.</p> <p>Mode 2: When calculating the reactive current, the value of the dead band is subtracted from the amount of voltage change. For overvoltage and undervoltage events, formula (4) therefore applies:</p> $I = (\Delta u_1 - tb) * k * I_{max}$
	Minimum operating voltage activation  104 – 248 [V]  1 [V] & Maximum operating voltage activation  104 – 288 [V]  1 [V]	Dynamic grid support via fast feeding of residual current is activated on voltage events with at least one phase/phase or phase/neutral conductor voltage outside the configured normal operating voltage range. Dynamic grid support via fast feeding ore residual current is deactivated when the voltage returns to the normal operating voltage range.
	Reactive current limitation  0 – 100 [% I _{max}] /  100 [% I _{max}] /  1	The reactive power component of the fast feeding of residual current is limited to permit a defined proportion of active power components.
	Minimum support time  1000 – 15000 [ms] /  5000 [ms]  10	If due to a voltage jump in accordance with formula (1) and the configured dead band is activated, the dynamic grid support is deactivated via fast feeding of residual current after the minimum support time elapses.
IL_L, IL-MV and UD.	Deactivation delay   0 [ms] / 0 – 500 [ms] IL_LV / UD /  500 [ms] IL-MV /  1	Deactivates the dynamic power support after the desired delay as soon as the voltage returns to the normal operating range. This parameter is only available for the country settings IL_LV, IL-MV and UD.

10.4 Other grid-supporting functions that are effective in the case of active power

10.4.1 Permanent power gradient limitation

The maximum active and apparent power to be installed for a generation plant is agreed between the grid operator and plant operator. The device capacity of a plant can be set to the exact agreed value using the S_{lim} and P_{lim} settings. To ensure that the load on the devices in the plant is uniform, we recommend distributing the performance reduction evenly across all devices.

Some grid connection rules insist that the agreed reactive power be supplied from every operating point of the plant without a reduction in the actual active power. Because KACO devices have the full P-Q operating range, a reduction in the active power is, however, required during operation at maximum active power because an apparent power reserve is not available. By adjusting P_{lim} , the maximum active power can be restricted in order to establish an apparent power reserve and ensure that the agreed reactive power can be delivered from any active power operating point. The graphic [See figure 83 [► Page 96] shows the appropriate P-Q operating range with a required example active power of 48% of the maximum apparent power of the plant or 43% of the maximum active power of the plant.




Fig. 83: P-Q operating range with limited active power ($Q_{max}=S_{max} \neq P_{max}$) for PV inverters

The power reduction parameters can be adjusted in SunSpec model DID123. During this process, you should also check whether internal and/or external power reduction is active.

Internal power limitation	Parameters for external power limitation	Parameters for power limitation
Status = active	Status = active	Parameters in SunSpec model 123:
Maximum apparent power $S_{lim} = 100000 \text{ VA}$		"WMaxLimPct" = 50% P_{lim} (approx. 40000 W)
Maximum active power $P_{lim} = 80\%$ (approx. 80000 W)	AC fallback active power $P_{fb} = 75\%$ P_{lim} (approx. 60000 W)	"WMaxLimPct_RvrtTms" = 60s
	PT1 settling time = 1s	"WMaxLimPct_RmpTms" = 2s
		"WMaxLim_Ena" = 1

Tab. 15: Sample parameters for power limitation

If the ramp time "WMaxLimPct_RvrtTms" in the SunSpec model is specified as 0 s, then the internal output gradient is used. Otherwise, the set value will be used.

Irrespective of the communication protocol used, the settling time "WMaxLim_Ena" is used in order to transfer the new power value. Otherwise, the internally configured value will be used.

The additional ramp time "WMaxLimPct_RmpTms" specifies the jump time from a power value to the new power value.

The following formulae are used to calculate the gradient $S_{lim/min}$:

$$\text{GradientWattPerMin} = \frac{\left(\frac{WMaxLimPct}{100} \times P_{lim} - P_{actual} \right)}{WMaxLimPct_{RmpTms}} \times 60 \times \frac{100}{S_{lim}}$$

$$\text{GradientWattPerMin} = \frac{\left(\frac{50\%}{100} \times 80000 \text{ W} - 60000 \text{ W} \right)}{2 \text{ s}} \times 60 \times \frac{100}{100000 \text{ VA}}$$

GradientWattPerMin = -600 % Slim /min




Fig. 84: Power gradient according to sample parameters and calculation

The following formulae are used to calculate the Q filter parameter and cos ϕ gradient:


$$\text{GradientVArPerMin} = \frac{\left(\frac{VArMaxPct}{100} \times S_{lim} - Q_{actual} \right)}{VArPct_{RmpTms}} \times 60 \times \frac{100}{S_{lim}}$$

Fig. 85: Formula for calculating the Q filter parameter

$$\text{GradientVArPerMin} = \frac{\left(\frac{VArMaxPct}{100} \times S_{lim} - Q_{actual} \right)}{OutPFSet_{RmpTms}} \times 60 \times \frac{100}{S_{lim}}$$

Fig. 86: Formula for calculating the cos ϕ gradient (internal power gradient)

10.4.1.1 Parameters for permanent power limitation

Country-spec. Settings	Menu level	Display/ Setting	Action in this menu/meaning
		Power limitation	Activate or disable the power limitation.
		 Check activation	
		Maximum apparent power (S_{lim}) 1000 – S_{max} [VA]	The apparent power is limited globally to the configured value in VA. As soon as S_{lim} has been configured, all of the active and reactive power control values will use S_{lim} as 100% instead of S_{max} .
		Maximum active power (P_{lim}) 1 – 100 [% S_{lim}]	Active power is limited globally to the configured value in % S_{lim} .

10.4.2 Soft start up / power ramp-up limiting

A soft start-up function is available to prevent the grid from being negatively impacted by a sudden increase in feed-in power from the inverters.

When the inverter is activated or switched on, the increase in power is restricted by the set gradient. It is possible to configure whether the soft start-up should occur every time the device is switched on, only upon initial start-up each day or only upon start-up after the device has been switched off by grid protection. Due primarily to the fact that there is the risk that many plants could increase their power levels simultaneously after they have been switched off by grid protection, a soft start-up is usually only required for start-up after a device has been switched off by grid protection.




The soft start up is implemented by an absolute power limitation that increases with a continuous gradient up to the maximum power. The actual power of the inverter may vary freely below this limit due to a possible fluctuation in the available power or the target value, but at no time increases above the absolute power limit.

10.4.3 Normal operation power gradient

In the case of very large plants, it may also be necessary to restrict the change in power level during normal operation. If the set value (for increase and decrease in power level) and the solar irradiation change (for increase in power level), then the grid feed-in power is increased or decreased in line with the configured gradient. A limitation is not possible if the solar irradiation is reduced.

The function is not active for power changes defined by another grid support function, such as power recovery after Fault Ride Through, P(f), P(U).

10.4.3.1 Parameters for power gradient in normal operation

Country-spec. Settings	Menu level	Display/ Setting	Action in this menu/meaning
		Operation mode  On / Off	Activate or deactivate the power gradient limitation in normal operation.
		Increasing gradient  1-65534 [% S_{max} / min]	The change in the active power is limited to a configured power increase gradient.
		Falling gradient  1 – 65534 [% S_{max} / min]	The change in the active power is limited to a configured power decrease gradient.

10.5 Advanced islanding detection

Due to decentralized generation, there is the possibility that a deactivated part of the grid will remain live in an unintended island due to the balance of load and generation in this part of the grid. The detection of unintended island formation is an important function of decentralized generating units and is related to the prevention of damage to equipment as well as safety of personnel.

Depending on the structure and the operation of the distribution grid several dangers exist:

- In case of maintenance work in a distribution grid, personnel may be placed in danger if the deactivated part of the grid remains live as an island. This is especially the case if not all safety rules are followed.
- If fast auto-reclosure is used in a distribution grid and the deactivated part of the grid remains live as an island, reclosure will likely happen during phase displacement which might cause damage to rotating machinery on the grid.
- In the event of a fault in a medium voltage grid, the faulty part of the grid is disconnected. If the fault has a significant resistance, the deactivated part of a medium-voltage grid remains live as an island. Depending on the type of fault, but explicitly in case of a fault in the transformer, dangerous medium voltage might be accessible or even present in low-voltage appliances.

Especially for the last example very fast disconnection of the generating units to cause collapse of the forming island is necessary. At the same time any island formation detection method may cause false tripping. The industry is therefore in constant research to develop methods that are fast and reliable and at the same time reliably prevent false tripping.

Enhanced island detection method

The new method by KACO new energy, enhanced island detection, employs a strategy to reliably detect island formation that is based on the characteristic differences between an interconnected grid and an islanded grid, thus ensuring reliable fast detection and prevention of false tripping.

An interconnected grid is dominated by rotating machinery, as a consequence frequency is proportional to active power balance and voltage is proportional to reactive power balance. In contrast an islanded grid behaves like a resonant circuit, as a consequence frequency is proportional to reactive power balance and voltage is proportional to active power balance. The active enhanced island detection method detects this difference by monitoring the behaviour of the grid. The improved islanding detection monitors the natural fluctuation of the grid frequency and feeds in a minimal reactive power that is proportional to the rate of change of the frequency. At the moment that islanding is established, the connected grid closes a positive feedback loop, which allows the inverter to detect the altered situation and disconnect. In case of formation of an island, the inverter disconnects within some 100 ms, well below 1000 ms.

- The number of parallel inverters does not affect the reliability of this function.
- This method also guarantees that the impact on the distribution grid is minimised.
- In normal operation no effects on harmonic content, flicker and grid stability are detected.

This detection method is combined with a two stage passive rate of change of frequency (ROCOF) observation. If the ROCOF of the grid exceeds the configured disconnection threshold (stage 1) for the configured disconnection time, the device switches to zero current mode. If the ROCOF of the grid exceeds the configured disconnection threshold (stage 2) for the configured disconnection time, the device switches off. In case of an island, this will shut down the island instantaneously. If the grid stabilizes, what might be the case if the ROCOF event was due to a short disturbance in the power grid, the inverter will resume normal operation. In the event of active stage 1, the device switches to zero current mode, and re-starts the infeed after a few 100 ms. With stage 2 active, the device has switched off and the set reconnection conditions shall apply.

10.6 Q on Demand



⚠ DANGER

When deactivating night shutdown ("Q on Demand" mode), a high DC voltage may still be present both at the string combiner and at the device despite the string combiner being switched off.

1. In case of maintenance, the device must also be disconnected from the power supply on the AC side.
2. We recommend affixing an appropriate danger notice to the string combiner.

The "Q on Demand" function can also provide reactive power Q outside of feed-in mode (e.g. at night) for grid stabilisation. The function is only available from the named firmware version onwards [See section 1.1 ▶ Page 4].

Important preconditions:

- "Night shutdown" function disabled in the menu
- Device is connected on the AC side
- Device was in feed-in mode.


First priority is given to the specifications that the inverter receives from the grid operator via the park controller over Ethernet or RS485. Second priority is given to the parameters stored in the inverter for Q-constant and Q(U).

In the event of AC disconnection during "Q on Demand" mode outside of feed-in mode, it is only possible to use the "Q on Demand" function again after normal feed-in mode (with sufficient DC supply). The existing disabled "night shutdown" also remains active.

The following figures show normal operation in the P-Q operating range, during the day (feed-in mode) (1) and "Q on Demand" operation at night (2).

Only reactive power is generated at night. Inevitably, some active power is required for the internal power supply in order to maintain the pre-set reactive power functions in "Q on Demand" mode (see pos. 2 in the negative P range).

Reactive power control mode setting: See table : Configuration via web user interface [▶ Page 63].



Key

- (1) Normal operation: Active power and reactive power provision at different voltages.
- (2) Q on Demand function: Reactive power provision at nominal grid voltage outside feed-in mode.

11 Maintenance and troubleshooting

11.1 Visual inspection

Inspect the product and cables for visible external damage and note the operating status display, where applicable. In the event of damage, notify your installation engineer. Repairs may only be carried out by authorised electricians.



⚠ DANGER

Dangerous voltage due to two operating voltages

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched. The discharge time of the capacitors is up to 5 minutes.



1. Only appropriately qualified electricians authorised by the mains supply network operator are permitted to open and maintain the device.
2. Before opening the device: Disconnect the AC and DC sides and wait at least 5 minutes.



NOTE

There are components in the housing of the device which may only be repaired by the customer service team.

1. Do not attempt to repair faults that are not described here (in the chapter on troubleshooting and fault rectification). Contact our Customer Service department. Only carry out maintenance activities that are described here.
2. Log each maintenance activity in the "Service" menu item: "Service Log" (exception: "User" interface) Configuration via web user interface
3. The device should be checked for proper operation by a qualified electrician at regular intervals and if you experience problems, you should always contact the system manufacturer's Service department.

11.2 Cleaning

11.2.1 Cleaning the housing

⚠ CAUTION

Risk of damage to the device during cleaning!

1. Do not use compressed air or high-pressure cleaners.
2. Use a vacuum cleaner or a soft brush to remove dust from the fan cover and from the top of the device on a regular basis.
3. Remove dust from the ventilation inlets if necessary.

11.2.2 Cleaning the fan drawer

Opening the fan drawer

- ⌚ Ensure that the device is completely free of AC/DC voltage and that there is sufficient access from the side.
- ⌚ **DANGER! Risk of injury from starting fans: If the device is not completely disconnected from the voltage source, the fan may start up unexpectedly and injure limbs. This may also cause damage to the fan and impair the functionality of the device.**
- ⌚ Wait until all 3 fans have stopped rotating.

1. Loosen the lateral fastening screws on the left or right housing body.
2. Carefully push the drawer out by pressing on it.




Fig. 87: Opening the fan drawer

- 1 Drawer
- 2 Fastening screw
- 3 Connector

⌚ The fan drawer needs to be loosened and removed for cleaning.

1. Remove dirt and dust particles from all fans with a suitable brush.
2. If necessary, remove internal dirt by lightly tapping on the side of the fan grille.
3. Replace the fan drawer and connect the power supply cable.

⇒ Cleaning completed. If necessary, clean another drawer.




Fig. 88: Cleaning the fan drawer

- 1 Fan
- 2 Power supply cable
- 3 Fan grille

11.3 Replacing the fan

Take out the drawer and remove the fan

⌚ Time required to replace the fan: (10 min each fan) 30 min

⌚ Power supply cable for all fans uncoupled from connector. [XT_S_Z2]

1. Turn the drawer to the side and remove the power supply to the defective fan.
2. Remove the defective fan from the holder by loosening the two fastening screws. [XT_20]
3. Fit the replacement fan into the designated holder and secure it with the two fastening screws. [XT_20 / \uparrow 2 Nm]
4. If required, fit another fan.
5. Connect the power supply cable for all fans to the connector and carefully push the drawer back into the housing of the device.
6. Attach the drawer to the housing body with fastening screws [XT_20 / \uparrow 2 Nm].

⇒ Fan successfully replaced.

Removing the interior fan

⌚ **DANGER! Risk of injury from starting fans: If the device is not completely disconnected from the voltage source, the fan may start up unexpectedly and sever or injure limbs. This may also cause damage to the fan and impair the functionality of the device.**

1. Remove the cover for the covered fan over the mounting screws.
2. Wait until the 2 fans have stopped rotating.
3. Push the defective fan to the side by approx. 10 mm and remove it carefully with the collar.
4. Release the interlock and remove the connector plug from the inside of the housing.
5. Remove the fan.

⇒ Install the replacement fan.




Fig. 89: Removing the fan

- 1 Fastening screws (2x)
- 2 Power supply cable
- 3 Fans 1 - 3




Fig. 90: Releasing the cover on the first interior fan




Fig. 91: Removing the interior fan

- 1 Cover
- 2 Fastening
- 3 Fan
- 4 Rubber collar

Fitting the fan

↪ You have removed the defective fan.

1. Plug in the connector plug of the new fan at the connection socket provided within the housing and check the interlock.
2. Insert the replacement fan into the collar holder.
3. Insert the fan in the intended position and push it approx. 10 mm to the side.
4. If necessary, insert another fan.

⇒ Fit the cover back in place.




Fig. 92: Removing the interior fan

11.4 Replacing overvoltage protection

AC overvoltage protection

↪ **NOTE: If the message "Overvoltage protection module defective" appears in the web interface, these modules must be replaced.**

↪ **NOTE: Ensure that the device is completely free of AC/DC voltage**

1. [See section 7.2 ▶ Page 22].
2. Remove faulty modules individually from the plug-in frame and replace with a module of the same type.
 - **NOTE: Different AC surge protection modules are used. The designation on the PCB must match the module code (GTD/MOV).**
3. Insert the AC overvoltage protection modules into the plug-in frame one after another.
4. Ensure that all protective elements are properly secured.

⇒ Proceed with the installation of the device.




Fig. 93: Replacing the AC overvoltage protection

- 1 AC overvoltage protection module (1 slot for PE)
- 2 AC surge protection socket
- 3 AC overvoltage protection module (3 slots)

DC overvoltage protection

↪ **NOTE: If a fault appears on the status display of the overvoltage protection module, the overvoltage protection module should be replaced.**

↪ **NOTE: Ensure that the device is completely free of AC/DC voltage.**

1. [See section 7.2 ▶ Page 22].
2. Carefully remove defective modules from the circuit board.
 - **NOTE: The vendor of the module and the type of module must be the same as the module to be replaced.**
3. Insert DC overvoltage protection modules individually in the same position.
4. Ensure that all protective elements are properly secured.

⇒ Proceed with the installation of the device.




Fig. 94: Replacing the DC overvoltage protection

- 1 DC SPD ground module (KACO art. no. 3015625)
- 2 DC SPD module (KACO art. no. 3015624)
- 3 Slot type 1/2

11.5 Shutting down for maintenance



⚠ DANGER

Lethal voltages are still present in the connections and cables of the device even after the device has been switched off and disconnected!

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched.

Only appropriately qualified electricians authorised by the mains supply network operator are permitted to open and maintain the device.

1. Comply with all safety regulations and current technical connection specifications of the responsible power supply company.

Shutdown sequence

1. Switch off the grid voltage by turning off the external circuit breakers.
2. Disconnect the DC side using the integrated DC isolator switch.

. DANGER! The DC cables are still live

⇒ After shutdown, wait 5 minutes before opening the device.

11.6 Troubleshooting

11.6.1 Procedure


⚠ DANGER

Lethal voltages are still present in the connections and cables of the device even after the device has been switched off and disconnected!

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched.

1. The operator can only carry out actions marked with a B.

11.6.2 Rectifying the cause

B = Operator's responsibility; E = The indicated work may only be carried out by an authorised electrician! ; K = The indicated work may only be carried out by a service employee of KACO new energy GmbH!



Fault	Possible cause	Explanation/remedy	from
The LEDs do not light up	Grid voltage not available	› Check whether the DC and AC voltages are within the permitted limits (see Technical Data)	E
		› Notify KACO Service.	E
The device stops feeding into the grid shortly after being switched on, even though there is sunlight present.	Defective circuit-breakers in the device	If the circuit-breakers are defective, the device will recognize this during the self-test.	K
		› Ensure that there is sufficient PV generator power.	E
		› If the grid separation relay is defective, have it replaced by KACO Service.	
	› Notify KACO Service.		
Device is active but not connected to the grid. A grid fault is displayed on the status LED.	Grid-feed is interrupted due to a grid fault.	Due to a grid fault (over/undervoltage, over/underfrequency), the device stopped the feed-in process and disconnected from the grid for safety reasons.	
		› Change the grid parameters within the permitted operating limits (see the "Start-Up" section).	E
The grid fuse trips.	The grid fuse capacity is too low.	In case of a high level of solar radiation, the inverter exceeds its rated current for a short period, depending on the PV generator.	
		Select the capacity of the device's backup fuse to be somewhat higher than the maximum feed-in current (see the "Installation" section).	E
		› Contact the grid operator if the grid failure continues to occur.	E
The grid fuse trips.	Hardware damage on the device.	If the grid fuse trips immediately when the device goes into feed-in mode (after the start-up period is complete), the device's hardware is probably damaged.	
		› Contact KACO Service to test the hardware.	E
The device is displaying an impossible daily peak value.	Faults in the grid.	The device continues to operate as normal without losses to the yield, even when an erroneous daily peak value is displayed. The value is reset overnight.	
		To reset the value immediately, switch the device off by disconnecting it from the grid and switching off the DC, then switch it back on.	E

Fault	Possible cause	Explanation/remedy	from
Daily yields do not correspond to the yields on the feed-in meter.	Tolerances of the measuring elements in the device.	The measuring elements of the device have been selected to ensure maximum yields. Due to these tolerances, the daily yields shown may deviate from the values on the feed-in meter by up to 15%. › No action.	E
Device is active but not connected to the grid.	Generator voltage too low; grid voltage or PV generator voltage unstable.	The PV generator voltage or power is not sufficient for feed-in (solar radiation is too low). The inverter checks the grid parameters before the feed-in process begins. The length of time it takes to switch back on again differs from country to country, depending on applicable standards and regulations, and may be several minutes. The starting voltage may have been set incorrectly. › Adjust starting voltage in the Parameter menu. › No action	E
Even with high radiation levels, the device does not feed the maximum power into the grid.	Particular ambient conditions.	The device has reduced its power to prevent damage due to excessive temperatures inside the device. Note the technical data. Ensure that the convection cooling is not impeded from the exterior. Do not cover the cooling fins. › Ensure sufficient cooling of the device. › Remove any foreign bodies which are present on the unit. › Clean the cooling fins	B B E
	DC fuse defective	A generator string is disconnected from the device owing to a faulty fuse. Check why it has tripped by measuring all DC strings using a clip-on ammeter. - If there is no current flow in a string, the associated DC fuse is faulty. › Check the no-load voltage and dimensioning of the PV generator. Replace the damaged modules if necessary. › Replace the PV fuse with a fuse of the same size and type.	B, E

Tab. 16: Troubleshooting

11.7 Messages

Many event messages indicate a fault in the grid. They are not operational faults of the device. The triggering levels are defined in standards, e.g. VDE0126-1-1. The device shuts down if the values exceed or fall below the approved levels.

Fault LED (red)	Status	Explanation	LED
	FS (fault status)	– Fault signal relay has been tripped. – Feed-in was ended due to a fault.	On
	OS (operating status)	– The fault relay releases again. – The device feeds back into the grid again after a country-specific time period.	Off

11.8 Event messages

The following table lists the possible ProLog© status messages that the device can display by means of the LC display / web user interface and the LEDs.

No.	Event message	Explanation	Remedy	Pers.
–	0	Device is waiting until the start voltage is reached.	PV modules must have sufficient exposure to daylight => Remove covers if necessary.	–

No.	Event message	Explanation	Remedy	Pers.
1	Waiting for feed-in	Message is displayed when the device starts up. The generator voltage is lower than the starting voltage (pre)set in the device or the grid is still being checked for stability.	Start voltage set too high. => Check the DC configuration of the PV system and reduce the "Start voltage" in the menu if necessary.	-
2	Insufficient generator voltage insufficient battery voltage	Insufficient battery voltage and power, status before the transition from or into standby.	<ul style="list-style-type: none"> > Does the web user interface correctly display the voltage measured at the DC terminals? => If necessary, check the phase voltage individually. > Are the individual DC isolator switches switched off? => Switch off DC isolator switches individually > Is there DC polarity reversal? => Check polarity according to chapter 7.5. > Is the firmware fully installed? => Install firmware again according to "Software Update Guide xxx". 	-
4	Yield counter for daily and annual yields are displayed	Message indicates regular feed-in mode. In cases of sufficient sunlight, the unit feeds into the grid with MPP control so as to maximise yields.	<p>Is the expected power not being fed in? => Check the open circuit voltage with a multimeter and check whether the PV system is working:</p> <ul style="list-style-type: none"> - Strings with different voltages are on the same tracker - a DC isolator switch is switched off - DC polarity reversal is present - frequent power limitation due to inadequate dimensioning - if constant voltage mode is active: check whether open circuit voltage is lower than the set constant voltage 	E
8	Self test in progress	<p>"The following sequence is run through during the self-test before feeding in:</p> <ol style="list-style-type: none"> 1. S8 grid relay self-test 2. S79 ISO measurement 3. S8 filter relay self-test 4. S75 (load DC link) 5. S8 pre-synchronisation 6. S4 feed-in 	The results of the self-test can indicate the cause of the PV system or device. Note the last status issued.	-
10	Temperature in device too high	Due to a lack of air circulation, the device was switched off because of overtemperature.	<p>Have the minimum distances for overleaf installation been observed? => Check information in chapter 6.</p> <p>Has the device been covered inadvertently? => Remove the object or cool down the environment.</p> <p>Is the fan or, if it can be reached, the heat sink dirty? => Clean fan & heat sink according to chapter 11.2.</p>	B B E
11		Power limitation: If the generator power is too high, the device limits itself to the maximum power (e.g. around noon if the generator capacity is too large).	See status 8 in remedy	-

No.	Event message	Explanation	Remedy	Pers.
17	“Powador-protect disconnection” or “External grid protection shutdown”	Due to a grid failure (e.g. under/over-voltage or under/overfrequency), a shutdown was initiated by the higher-level grid plant protection. The set limit value has been exceeded.	Has the grid plant protection been supplied with power correctly? => Check the “grid parameters” on the grid plant protection. (external device) > Is the cabling implemented correctly? => If external grid plant protection is not required, it must be deactivated in the menu of the device. See chapter 9.4 Menu structure.	E
18	Resid. current shutdown	The integrated AC/DC-sensitive residual current device registered an non-permissibly high leakage current going to PE. Tripped with a jump of 30 mA, 60 mA & 150 mA each with the corresponding shutdown times. The reconnection time is country-specific.	> Has the PE line been laid correctly or does this error also occur frequently in the rain? => Measure the insulation resistance of the system and, if necessary, earth the PE line correctly.	E
20	Active ramp limitation	Internal power limitation, e.g.: “Ramp Up” 10 %/min The result when the power is increased with a ramp is country-specific (after P(f), restart, after grid error, after every connect)	This is required by the country-specific standard.	-
30	Voltage trans. fault	Current and voltage measurement in the device are not plausible.	If the device displays the same message after restarting (AC / DC disconnection) => contact the service department	-
31	RCD module error	An error has occurred in the AC/DC-sensitive residual current device.	N/A	-
33	DC feed-in error	The DC component in the feed-in current is outside the allowable limit values.	If displayed once, the system will attempt to recalibrate itself. In case of frequent or permanent display, you should contact the service department. Note: Due to country-specific requirements (e.g. Italy), the limit values for shutting down are very low).	E
34	Internal communication error	A communication error has occurred in the internal data transmission.	If an installer is on site, the communication cable between the display board and the AC power unit should be checked for firm seating, or a commercially available CAT5 cable should be used for testing. Note: A high temperature-resistant cable is prescribed in the device. Please contact the service department.	E

No.	Event message	Explanation	Remedy	Pers.
35	Protect. shutdown SW	Due to a measured value which is outside the permissible range, a shutdown has been carried out to protect the device	<p>> Does the error or fault occur only sporadically? => Restart device (AC+DC disconnection). > How is the device connected to the grid (strongly inductive network (directly on the transformer))? => If the system has its own transformer, the short-circuit voltage of the transformer provides information on the inductance of the grid for the system (4% short-circuit voltage is a very good value). SW from V3.14 also supports 8% and more. => Update SW.</p> <p>If the error is present continuously, all connection terminals from the device to the grid connection must be checked. A fluctuating or missing AC voltage can indicate this connection problem. Otherwise, contact the service department.</p>	K
36	Protection shutdown HW	Group message for all trip zone shutdowns.	Grid-related disconnection of the grid operator. The grid connects again automatically. Please wait.	-
38	Error: Generator Voltage too high Error: Battery overvoltage	The voltage of the PV generators has exceeded the maximum permissible value (for limit values, see data sheet).	Are PV strings connected in series instead of in parallel? => Check PV voltage with a suitable measuring device and, if necessary, check planning and assignment.	E
41	Grid failure under-voltage L1	The limit value is country-dependent. This is a legally required check of the power supply.	Your installer should check the AC voltage at the terminals and AC wiring. If the settings in the menu are also correct, contact the service department.	E
42	Grid failure: over-voltage L1	See explanation in status 41	See remedy in status 41	E
43	Grid failure under-voltage L2	See explanation in status 41	See remedy in status 41	E
44	Grid failure: over-voltage L2	See explanation in status 41	See remedy in status 41	E
45	Grid failure under-voltage L3	See explanation in status 41	See remedy in status 41	E
46	Grid failure: over-voltage L3	See explanation in status 41	See remedy in status 41	E
47	Grid failure phase-to-phase voltage	The phase angles between the individual phases of the three-phase supply network is not correct, possibly no three phase connection.	<p>Measure the voltages on the device terminal and compare to the relevant country-specific limit.</p> <p>Check set values in the parameters menu. Check the AC fuses: A phase may be missing.</p> <p>This error can be caused by a poor connection/cabling on the AC side. Check all connection terminals from the inverter to the grid connection. A fluctuating or missing AC voltage can indicate this connection problem.</p>	B/K

No.	Event message	Explanation	Remedy	Pers.
48	Grid failure underfrequency	Measured value for grid frequency is outside the permissible limit. Limit is country-dependent.	Has the correct country setting been made? => Check set values in the parameters menu. Your installer should check the AC connection and the connection to the device. Otherwise, contact the service department.	E
49	Grid failure overfrequency	See explanation in status 48	See remedy in status 48	E
50	Grid failure: average voltage	The grid voltage measurement according to EN 50160 (10 min average value) has exceeded the maximum permitted limit value.	If it appears frequently, check the settings E in the menu. > Has the firmware not been installed correctly? => Unpack the firmware according to the instructions in the download area.	E
56	SPI remote shutdown	Remote switch off via digital input. (e.g. CEI 0-21)	This was caused by the grid operator.	-
57	Waiting for reactivation	The waiting period following a fault is country-dependent and can last several minutes.	Does the message appear frequently? => Find the reason for switching off via error logs, Prolog status	-
58	Control board overtemp.	The temperature inside the device was too high. The device shuts down to avoid hardware damage.	This message appears only at high ambient temperatures (<60°C) > Has the power been checked? => Observe derating temperature according to data sheet > Is the fan or heat sink covered? => Clean device according to chapter 11.2.	E
60	Generator voltage too high Battery voltage too high	This can occur briefly with designs with high open circuit voltage and very low external temperatures, and is a protective function of the device.	Are PV strings connected in series instead of in parallel? => Check PV voltage with a suitable measuring device and, if necessary, check planning and assignment.	-
61	External limitation x%	The grid operator requires an active power reduction. If only reactive power is specified, this message does not appear.	This is a requirement from of the grid operator.	-
63	Frequency-dependent power change) This requirement is country-dependent. The response is configurable. Normative requirements. No indication on display (behaves in the same way as normal feed-in mode status 4, therefore no flashing "Feed-in" LED). Can be viewed in service log files and via proLOG/portal. When certain country settings are activated, the frequency-dependent power change is activated.	This is a normative requirement.	-
64	Output current limiting	Power limitation as the max. permissible value of the feed-in current per phase has been reached.	This is a normal protective function of the device due to an excessively low grid voltage.	-
73	Grid failure: Islanding	Standalone mode was detected.	Device was switched off after event in PV system. Contact the service department.	B
75	Self test in progress	Self-test sequence is documented in S8.	See remedy in status 8	-

No.	Event message	Explanation	Remedy	Pers.
78	Resid. current shutdown (AFI)	A static residual current causes the device to shut down. The shutdown threshold is determined by the power class and the relevant regulations. For devices in USA/Canada (with UL certification), the device can be reconnected a maximum of 4 times within 24h. F78 therefore stops once the 5th Fault is triggered within 24h.	If the fault occurs in the event of precipitation or high air humidity, this indicates an increased discharge current => check location in the system. Otherwise contact the service department.	E
79	Insulation measurement	Insulation resistance of the system is calculated before connection. Further information in status 19.	Normal device behaviour If the status persists, the service department should be contacted.	B
80	Insulation meas. not possible	Not possible to calculate the insulation resistance.	The installer should check the installation of the PV module. => If the message persists, contact the service department.	E
81	Protection shutdown grid volt. L1	Protection shutdown due to excessively high grid voltage. It is the live value which is decisive for the shutdown procedure. This means that an individual peak value is enough to trigger a shutdown.	Does the message appear frequently? => The installer must check the installation and contact the service department if necessary.	E
82	Protection shutdown grid volt. L2	See explanation in status 81	See remedy in status 81	E
83	Protection shutdown grid volt. L3	See explanation in status 81	See remedy in status 81	E
84	Protection shutdown undervolt. DC link	Display if the min/max. value of the DC link voltage is undershot. If the device stops feeding in, then there is a fault in the device, otherwise, a highly inductive grid is responsible for this.	Is the location on the AC side to the device correct? => Check all connection terminals from the device to the grid connection. A fluctuating or missing AC voltage can indicate this connection problem. Note: Check the AC-side wiring (transformer inductance capacity) N-conductor is theoretically permitted to have reduced specifications.	E
85	Protective shutdown overvolt. DC link	See explanation in status 84	See remedy in status 84	E
86	Protect. shutdown DC link asymmetry	Protective shutdown due to excessive asymmetry of the two DC link halves	Is the message present after a new feed-in start? => Contact the service department.	E
87	Protect. shutdown overcurrent L1	Protective shutdown due to an excessively high grid current.	Is the AC wiring correct? => The current measurement is possibly not correct. Contact the service department.	E
88	Protect. shutdown overcurrent L2	See explanation in status 87	See remedy in status 87	E
89	Protect. shutdown overcurrent L3	See explanation in status 87	See remedy in status 87	E
91	Protect. shutdown voltage drop 2.5 V	Protective shutdown because internal 2.5 V reference voltage outside the permissible range.	Fault in the device	-
92	Protect. shutdown voltage drop 1.5 V	Protective shutdown because internal 1.5 V reference voltage outside the permissible range.	Fault in the device	-
93	Buffer 1 self-test error	Error in the buffer test during the self-test - automatic restart after 3 minutes	If the error is displayed continuously, there is a device error.	E/K

No.	Event message	Explanation	Remedy	Pers.
97	Protection shutdown overcurrent HW	The protective shutdown has tripped due to an overcurrent into the grid. Triggering takes place via a TripZone.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	E/K
100	Protect. shutdown HW overheating	See explanation in status 97	See remedy in status 97	B E
101	Temperature plausibility error	The individual temperatures in the device are compared with one another. If a certain limit value is exceeded, the message appears.	In case of repeated occurrence, contact the service department.	K
102	Plausibility fault efficiency	The degree of efficiency of the device must remain within certain limits.	In case of repeated occurrence, contact the service department.	K
104	Plausibility fault AFI module	The device has shut down because of implausible internal measured values.	In case of repeated occurrence, contact the service department.	K
105	Plausibility fault relay	See explanation in status 104	See remedy in status 104	K
106	Plausibility error DCDC converter	See explanation in status 104	See remedy in status 104	K
108	Grid failure: over-voltage L1	Device has detected a fault on one phase and has been switched off.	Are the setting values in the menu correct according to the grid voltage? => Once the test is finished, check all connection terminals from the device to the grid connection. A fluctuating or missing AC voltage can indicate this connection problem.	E
109	Grid failure: over-voltage L2	See explanation in status 108	See remedy in status 108	-
110	Grid failure: over-voltage L3	See explanation in status 108	See remedy in status 108	-
111	Grid failure under-voltage L1	See explanation in status 108	See remedy in status 108	-
112	Grid failure under-voltage L2	See explanation in status 108	See remedy in status 108	-
113	Grid failure under-voltage L3	See explanation in status 108	See remedy in status 108	-
125	Relay control error	The enable signal for the relay control is read back.	In case of repeated occurrence, contact the service department.	K
128	Internal memory error 1	Fault in read or write access to the internal RAM.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
129	Power reduction P(U)	Message present, if the function P(U) sets the power level according to the specified parameters subject to the AC voltage.	This functionality may, for example, be requested by the grid operator. If there is no request, the function can be deactivated.	B
130	AFCI module self-test error	An arc test spectrum that is regularly fed into the sensor was not correctly detected. The self-test is repeated and if the test spectrum is detected again, the error is reset.	N/A	-

No.	Event message	Explanation	Remedy	Pers.
131	Arc detected on DC input 1 or 2	The arc monitoring on the DC side has detected an arc spectrum on the specified tracker. An arc is likely, but it could also be triggered by other external influences that produce a similar interference spectrum. A check of the system should be carried out. The fault must be manually reset. An appropriate entry appears in the installer menu. Arc detected on DCx. When an arc is detected, the current flow is interrupted for 1 second to extinguish the arc. These events are recorded.	Faulty plug connections or junction boxes (loose contacts), faulty cables (animal bite), defects in the module itself. Check cables, check whether the open-circuit voltage of the individual strings is OK in order to isolate the fault on the individual string. If no error is found, analyse possible sources of interference: If the DC cables are routed together with other circuits, coupling from other electrical devices may have occurred. Is there a connection between the tripping and the operation of other electrical devices? Kaco service technicians can pull a data set on USB that can be used to analyse the interference spectrum. The record is automatically included when the service logs are deducted.	-
132	Arc detected on DC input 3 or 4	See explanation in status 108	See remedy in status 108	-
133	Arc detected on DC input 5 or 6	See explanation in status 108	See remedy in status 108	-
134	Arc detected on DC input 7 or 8	See explanation in status 108	See remedy in status 108	-
135	Arc detected on DC input 9 or 10	See explanation in status 108	See remedy in status 108	-
140	Not enough AFCI DC inputs	The AFCI circuit has detected a hardware problem and feed-in mode is terminated.	N/A	-
141	Error controller output pin	The AFCI circuit has detected a software problem and feed-in mode is terminated.	N/A	-
143	Configuration error AFCI	The AFCI circuit has detected a hardware issue and the feed-in operation will be terminated.	"Have you tried restarting the device? (Disconnect AC/DC - turn it back on after 5 minutes.) => If unsuccessful, contact service.	-
148	External memory error 1	The device has permanent internal memory for the purpose of, for example, storing the hardware used. Operation parameters are deduced from this.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
150	Protect. shutdown volt. drop 1.65 V	Internal protective function in order to adhere to the required measurement accuracy.	See remedy in status 148	B
158	Power limitation	Power limitation because the internal temperature is too high. The temperature is measured on the control card. This is a protective function of the device.	Check whether the cooling of the device is guaranteed: Heat sink clean and installation instructions according to manual adhered to (clearances)?	-
159	Waiting for fault acknowledgement	The DSP is waiting for the configuration data from the HMI.	Configuration of the device via web user interface must be concluded in full.	B
160	Error: Grid relay L1	The self-test has detected a fault with the grid-side relay.	In case of repeated occurrence, contact the service department.	-
161	Error: Grid relay L2	See explanation in status 160	See remedy in status 160	-
162	Error: Grid relay L3	See explanation in status 160	See remedy in status 160	-
164	Error: Filter relay L1	The self-test has detected a fault with the grid-side relay.	In case of repeated occurrence, contact the service department.	-

No.	Event message	Explanation	Remedy	Pers.
165	Error: Filter relay L2	See explanation in status 164	See remedy in status 164	-
166	Error: Filter relay L3	See explanation in status 164	See remedy in status 164	-
169	Error: AFI sensor	The AFI sensor is demagnetised prior to feed-in. If this is not possible, this message appears	In case of repeated occurrence, contact the service department.	-
170	Check overvoltage protection on DC side	The AC-side overvoltage protection (if present in the device) has tripped and must be replaced. All 3 LEDs light up on the device.	<p>Has the overvoltage protection been checked?</p> <p>- No -> please check overvoltage protection device - Yes and not OK. -> Replace overvoltage protection</p> <p>- Yes and OK. -> Replace device and comment: "Overvoltage protection has been checked and is OK. – Message is still displayed"</p> <p>Check the overvoltage protection in the device. The overvoltage protection module has a corresponding function display. With a red function display, the overvoltage protection module must be checked, and replaced if necessary.</p>	-
171	Check overvoltage protection on AC side	The AC-side overvoltage protection (if present in the device) has tripped and must be replaced. All 3 LEDs light up on the device.	<p>Has the overvoltage protection been checked?</p> <p>- No -> please check overvoltage protection device - Yes and OK. -> Replace device and comment: "Overvoltage protection has been checked and is OK. – Message is still displayed"</p> <p>Check the overvoltage protection in the device. The overvoltage protection module has a corresponding function display. With a red function display, the overvoltage protection module must be checked, and replaced if necessary.</p>	-
172	Internal fan error	Failure of an external fan or the corresponding tacho signal. The power is reduced to 50% P _{nom} . All 3 LEDs light up on the device.	Is the fan blocked? => If necessary, clean according to Maintenance chapter. For electrically trained and qualified personnel: Are the plugs correctly plugged in?	-
173	External fan error	Failure of an external fan or the corresponding tacho signal. All 3 LEDs light up on the unit	See remedy in status 172	-
180	Pre-synchronisation not possible	Adequate voltage pre-synchronisation with the AC grid not possible.	<p>Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.)</p> <p>=> If not successful, contact the service department.</p>	B
181	Insulation error, centre	The insulation error is located close to the centre of a PV string. The area covers +-15% of the half of the modules based on the total number of modules.	<p>Has the isolation been carried out correctly? => Check the insulation resistance in the system.</p> <p>Note: Insulation fault messages after the update to V4.xy indicate insulation faults in the PV system that previously remained undetected. These must be rectified in order to operate the PV system safely and reliably.</p>	E

No.	Event message	Explanation	Remedy	Pers.
182	Insulation error, minus	The insulation fault is located between the centre of a string and the minus terminal on the inverter. If the insulation fault is located very close to the minus inverter terminal, then the fault occurs even if the insulation fault <150 kOhm and is above the set value.	See remedy in status 181	-
183	Insulation error, plus	The insulation error is located between the centre of a string and the plus terminal on the inverter. If the insulation error is located very close to the plus inverter terminal, then the error occurs even if the insulation error is greater than 150 kOhm and is above the set value.	See remedy in status 181	-
184	Protective shutdown overcurrent L1 int.	Protective shutdown due to an excessively high grid current in the interleaved path (channel B) at phase Lx. The live value is the critical factor in the shutdown.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	-
185	Protective shutdown overcurrent L2 int.	See explanation in status 184	See remedy in status 184	-
186	Protective shutdown overcurrent L3 int.	See explanation in status 184	See remedy in status 184	-
188	Semiconductor test not possible	The measurement or actuation of the semiconductors has failed. If necessary, the integrated AC filter can no longer be discharged below 50 V.	Make sure that there is no earthing problem. Disconnect the device on the AC and DC sides. Observe waiting time according to warning sign. Switch the device on again. If this message is displayed again, contact the service department.	B
189	Semiconductor module 1 in channel A defective	Semiconductor module x from channel A is defective or the corresponding filter relay is not closing correctly.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
190	Semiconductor module 2 in channel A defective	See explanation in status 189	See remedy in status 189	-
191	Semiconductor module 3 in channel A defective	See explanation in status 189	See remedy in status 189	-
192	Semiconductor module 1 in channel B defective	Semiconductor module x from channel B is defective or the corresponding filter relay is not closing correctly.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	-
193	Semiconductor module 2 in channel B defective	See explanation in status 191	See remedy in status 191	-
194	Semiconductor module 3 in channel B defective	See explanation in status 191	See remedy in status 191	-

No.	Event message	Explanation	Remedy	Pers.
195	DESAT error	Saturation monitoring (DESAT) of the IGBTs has tripped or the voltage supply (24 V) of the gate drivers is too low.	In case of repeated occurrence, contact the service department.	-
203	Protection shutdown grid volt. L1	Protective shutdown due to excessive grid voltage. It is the effective value which is decisive for the shutdown procedure.	Is the error displayed frequently? => Check the installation again. Otherwise contact the service department. Note: Fault can be caused by a poor location on the AC side. Check all connection terminals from the inverter to the grid connection. A fluctuating or missing AC voltage can indicate this connection problem.	E
204	Protection shutdown grid volt. L2	See explanation in status 203	See remedy in status 203	-
205	Protection shutdown grid volt. L3	See explanation in status 203	See remedy in status 203	-
206	Protection shutdown overcurrent HW	AC overcurrent shutdown triggered by hardware comparator.	In case of repeated occurrence, contact the service department.	-
207	Detection of hardware detection failed: Control card	The data stored in the EEPROM on the AC control card is not correct.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
208	Detection of hardware detection failed: AC power board	The data stored in the EEPROM on the AC power board is not correct.	See remedy in status 207	B
209	Detection of hardware detection failed: AC relay board	The data stored in the EEPROM on the AC relay board is not correct.	See remedy in status 207	B
210	Detection of hardware detection failed: DC control card	The data stored in the EEPROM on the DC control card is not correct.	See remedy in status 207	-
211	Detection of hardware detection failed: DC power board	The data stored in the EEPROM on the DC power board is not correct.	See remedy in status 207	-
212	Detection of hardware detection failed: AFPE board	The data stored in the EEPROM on the AFPE module is not correct.	See remedy in status 207	-
216	Protect. shutdown HW - overvoltage DC link halves	One of the two DC link halves has exceeded the maximum value. Shutdown occurs by way of HW-detection and TripZone shutdown.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
217	Protect. shutdown HW - 24 V supply voltage	The supply voltage in the device has exceeded its max. permitted value. Shutdown occurs by way of HW-detection and TripZone shutdown.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	B
224	External limitation	This is a relative specification of the desired active power adjustment.	N/A	-
226	The inverter is disconnected from the grid manually	The device can be disconnected from the grid manually after logging in via the web user interface. This message then appears.	Activate the network connection via the symbol on the web user interface.	B

No.	Event message	Explanation	Remedy	Pers.
227	Protective shutdown current asymmetry	Protective shutdown that enables safe shutdown of the device in the event of (high-ohm) grid failures. During grid events, asymmetrical currents may occur in the inverter. These are detected and switched off accordingly.	In case of repeated occurrence, contact the service department.	-
228	Protective shutdown voltage asymmetry	Protective shutdown that enables safe shutdown of the device in the event of (high-ohm) grid failures. During grid events, asymmetrical voltages may occur in the inverter. These are detected and switched off accordingly.	See remedy in status 227	-
230	AC voltage limitation	This is a protective function of the device that allows it to be switched off quickly in case of incidents or switching operations at the medium voltage level.	Normative requirement of the grid operator	-
231	External active power target value	External specification of a target value for the fed-in active power. The fed-in active power can be increased and reduced by the grid support procedures. Thus, the network support processes have higher priority.	Normative requirement of the grid operator	-
234	Shutdown by boost converter	The boost converter controller has initiated a shutdown. This can happen, for example, due to impermissible voltages or currents	N/A	-
235	Over current DC input	The DC input current of at least one DC tracker was too high and the feed-in was terminated. The connected PV modules have supplied too much current.	Has the input circuit been checked? => Possibly the short-circuit current of the corresponding input is too high.	-
236	Error reference voltage (DC input)	Error of the reference voltage (2.75V) for the current sensors of the DC input side. Error in the measurement technology.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	-
237	DC input polarity reversed	At least one DC input is connected with reversed polarity, i.e. + and - are reversed.	Has the polarity at the DC connections been checked? If necessary, check polarity according to chapter 7.6.5.	-
238	Error configuration (DC input)	The internal configuration data on the DC input side is incorrect.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If not successful, contact the service department.	-
239	-	The DC current measurements in the unit are not plausible.	If the unit displays the same message after restarting (AC / DC disconnection) => contact Service.	-
240	Feed-in limitation	Feed-in limitation active	-	-
241	Exceeding the feed-in limitation	Grid disconnection due to exceeding a set maximum feed-in limitation.	Device restart attempted? (Disconnect AC/DC – switch it back on after 5 minutes.) => If no success, contact the service department.	-
242	No communication with the external measuring equipment	Grid disconnection due to communication failure of the external measuring equipment.	Check the function and location of the external measuring equipment.	-

**NOTE****Event number not found?**

If event numbers are displayed on the device but are not listed here, then it is usually necessary to have this looked at by your installation partner.

**NOTE****Quick remedy through provision of the service package**

If events occur irregularly, our service technician needs to have the service package stored on the device. You must download and send this under the menu item "Service" – "Export Service Package". See table : Configuration via web user interface [▶ Page 73]

12 Decommissioning and dismantling

12.1 Switching off the device



⚠ DANGER

Lethal voltages are still present in the connections and cables of the device even after the device has been switched off and disconnected!

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched.

1. Comply with all safety regulations and current technical connection specifications of the responsible power supply company.
2. The device is only permitted to be opened or serviced by a qualified electrician.
3. Switch off the grid voltage by turning off the external circuit breakers.
4. Capacitor discharge time: Wait at least 5 minutes before opening.
5. Do not touch the cables and/or terminals/busbars when switching the device on and off.
6. Keep the device closed when in operation.



⚠ DANGER

Destruction of the DC plug connectors

DC plug connectors can be destroyed by arcing if disconnected while still live. It is absolutely essential that the following shutdown sequence be carried out in the correct order:

1. Check that there is no current in any of the DC cables using a clip-on ammeter.
2. Switch off the DC circuit breaker for the selected string. Disconnect the DC connections one by one.

12.2 Disconnecting connections

12.2.1 AC connection

- ⌚ Ensure that the device is completely free of AC/DC voltage.
- ⌚ Remove the housing cover and put it aside.

1. Detach cables (L1/L2/L3/N) from the AC connection terminal [XW_17].
2. Detach the PE line from the earthing bolt [XW_17].
3. Loosen the cable fitting and pull the cables out through the cable fitting [XW_46].

NOTE: If the AC cable does not fit through the cable fitting due to the size of the cable lug, then the AC cable must be severed at the cable lug.

4. Place protective caps on the ends of the AC cables.

12.2.2 DC connection

- ⌚ Ensure there is no AC/DC voltage present.
- ⌚ Check that there is no current using a clip-on ammeter.
- ⌚ **NOTE: Plug connectors may be unplugged under voltage, but never under load.**

1. Use a screwdriver (blade width 3 mm) to push out the latch on the coupling.
2. Leave the screwdriver in place.
3. Disconnect the DC connector from the DC socket.




Fig. 95: Unplugging the plug connector

1 Screwdriver 2 Latch

12.3 Uninstalling the device



⚠ DANGER

Dangerous voltage due to two operating voltages

Severe injuries or death may occur if the cables and/or terminals/busbars in the device are touched. The discharge time of the capacitors is up to 5 minutes.



1. Only appropriately qualified electricians authorised by the mains supply network operator are permitted to open and maintain the device.
2. Before opening the device: Disconnect the AC and DC sides and wait at least 5 minutes.

NOTE: Uninstalling the device involves removing the attached screw with lock nut or a padlock.

⌚ Device shut down and no voltage is present.

1. Remove the screw and lock nut from the left/right pedestal/carrying handle and place it back in the assembly bag.
2. Optional: Remove the attached padlock from the left / right pedestal/carrying handle and keep it for your own safekeeping. (not in scope of supply)




Fig. 96: Securing the device with a padlock

- ⌚ The device is switched off and a check has been performed to ensure that it is de-energised.
- ⌚ AC cable disconnected [See section 12.2.1 ▶ Page 117].
- ⌚ DC connection disconnected [See section 12.2.2 ▶ Page 117].

1. Undo the cable fitting for Ethernet cables [~~X~~W_29].
2. Undo the cable fitting for RS485 cables [~~X~~W_20].
3. Disconnect the plug from the communication circuit board.
4. Remove the interface cables from the device.
5. Insert the sealing plug in all open cable fittings.

⇒ The device has been uninstalled. Proceed with removal.

12.4 Removing the device

⌚ Device has been switched off and uninstalled.

1. Release the safety clip or safety lock from the lower device fastening.
2. Use the lateral openings and remove the device from the wall or PV shelter fastening.

⇒ The device has been uninstalled. Proceed with removal.

12.5 Packaging the device

⌚ Device has been uninstalled.

1. If possible, always pack the device in the original packaging. If this is no longer available, an alternative is to use equivalent packaging.
2. You must be able to close the box completely and it must be able to accommodate the weight and size of the device.

12.6 Storing the device



NOTE

Risk of damage to property as a result of condensation

Faulty storage can form condensate in the device and impair the functionality of the device (e.g. storage outside the ambient conditions or temporary relocation from a cold to a hot environment).

1. Prior to installation, check the inner area for condensation and if necessary, allow it to dry sufficiently before installation.
2. Store in accordance with the technical data > [See section 4.3 ▶ Page 14]

**NOTE****Storage period limited to 5 years if the device described has only ever been in storage**

With increasingly long storage times, the aluminium oxide layer (dielectric) in electronic components deteriorates, leading to significant leakage currents.

To prevent this, an anti-ageing process should be carried out. In this process, the aluminium oxide layer is re-stored to its original state. This reformation process should reduce the leakage current to less than 3 mA or to the corresponding specified value, thereby ensuring the longevity and functional capability of the component.

↻ Device packaged.

1. Keep the device in its original packaging.
2. The packaging containing the device must not be tilted over or turned upside down.
3. Store the device at a dry location, in accordance with the ambient temperature range [See section 4.3 ▶ Page 14].
4. If the device has been stored for 6 months or longer, it must be completely inspected and tested by specialists before it can be put into operation.

13 Disposal



CAUTION

Risk to the environment if disposal is not carried out in the correct manner

For the most part, both the device and the corresponding transport packaging are made from recyclable raw materials.

Device: Do not dispose of faulty devices or accessories together with household waste. Ensure that the old devices and any accessories are disposed of in a proper manner.

Packaging: Ensure that the transport packaging is disposed of properly.

14 Service and warranty

KACO-Service

If you need help solving a technical problem with KACO products, please contact our service hotline.

Please have the following information ready so that we can help you quickly and efficiently:

- Device name / serial number
- Date of installation / Start-up report
- Consignment identification / Delivery address / Contact person (with telephone number)
- Information about the accessibility of the installation site

You can find the following items and other information at our website [Kaco-newenergy](https://www.kaco-newenergy.com):

- our current warranty conditions,
- a complaint form,
- a form for registering your device. Please register your device without delay. In this manner, you can assist us in providing you with the quickest service possible.



NOTE

Specific length of warranty

The maximum length of the warranty is based on the currently applicable national warranty conditions.

15 Appendix

15.1 EU Declaration of Conformity (EN)

Manufacturer's name and address	KACO new energy GmbH Werner-von-Siemens-Allee 1 74172 Neckarsulm, Germany, Germany	
Product description	Photovoltaic feed-in inverter	
Type designation [KACO art. no.]	KACO blueplanet 100 NX3 M8 WM OD IIGX	[1002081] variant „B“
	KACO blueplanet 100 NX3 M8 WM OD IIGM	[1002132] variant „M“
	KACO blueplanet 100 NX3 M8 WM OD FRGM	[1002133] variant „MF“
	KACO blueplanet 100 NX3 M8 WM OD IIGL	[1002170] variant „L“
	KACO blueplanet 125 NX3 M10 WM OD IIGX	[1002080] variant „B“
	KACO blueplanet 125 NX3 M10 WM OD IIGM	[1002131] variant „M“
	KACO blueplanet 125 NX3 M10 WM OD FRGM	[1002130] variant „MF“
	KACO blueplanet 125 NX3 M10 WM OD IIGL	[1002171] variant „L“

15.2 Standards & directives

This is to confirm that the devices listed above comply with the protection requirements set forth in the Directive of the Council of the European Union of 26th February 2014 on the harmonisation of the laws of the member states relating to Electromagnetic Compatibility (2014/30/EU) and the Low Voltage Directive (2014/35/EU).

The devices conform to the following standards:

2014/35/EU	Safety of the device
"Directive relating to electrical equipment designed for use within certain voltage limits"	EN 62109-1:2010 EN 62109-2:2011
2014/30/EU	Interference immunity
"Directive relating to electromagnetic compatibility"	EN IEC 61000-6-1:2019 EN 61000-6-1:2007 EN IEC 61000-6-2:2019 EN 61000-6-2:2005 + AC:2005 EN 62920:2017 + A11:2020 + A1:2021
	Emitted interference
	EN 62920:2017 + A11:2020 + A1:2021 Class A EN 55011:2016 + A1:2017 + A11:2020 + A2:2021 group 1, Class A* *DC → > 20 kVA ≤ 75 kVA
	EN IEC 61000-6-4:2019 EN 61000-6-4:2007 + A1:2011
	Secondary effects on the grid
	EN 61000-3-11:2000 EN IEC 61000-3-11:2019 EN 61000-3-12:2011
2011/65/EU	RoHS
"Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment"	EN IEC 63000:2018 (Technical documentation for the assessment of electrical and electronic equipment with regard to the restriction of hazardous substances)

The types mentioned above are therefore labelled with the CE mark.

Unauthorised modifications to the supplied devices and/or any use of the devices that is contrary to their intended use render this Declaration of Conformity null and void.

This Declaration of Conformity is issued under the sole responsibility of KACO new energy GmbH.



The text and figures reflect the current technical state at the time of printing. Subject to technical changes. No liability for printing errors.



3016262-04-251015