




Rapid Shutdown

XRSD-1C/XRSD-2C

XRSD-Core Kit

User Manual

Version 2.0

www.solaxpower.com



eManual in the QR code or
at www.solaxpower.com

STATEMENT

Copyright

Copyright © SolaX Power Network Technology (Zhejiang) Co., Ltd. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of SolaX Power Network Technology (Zhejiang) Co., Ltd.

Trademarks



SOLA^{POWER} and other symbol or design (brand name, logo) that distinguishes the products or services offered by SolaX has been trademark protected. Any unauthorized use of above stated trademark may infringe the trademark right.

Notice

All or part(s) of the products, features and services described in this document may not be within your scope of purchase or usage. Unless otherwise specified in the contract, the contents, information and recommendations in this document are provided as is, SolaX makes no kind of warranties, guarantees or representations expressly or implicitly.

The content of the documents is continually reviewed and amended, where necessary. However, discrepancies cannot be excluded. SolaX reserves the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without the prior notice.

The images contained in this document are for illustrative purposes only and may vary depending on product models.

Please visit the website www.solaxpower.com of SolaX Power Network Technology (Zhejiang) Co., Ltd. for more information.

SolaX reserves all the right for the final explanation.

About This Manual

Scope of Validity

This manual is an integral part of the SolaX XRSD-1C/2C and XRSD-Core Kit. It describes the detailed information, installation, and usage of the product. Please read it carefully before operating.

XRSD	XRSD-1C ^{*1}
(SolaX Rapid Shutdown Device)	XRSD-2C ^{*1}
Transmitter Kit	XRSD-Core Kit ^{*2}

Note:

^{*1} "1C" means one input. "2C" means two inputs.

^{*2} XRSD-Core Kit includes an outdoor enclosure, an 85–264 V power supply, a transmitter, and one core (two cores are optional).

Target Group

The installation, maintenance and grid-related setting can only be performed by qualified personnel who

- Are licensed and/or satisfy state and local jurisdiction regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
 DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION!	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE!	Provides tips for the optimal operation of the product.

Change History

Version 2.0 (2026/01/17)

Updated["5 Technical Data"](#)(Max. PV input current).

Version 1.0 (2025/12/23)

["2.2 XRSD"](#) Added a requirement stating that when using the XRSD-2C, both INPUT1 and INPUT2 ports must be connected to PV modules.

["3.1 Safety Precautions"](#) Added a precaution stating that the RSD enclosure must not come into contact with oil-based substances.

Updated["5 Technical Data"](#)(Max. PV input current and operating temperature range).

Deleted document material number QR code and contact information.

Version 0.0 (2024/11/20)

Initial release

Table of Contents

- 1 Safety 1
 - 1.1 General Safety 1
 - 1.2 Safety Instructions 2
- 2 Product Overview 4
 - 2.1 System Description 4
 - 2.2 XRSD 5
 - 2.3 XRSD-Core Kit..... 6
 - 2.4 Symbols on the Device 7
- 3 Installation 8
 - 3.1 Safety Precautions 8
 - 3.2 Scope of Delivery..... 10
 - 3.3 Tools Requirement..... 12
 - 3.4 XRSD Installation 14
 - 3.5 XRSD-Core Kit Installation 20
 - 3.6 Conduit Drilling Guide 31
- 4 Rapid Shutdown methods..... 32
 - 4.1 Automatic shutdown 32
 - 4.2 Manual shutdown 32
- 5 Technical Data 33
- 6 Appendix 35

1 Safety

1.1 General Safety

Safety precautions must be strictly observed and followed to reduce the risk of personal injury and ensure a safe installation.

Before installing the device, carefully read, fully understand, and strictly follow the detailed instructions of the user manual, related sections of your inverter manual, and other regulations. And the safety instructions in this document are only supplements to local laws and regulations.

SolaX shall not be liable for any consequences caused by the violation of the storage, transportation, installation, and operation regulations specified in this document, including, but not limited to:

- Product damage due to force majeure, such as an earthquake, flooding, thunderstorm, lighting, fire hazard, volcanic eruption, etc.
- Product damage due to man-made causes
- Product used or operated against any items in local policy
- Failure to follow the operation instructions and safety precautions on the product and in this document
- Not install and operate within the [5 Technical Data \(P33\)](#) listed in their datasheets.
- Unauthorized modifications to the product or software
- Product damage caused during transportation by the customer
- Installation and commissioning are operated by unauthorized personnel who are not licensed and/or satisfy state and local jurisdiction regulations.

1.2 Safety Instructions

Please read these instructions carefully, and use this product correctly and safely. After reading, please keep these instructions in a safe place

DANGER!

- When exposed to sunlight, high DC voltage will be generated by PV modules. Death or lethal injuries will occur due to electric shock.
- Do not attempt to install in inclement weather.
- The installation, wiring, or maintenance of the XRSD and XRSD-Core Kit can only be performed by qualified and experienced electricians.
- In order to avoid electric shock, do not open the enclosure of the XRSD. And the disassembly or maintenance of this product must be operated by a qualified person.
- Please perform all electrical installations in accordance with local codes.
- Use insulated tools when installing the device. Individual protective tools must be worn during installation, electrical connection, and maintenance.
- Do not touch non-insulated parts or cables.
- Do not install the XRSD in the situation of having been physically damaged or meeting the wiring standards any more.
- Do not use connectors from different manufacturers for risks of burns can be produced due to incompatible connectors.

DANGER!

- Do not connect or disconnect the XRSD while the inverter is running. And turning off the inverter and/or the XRSD products may not reduce this risk. After disconnecting all power sources, internal capacitors within the inverter can remain charged for several minutes.
- If service is required, verify capacitors have discharged by measuring a voltage across inverter terminals before disconnecting wiring.
- After rapid shutdown activation, wait 30 seconds before disconnecting DC cables or turning off DC disconnect switch.
- Do not disconnect the PV module from the XRSD without first disconnecting the AC power of the XRSD-Core Kit.
- Make sure that the emergency stop button is pressed to cut off the AC power during installation.
- The power supply of the XRSD-Core Kit MUST be on the same AC branch circuit as the inverter in order to meet the rapid shutdown requirement.

**WARNING!**

- Do not touch the XRSD when it is running. Surface high temperature may cause burns or personal injury.
- Do not attempt to repair the device if it is not working properly, please contact the SolaX Customer Support team. Any attempt to repair the XRSD will automatically void the warranty.

**CAUTION!**

Keep the products away from children.

NOTICE!

All the labels and nameplate on the product shall be maintained clearly visible.

2 Product Overview

2.1 System Description




Figure 2-1 Enables rapid shutdown(XRSD-1C)




Figure 2-2 Enables rapid shutdown(XRSD-2C)

The XRSD is part of the rapid shutdown solution when paired with the XRSD-Core Kit.

The XRSD-Core Kit is installed in line with a solar PV inverter. It continuously sends a 'keep-alive' signal to the XRSD, ensuring a stable connection between the PV modules and the inverters. When XRSD receive an uninterrupted 'keep-alive' signal from the XRSD-Core Kit, they will operate the PV system as expected.

However, when power to the XRSD-Core Kit having been cut, this signal will cease and send every XRSD into shutdown mode to ensure system safety.

In this way, once the AC power supply of the XRSD-Core Kit is lost, the PV array enters rapid shutdown.

2.2 XRSD



As part of the SolaX rapid shutdown solution for PV system, XRSD-1C can be connected to one PV module while XRSD-2C can be connected to two.

* When using the XRSD-2C, both the INPUT1 and INPUT2 ports must be connected to PV modules. **If only one PV module is connected, the XRSD-1C must be used instead.**

Highlights

- Meets NEC2017&NEC2020 690.12 requirements
- One or two inputs, Max. PV input current 20 A
- PLC communication, rapid shutdown
- Clip installation design, simple and convenient
- Lower power consumption and wider operating voltage range
- IP68 protection, long life cycle
- High security: overvoltage protection, overcurrent protection, overtemperature protection

2.3 XRSD-Core Kit

The XRSD-Core Kit, in tandem with XRSD, forms a crucial segment of the SOLAX rapid shutdown system. It includes an outdoor enclosure, an 85–264 V power supply, a transmitter, and one core (two cores are optional).

Highlights



- Meets NEC2017&NEC2020 (690.12)
- Realize rapid shutdown by simply powering off the XRSD-Core Kit or using external initiator on the enclosure
- Equipped with one or two cores (two cores are optional)
- IP65 protection

2.4 Symbols on the Device

The information on the device includes technical data and serial number of the device. Safety instructions on the label are listed and explained below :

Table 2-1 Description of symbols

Symbol	Description
	Danger of high voltages. Danger to life due to high voltages in the inverter!
	Danger. Risk of electric shock!
	Observe enclosed documentation.
	Double insulation symbol The device does not require a safety connection to electrical earth (ground).
	CE mark. The device complies with the requirements of the applicable CE guidelines.
	The device can not be disposed together with the household waste. Disposal information can be found in the enclosed documentation.

3 Installation

3.1 Safety Precautions

- Do not attempt to install in inclement weather.
- Only qualified personnel can perform the mechanical installation.
- Perform all electrical installations in accordance with local codes.
- Be equipped with individual protective tools and insulated tools when installing the XRSD and XRSD-Core Kit.
- Before installing or using XRSD, please read all instructions and warnings in the user manual, on the inverter system, and on the PV array.
- Follow the installation steps sequence to install. Damage caused by improper installation will not covered by warranty.
- Make sure the voltage, current and power specification of PV modules match the XRSD specifications.
- The maximum open circuit voltage of the PV module must not exceed the specified maximum input voltage of the XRSD.
- Never apply an external voltage source to a module or string that is equipped with XRSD.
- Connect XRSD to its respective modules before connecting its outputs in series.
- Install XRSD before powering on the XRSD-Core Kit.
- If parallel string connections are needed, first connect the XRSD to the PV modules, then connect all outputs of XRSD in series, and finally pass one side (+ or -) of the string through the transmitter to turn the system ON.
- Do not touch any live parts in the system, including the PV array, when the system has been connected to the electrical grid.

- Avoid contact between the XRSD enclosure and oil-based substances, as such contact may adversely affect the service life of the enclosure.
- After installing XRSD and XRSD-Core Kit, place the rapid shutdown system label within 1m of the emergency stop button or AC disconnect.





Figure 3-1 Rapid shutdown system label

3.2 Scope of Delivery

XRSD



* Refer to the actual purchase quantity.

XRSD-Core Kit






















Table 3-1 XRSD-Core Kit Packing list

Item	Description	Quantity	Remark
A	Outdoor enclosure	1 pcs	
B	Mounting lugs	4 pcs	
C	Round head screws	4 pcs	For wall-mounting instalation
D	Plastic wall anchor & Self-Tapping screw	4 pairs	
E	DIN35 rail	1 pcs	
F	M4.8*L10 screw	2 pcs	For securing DIN35 rail
G	Clamps	2 pcs	
H	AC power Supply	1 pcs	
I	Transmitter	1 pcs	
J	Core	1/2 pcs(optional)	
K	Zip ties	4 pcs	
L	Documents	/	

* Refer to the actual delivery for the optional accessories.


3.3 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.

 Torque screwdriver (Phillips head: PH2)	 Step drill bit	 Measuring tape	 Utility knife
 Hammer drill (drill bit: Ø10 mm)	 Marker	 Spirit level	 Rubber mallet
 Wire stripper	 Wire cutter	 Crimping tool for PV terminals	 PV connector disconnect tool
 Torque wrench (Including 16 mm wrench)	 Flat-head screwdriver	 Multimeter (≥ 1100 V DC)	
 Safety gloves	 Safety boots	 Safety goggles	 Anti-dust mask

Additionally Required Materials

Table 3-2 Additionally required wires

No.	Required Material	Type	Quantity
1	PV cable	 According to the inverter type	/
2	MC4 PV Connector	 match with PV cable of inverter	/
3	Waterproof connectors with corrugated pipe	 M12(for power cable port)	1 pcs
			2 pcs (single core)
			4 pcs (dual core)
4	power cable of XRSD-Core Kit	 2 Core, 0.5 A Conductor diameter:24 AWG Overall diameter:match with waterproof connectors	/

* M25: Max. Number of Strings- 2.5

M32: Max. Number of Strings- 5

3.4 XRSD Installation



WARNING!

- Make sure that the PV system is powered off.
- When installing XRSD, connect the input cables to the PV module before connecting the XRSD output cables in series.
- When disconnect XRSD, disconnect XRSD output cables from a string before disconnecting the XRSD input cables from the module junction box.
- Connectors from different manufacturers cannot be mated with each other.

NOTICE!

- Do not place the XRSD (including DC connectors) where exposed to the sun, rain or snow, even gap between modules.
- Allow a minimum of 1.5 cm of space between the roof and the XRSD enclosure in order to ensure ventilation and heat dissipation.
- Recommended model for PV module connectors:
Dian Wei Electronic Technology (Vaconn Interconnection Solution)
VP-D4B-CTSF4
VP-D4B-CTSM4
We are not responsible for any problems caused by using other models.

XRSD-1C



Figure 3-2 XRSD-1C terminal

Step 1: Remove the serial number label on the machine package and attach it on the corresponding position on the [installation map](#), which is used to model the physical layout of the roof module.




Figure 3-3 Stick the serial number label on the installation map

Step 2: Install XRSD on the frame of the PV module with mounting brackets.




Figure 3-4 Buckle XRSD on the PV module frame

Step 3: Connect PV modules to XRSD inputs. Each XRSD must have a PV module connected to its inputs. You can use the DC extension cable if necessary.




Figure 3-5 Connect PV modules to XRSD inputs

Step 4: Use a multimeter to measure the XRSD-1C output voltage. The output voltage should be 0.2–1.5 V.




Figure 3-6 Measure the XRSD-1C output positive/negative voltage

Step 5: Connect the output of two adjacent XRSDs together.




Figure 3-7 Connect XRSD outputs in series

XRSD-2C




Figure 3-8 XRSD-2C terminal

Step 1: Remove the serial number label on the machine package and attach it on the corresponding position on the [installation map](#), which is used to model the physical layout of the roof module.




Figure 3-9 Stick the serial number label on the installation map

Step 2: Install XRSD on the frame of the PV module with mounting brackets.




Figure 3-10 Buckle XRSD on the PV module frame

Step 3: Connect modules to XRSD inputs. Each XRSD must have a PV module connected to its inputs.
You can use the DC extension cable if necessary.




Figure 3-11 Connect PV modules to XRSD inputs

Step 4: Use a multimeter to measure the XRSD-2C output voltage. The output voltage should be 0.2–1.5 V.




Figure 3-12 Measure the XRSD-2C output positive/negative voltage

Step 5: Connect the output of two adjacent XRSDs together.




Figure 3-13 Connect XRSD outputs in series

3.5 XRSD-Core Kit Installation

XRSD-Core Kit box drilling

Step 1: Drill holes on the sides of the enclosure by using the drilling template.
For detailed size please refer to [3.6 Conduit Drilling Guide \(P31\)](#)
Remove burrs after drilling holes.

Step 2: Install the waterproof connectors to ensure the safety of the box.




Figure 3-14 Install waterproof connectors

Step 3: Fix the mounting lugs with round head screws at the four corners of the box.





Figure 3-15 Fix mounting lugs with round head screws

Box inside installation



Connection diagram

Step 4: Fix the DIN rail onto **the second row** from the top.




Figure 3-16 Fix DIN rail

Step 5: Mount AC power supply, transmitter, SolaX Pocket WiFi+LAN, and cores on DIN rail in the following order.

- 1) Fix a clamp at the left ends of the rail, then use a one-screwdriver to cock the edge of the clamp and snap it into the rail slot.




Figure 3-17 Fix clamp

- 2) Pull down the bottom latch of the power supply.
Attach the power supply to the rail and push the latch back.




Figure 3-18 Fix power supply

- 3) Pull down the latch of transmitter.
After fixing the transmitter to the rail, push the latch back.
Install another clamp next to the transmitter.




Figure 3-19 Fix transmitter and clamp

- 4) Insert the cores into the bottom of the transmitter until you hear a "click". If there is only single core , connect Core 1 to PLC1 first.




Figure 3-20 Insert the cores

- Step 5:** Connect the emergency stop switch wire to the power supply and fix it to the rail. Then secure the wires with a flat-head screwdriver.
red/black wire — Power supply "+" / "-" port
plastic terminal — Transmitter "+12V-GND" port (Align the red wire with the "+12V" port and the black wire with the "GND" port.)




Figure 3-21 Connect emergency stop switch wire

Wall mounting




Figure 3-22 Recommended installation distance

Step 6: Lock the XRSD-Core Kit box.

Align the enclosure horizontally on the wall with spirit level: adjust the enclosure until the bubble stays in the middle.

Mark the position of the drill holes.




Figure 3-23 Mark the holes of XRSD-Core Kit box

Step 7: Set the enclosure aside and drill holes.(Drill bit:Ø10; Depth:60-80 mm)
Insert the expansion bolt into holes by using a rubber mallet.




Figure 3-24 Drill the holes

Step 8: Use a torque wrench to secure the enclosure to the wall with expansion bolts.





Figure 3-25 Secure the expansion bolts

Wire connection



! DANGER!

Press the emergency stop button to cut off the AC power before wire connection.

Step 9: Pull the PV cable through a corrugated pipe into the box.




Figure 3-26 Pull the PV cable through corrugated pipe

Step 10: Connect wires to N,L port of power supply from grid or inverter. Pass the same positive PV cable(+) **or** the same negative PV cable(-) through cores. Then run the PV cables through the box to the inverter.

NOTICE!

For SolaX Energy storage inverter, connect AC wires from **EPS terminal**.




Figure 3-27 Ingle Core-cable connect




Figure 3-28 Dual cores-cable connect

NOTICE!

If the number of PV strings exceeds 10, do not pass PV cable (-) through the box, connect it to the inverter from outside the box.

Step 11: Strip the 7 mm insulation of the PV cables and insert the stripped cable into the PV pin contact. Crimp it with crimping tool for PV terminal.




Figure 3-29 Stripping the PV cable and insert to PV pin contact


Step 12: Make the MC4 connector for PV cables.

Figure 3-30 Making MC4 connectors

CAUTION!

Make sure the the PV cable and PV pin contact are of the same polarity.


Step 13: Connect the serially connected outputs of XRSD to the inverter with the assembled connectors until there is an audible "Click".

Figure 3-31 Connect outputs of XRSD to the inverter

NOTICE!

- Max cable length from inverter(+) to inverter(-) : 10 m–200 m
- When multiple inverters are connected to the grid, each inverter needs to be grounded separately.

Commissioning

Step 1: Release the emergency stop button to turn on the AC power.




Figure 3-32 Twist emergency stop button

Step 2: Turn the DC switch of the inverter to ON position.





Figure 3-33 Turning on the DC switch

Step 3: After waiting for about 1 minute, please check the voltage of the series circuit displayed on the inverter. The voltage should be module open circuit voltage* the number of modules.

NOTICE!

After installing XRSD and XRSD-Core Kit, fill gaps around pipes both outside and inside with seal putty.



3.6 Conduit Drilling Guide




Figure 3-34 Drilling Guide for 1"and .75" Conduit

4 Rapid Shutdown methods

XRSD can be shutdown automatically or manually.

4.1 Automatic shutdown

Automatic shutdown will occur if any of the following conditions are met:

- Over temperature
When the temperature sensor on the XRSD detects ambient temperature is over **85°C**.
- Over voltage
When a single PV module voltage exceeds **80 V**.
- Over current
When a single PV module current exceeds **20 A**.

4.2 Manual shutdown



AC Supply Cut-Off

Shut down solar panel by disconnecting the external AC supply.

Activate an external initiator

Activate an external initiator when there is an emergency, then the PV system will enter module-level rapid shutdown within the time specified by the safety regulations.

The Emergency Switch can be conveniently located at ground level for easy access, and multiple switches can be installed in different multi-level building zones.




5 Technical Data

- XRSD

Model	XRSD-1C	XRSD-2C
Electrical Data		
Input voltage range	8–80 V	8–80 V / 8–80 V
Output voltage range	8–80 V	16–160 V
Max. PV input current	20 A	20 A
Max. short circuit current	26 A	26 A
Recommended fuse rating	30 A	30 A
Maximum system voltage	1500 V	1500 V
Mechanical		
Dimensions(W x D x H) (Without cables and connectors)	130 x 21 x 36 mm	135 x 20 x 59 mm
Weight(Including Cables)	400 g	720 g
Input cable length	0.2 m	0.45 m
Output cable length	1.2 m	2.4 m
Input / Output connectors	MC4 (standard)	
Communication type	PLC	
Environment limit		
Altitude	0–3000 m	
Pollution degree	3	
Protection class	IP68	
Operating temperature range	-40°C to +65°C	
Humidity	4% – 100%	
Over voltage category	II	
Compliance		
Safety	IEC/EN62109-1, EN IEC 61000-6-1/2/3/4	

* XRSD does not have an automatic shutdown function for arc detection. When the system is abnormal, the transmitter signal is cut off by powering off the XRSD-Core Kit or using external initiator on the enclosure, which triggers shutdown. While XRSD is designed to reduce the risk of fire suppression, it does not eliminate the risk of an arc fire.

Unit: mm




• XRSD-Core Kit

Model	XRSD-Core Kit
Electrical Data	
Power Supply Input Voltage	85–264 Vac
Transmitter Input Voltage	12 Vdc (±2%)
Transmitter Input Current	1 A
Core	
Max. Number of Configure Core	2
Max. Current per Core	150 A
Max. String Voltage	1500 Vdc
Diameter	31 (inner) /52mm (outer)
Max. Number of Strings per Core*	11
Mechanical	
Dimensions(W x D x H)	200 mm x 170 mm x 300 mm
Environment limit	
Altitude	0–3000 m
Pollution degree	3
Protection class	IP65
Operating temperature range	-40°C to +75°C
Humidity	4 – 100%
Over voltage category	III
Compliance	
Safety	IEC/EN62109-1, EN IEC 61000-6-1/2/3/4

* This data refers to a cable diameter of Ø6 mm.If cable diameter is more than Ø6 mm,Strings Per Core will be reduced.
Extra precaution must be taken to avoid exceeding the permissible current limit.

Unit: mm



6 Appendix



Make sure N for North



Panel type:
Azimuth:
Tilt:
Sheet of _

Customer information:

XRSD Core kit series number:

COLUMN

ROW

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

A

B

C

D



SolaX Power Network Technology (Zhejiang) Co., Ltd.

Add.: No. 278, Shizhu Road, Chengnan Sub-district, Tonglu County,
Hangzhou, Zhejiang, China
E-mail: info@solaxpower.com